


Instruction Manual • May 2006



 **SmartLinX**[®]

million
in one

smartlinx

PROFIBUS DP

MILLTRONICS

Safety Guidelines: Warning notices must be observed to ensure personal safety as well as that of others, and to protect the product and the connected equipment. These warning notices are accompanied by a clarification of the level of caution to be observed.

Qualified Personnel: This device/system may only be set up and operated in conjunction with this manual. Qualified personnel are only authorized to install and operate this equipment in accordance with established safety practices and standards.

Unit Repair and Excluded Liability:

- The user is responsible for all changes and repairs made to the device by the user or the user's agent.
- All new components are to be provided by Siemens Milltronics Process Instruments Inc.
- Restrict repair to faulty components only.
- Do not reuse faulty components.

Warning: This product can only function properly and safely if it is correctly transported, stored, installed, set up, operated, and maintained.

Note: Always use product in accordance with specifications.

Copyright Siemens Milltronics Process Instruments Inc. 2006. All Rights Reserved	Disclaimer of Liability
This document is available in bound version and in electronic version. We encourage users to purchase authorized bound manuals, or to view electronic versions as designed and authored by Siemens Milltronics Process Instruments Inc. Siemens Milltronics Process Instruments Inc. will not be responsible for the contents of partial or whole reproductions of either bound or electronic versions.	While we have verified the contents of this manual for agreement with the instrumentation described, variations remain possible. Thus we cannot guarantee full agreement. The contents of this manual are regularly reviewed and corrections are included in subsequent editions. We welcome all suggestions for improvement. Technical data subject to change.

MILLTRONICS® is a registered trademark of Siemens Milltronics Process Instruments Inc.

Contact SMPI Technical Publications at the following address:

Technical Publications
Siemens Milltronics Process Instruments Inc.
1954 Technology Drive, P.O. Box 4225
Peterborough, Ontario, Canada, K9J 7B1
Email: techpubs.smpi@siemens.com

- For a selection of Siemens Milltronics level measurement manuals, go to: www.siemens.com/processautomation. Under Process Instrumentation, select *Level Measurement* and then go to the manual archive listed under the product family.
- For a selection of Siemens Milltronics weighing manuals, go to: www.siemens.com/processautomation. Under Weighing Technology, select *Continuous Weighing Systems* and then go to the manual archive listed under the product family.

Table of Contents


SmartLinx PROFIBUS DP	1
Technical Support and Product Feedback	1
Safety Notes.....	2
The Manual	2
Specifications	3
Installation.....	4
Compatibility.....	4
Software Compatibility.....	4
Hardware Compatibility	5
Cable Connector.....	7
Termination Switch	9
Operation	10
Error Status LEDs	10
Error Conditions of the Red Diagnostics Light	11
Operation LED	11
Communication Setup	12
GSD Files.....	12
Baud Rate	12
Bus Address.....	12
Configuring the Slave Device.....	13
Map Element Selection	14
P762 Map Element Selection parameter.....	14
Module Identification	16
P794 SmartLinx Module Type.....	16
P795 SmartLinx Protocol	16
P634: Communication Totalizer Resolution.....	17
Application Layer	18
Parameter Indexes	18
Primary Index	18
Secondary Index	19
Data Access Methods	19
Direct Access.....	19
Multiple Parameter Access (MPA)	20
Single Parameter Access (SPA).....	21
Data Map: Level Products	23
Write Block.....	23
Read Block.....	26
Data Map: Mass Dynamic Products.....	30
Write Block.....	30
Read Block.....	34
Data Types.....	40

Integer	40
Bit Values	40
Unsigned Double Precision Integer (UINT32)	41
Split Values	41
Text Messages	42
Relay Function Codes (P111 in Level Products Only)	43
Troubleshooting	45
Generally	45
Technical Support or Product Feedback.....	45
Appendix A – Reducing the amount of data being transferred over the Bus	46
Level Products	46
Write Block	47
Read Block.....	49
Mass Dynamics Products	51
Write Block	52
Read Block.....	54
Index	56

SmartLinx PROFIBUS DP

The Siemens Milltronics SmartLinx¹ PROFIBUS DP module is a plug-in communications card designed to interface a Siemens Milltronics SmartLinx-compatible instrument to a PROFIBUS DP network.

Only those instruments which support the PROFIBUS DP protocol can use this card. See *Compatible Instruments* on page 3 for a list of compatible Siemens Milltronics SmartLinx instruments.



PROFIBUS is an open standard controlled by PROFIBUS industry groups worldwide. More information is available on the web site at www.profibus.com.

Note: Siemens Milltronics does not own the PROFIBUS DP protocol. All information regarding that protocol is subject to change without notice.

Technical Support and Product Feedback

For product feedback or technical support, please contact your local Siemens Milltronics representative or e-mail us at www.siemens.com/automation/support-request.

¹ SmartLinx[®] is a registered trademark of Siemens Milltronics Process Instruments Inc.

Safety Notes

Special attention must be paid to warnings and notes highlighted from the rest of the text by grey boxes.



WARNING: relates to a caution symbol on the product, and means that failure to observe the necessary precautions can result in death, serious injury, and/or considerable material damage.



WARNING: means that failure to observe the necessary precautions can result in death, serious injury, and/or considerable material damage.

CAUTION: means that failure to observe the necessary precautions can result in considerable material damage.

Note: means important information about the product or that part of the operating manual.

The Manual

Notes:

- Please follow the installation and operating procedures for a quick, trouble-free installation and to ensure the maximum accuracy and reliability of your Siemens Milltronics SmartLinx PROFIBUS DP module.
- This manual applies to the SmartLinx PROFIBUS DP module only.

This manual will help you install and connect a Siemens Milltronics SmartLinx PROFIBUS DP module, and set it up for communication with a master device on a PROFIBUS DP network. The manual is targeted at a technical audience in the industrial communications field with a sound working knowledge of PROFIBUS DP. (Please see next page for more details.)

We always welcome questions, comments, or suggestions about manual content, design, and accessibility.

Please direct your questions or comments to techpubs.smpi@siemens.com. For the complete library of Siemens Milltronics manuals, go to www.siemens.com/processautomation.

Specifications

Application:

- compatible with a master device on a PROFIBUS bus

Compatible Instruments:

- AiRanger XPL Plus / SITRANS LU 10
- AiRanger DPL Plus / SITRANS LU 02
- AiRanger SPL / SITRANS LU 01
- CraneRanger
- InterRanger DPS 300
- EnviroRanger ERS 500
- Milltronics BW500
- Milltronics SF500
- MultiRanger 100/200
- HydroRanger 200

Communication Settings:

- baud rate: 9.6 Kbaud to 12 Mbaud, automatically detected

Connection:

- varies by Siemens Milltronics SmartLinx[®] instrument, (see page 7)

Termination:

- switch selectable, open or special active termination as per PROFIBUS specification (see *Termination Switch* on page 9)

Cable:

- Belden PROFIBUS cable 3079A, or equivalent

Installation

The SmartLinX module is either shipped installed in the Siemens Milltronics instrument or shipped separately for on-site installation. Refer to the manual of your Siemens Milltronics instrument for details on module location and physical installation.

Compatibility

For the SmartLinX PROFIBUS card there are different hardware and software configurations available depending on the equipment used.

Software Compatibility

If a device is SmartLinX ready, it will work with the correct SmartLinX card for that device. However, if the firmware version is a lower number than the one listed below, the P762 Map Element Selection Parameter will not be available. Also, for the BW500 and the SF500, the read block will be a smaller size.

Product	Software Rev.	Product	Software Rev.
AiRanger XPL Plus / SITRANS LU 10	5.23	Milltronics SF500	3.05
AiRanger DPL Plus / SITRANS LU 02		Milltronics BW500	
AiRanger SPL / SITRANS LU 01		MultiRanger 100	1.04
InterRanger DPS 300		MultiRanger 200	1.03
		HydroRanger 200	
		EnviroRanger ERS 500	5.06

Retrofits

If you are replacing an older SmartLinX device with a new SmartLinX device, and you are using any product other than the BW500 or SF500, then you can use the default values for P762.


If you are replacing a BW500 or SF500 with a new device, then set P762 primary index 15 = 0, and P762 primary index 16 = 0.

Hardware Compatibility

All available SmartLinX card configurations are shown here for reference.


The card shown below is compatible with the following Siemens Milltronics units:

- AiRanger XPL Plus / SITRANS LU 10
- AiRanger DPL Plus / SITRANS LU 02
- AiRanger SPL / SITRANS LU 01
- CraneRanger
- InterRanger DPS 300



The card shown below is compatible with the following Siemens Milltronics units :

- EnviroRanger ERS 500 (Wall Mount)
- Milltronics BW500¹
- Milltronics SF500¹
- MultiRanger 100/200
- HydroRanger 200




Note:

- Install the SmartLinx card so that the mounting holes align and the pin connectors will mate correctly.
- Correct cable routing is important for electromagnetic noise suppression. Follow the routing instructions contained your unit's instruction manual.

¹. The termination switch is found only on the older SmartLinx cards, not on the new cards.


The card shown below is compatible with EnviroRanger ERS 500 (Rack or Panel Mount)



Cable Connector


Connect using Belden PROFIBUS cable 3079A or equivalent and terminate according to PROFIBUS DP specification and conventions.

AiRanger / SITRANS LU Series, CraneRanger, InterRanger DPS 300



Note: To daisy-chain devices, connect both the outgoing and the incoming wires to terminals 3 and 4. Then if you have to remove the connector, the bus will still be active.

EnviroRanger ERS 500 (Wallmount), Milltronics BW500, Milltronics SF500, MultiRanger 100/200, HydroRanger 200



Notes:

- To daisy-chain devices with the BW500, connect both wires to the existing A-line and B-line terminals.
- RTS is used in some equipment to determine the direction of transmission. In normal applications only A-line, B-line, and shield, are used.




EnviroRanger ERS 500 (Rack or Panel Mount)

When using a SmartLinx card with the EnviroRanger (rack or panel mount) all wiring is made to the EnviroRanger terminal board. The PROFIBUS connections map to the EnviroRanger terminal board as shown:

EnviroRanger	Connection
65	Gnd_bus
66	RTS ¹
68	A
69	B
71	V_bus +5V
67	bus cable shield

1. RTS is used in some equipment to determine the direction of transmission. In normal applications only A-line, B-line, and shield, are used.

Termination Switch¹

Termination	Setting	Switch Position
open (not used)	off	
<div> <div>+5V</div> <div>Line A</div> <div>Line B</div> <div>GND</div> </div> <div>  </div>	on	

PROFIBUS DP requires termination of the bus at both end points. See the PROFIBUS DP specifications for details.


¹. The termination switch is not present on all cards.

Operation


Communication on the PROFIBUS DP link is indicated by the SmartLinx LEDs.

Error Status LEDs

AiRanger / SITRANS LU Series, CraneRanger, InterRanger DPS 300



EnviroRanger ERS 500, Milltronics BW500, Milltronics SF500,
MultiRanger 100/ 200, HydroRanger 200



Error Conditions of the Red Diagnostics Light

1Hz – Error in Configuration

Indicates that the I/O length variable set during initialization is not equal to the length set during configuration of the network. See *Configuring the Slave Device* on page 13 for lengths supported by the SmartLinX module, and see your PLC documentation for setting the I/O length variable.

2Hz – Error in User Parameter Data


Indicates that the length and / or contents of the user parameter data set during initialization of the module is greater than the length and / or contents set during configuration of the network. See *Configuring the Slave Device* on page 13 for supported lengths.

4Hz – Error in Initialization

Consult your Siemens Milltronics representative.

Operation LED

EnviroRanger ERS 500, Milltronics BW500, Milltronics SF500,
MultiRanger 100/200, HydroRanger (200 only)



LED

- blinks orange as the module is initialized
- blinks green during normal operation

Communication Setup

The SmartLinX PROFIBUS DP module is a slave on the bus, and does not use any Siemens Milltronics instrument parameters for configuration. Set the rotary switches on the module to the desired slave address: other settings are provided in the GSD file or are automatically detected.

GSD Files

PROFIBUS master devices require a configuration file for each slave device on the network. This file configures the master for the capabilities and limitations of the slave. For the SmartLinX PROFIBUS DP module these files are:

- AiRanger / SITRANS LU Series hms_1002.gsd
- BW500, SF500, hms1003.gsd
HydroRanger 200,
MultiRanger 100/200, and ERS 500

Both files are supplied on the floppy disk that is shipped with the module.


The file hms_1002.gsd uses the manufacturer's I.D. number of 1002 hexadecimal (4,098 decimal). The file hms1003.gsd uses the manufacturer's I.D. number 1003 hexadecimal (4,099 decimal).

Baud Rate


The SmartLinX PROFIBUS module automatically configures itself to the correct baud rate for the PROFIBUS DP network. Follow the PROFIBUS guidelines with regards to bus length and baud rate.

Bus Address

Set the two rotary switches to the address for this slave.



Use a slave address switch in the range 03 to 99.
This example shows the value "06."



Configuring the Slave Device

Use the configuration software (or any equivalent master commands) to configure the slave. Refer to the information that came with the PROFIBUS master. The Siemens Milltronics instrument appears as a modular type slave, and should be configured as shown below.

After you import the GSD file, you can find the hardware in the hardware catalogue. If you are using Step 7, go to PROFIBUS DP > Additional Field Devices > General.

- For AiRanger / SITRANS LU products, select **AB-DT-PDP**.
- For all other products, select **Anybus-S_PDP**.

Then define two universal modules: one input module and one output module.

The data size of the input and output modules is dependent on P762, and on the type of unit the module is plugged into, (either Level or Mass Dynamics). (The following instructions assume that P762 is set to the default values shown in the chart on page 14.)

Level Products (includes AiRanger / SITRANS LU Series, ERS 500, MultiRanger 100/200, HydroRanger 200)

- 42 words input (see *Write Block* on page 23)
- 13 words output (see *Read Block* on page 26)
- read and write data as 16-bit words (see *Data Types* on page 40)

Mass Dynamics Products (includes BW500, SF500)

- 34¹ words input (see *Write Block* on page 30)
- 19 words output (see *Read Block* on page 34)
- read and write data as 16-bit words (see *Data Types* on page 40)

If your PROFIBUS master is not capable of handling the block sizes listed above then use multiple smaller blocks. (See next page for examples.)

¹ 34 is the correct value for BW500/SF500 units that have firmware V 3.05 or greater and have all the values of P762 turned on. For older units, the input size is 31 words.

Example:

An S5-115U with an IM 308C master would use the following:

For Level products:

Inputs: 3 address blocks of 16, 16, and 10 words

Outputs: 1 address block of 13 words

For Mass Dynamics products:

Inputs: 3 address blocks of 16 words, 16 words, and 2 words ¹

Outputs: 2 address blocks of 16 and 3 words

Notes:

- Data is read and written with the most significant byte (MSB) first.
- The address and size of the Reads and Writes in the PLC must match the Siemens Milltronics device (see above). If the PLC size is smaller than the Siemens Milltronics size, an error will be displayed and only the first portion of the data will be read.
- PROFIBUS DP diagnostic bytes are not supported, however, some diagnostic information can be accessed via reading and writing the data areas. See *Application Layer* on page 18.

Map Element Selection

P762 Map Element Selection parameter

P762 allows you to select what elements to include in the Input and Output Tables. By selecting only the data required, you can reduce the amount of data being transferred over the bus.

Notes:

- P762 should only be modified by an advanced user who wants to limit the amount of data being transferred. See *Appendix A – Reducing the amount of data being transferred over the Bus* on page 46 for more details.
- Changes do not take effect until after a power cycle.

The chart on page 15 gives the default values for this parameter. If the default values are used then the configuration and Data Map (see page 24) in the main body of this manual remain correct. If any of these values is changed, then the Data Map will be shortened and the configuration will change. Please see Appendix A on page 46 for details on how to use P762.

¹ This applies to BW500/SF500 units that have firmware V 3.05 or greater and have all the values of P762 turned on--it does not apply to older units.

AiRanger / SITRANS LU, EnviroRanger, MultiRanger				BW500, SF500		
P762 Index	Name of area	Default value	Range	Name of area	Default value	Range
1	Instrument status	1	0 = No 1=Yes	Instrument status	1	0 = No 1=Yes
2	Reading	10	0= No 1...10 = include that number of items	Rate	1	0 = No 1=Yes
3	Alarm	10	0= No 1...10 = include that number of items	Load	1	0 = No 1=Yes
4	Point on Priority	1	0 = No 1=Yes	Speed	1	0 = No 1=Yes
5	MPA	1	0 = No 1=Yes	Total	1	0 = No 1=Yes
6	SPA	1	0 = No 1=Yes	Relay Status	1	0 = No 1=Yes
7	Operating Mode	1	0 = No 1=Yes	DI Status	1	0 = No 1=Yes
8				SPA	1	0 = No 1=Yes
9				Command Control	1	0 = No 1=Yes
10				MultiSpan	1	0 = No 1=Yes
11				PID	1	0 = No 1=Yes
12				Batch	1	0 = No 1=Yes
13				Batch Prewarn	1	0 = No 1=Yes
14				Word Order	1	0 = No 1=Yes
15				Status 2	1 ¹	0 = No 1=Yes
16				Batch Total	1 ¹	0 = No 1=Yes

¹. For firmware V 3.05, the default is 0. For all higher versions, the default is 1.

Module Identification

Parameters P794 and P795 are used together to identify the module type and protocol used.

P794 SmartLinx Module Type

Identifies the module used.

Value	Module
0	No module present
1	Anybus DT module
2	Anybus S module

P795 SmartLinx Protocol

Identifies the protocol used: the value varies according to the module, and whether it is a type 1 or type 2.

Siemens Milltronics Instrument	Card	P794 value	P795 value
ERS 500 BW500 / SF500 MultiRanger 100 / 200	AB RIO	1	72
	PROFIBUS DP	2	1
	DeviceNet	2	37
AiRanger / SITRANS LU	AB RIO	1	72
	PROFIBUS DP	1	0
	DeviceNet	1	24
	Modbus RTU	1	57
	Modem Card	1	133

P634: Communication Totalizer Resolution

Parameter P634 is used to set the number of fixed decimal places for Total 1 and Total 2 for SmartLinx communication.

Note: P634 applies only to Milltronics BW500 and Milltronics SF500.

P634 Index	Description	Value		# of decimal places
Primary Index 1	Total 1 for SmartLinx communication	3	*1	3
		2		2
		1		1
		0		0
Primary Index 2	Total 2 for SmartLinx communication	3	*	3
		2		2
		1		1
		0		0

- 1. Factory setting.

Application Layer

This section describes the meaning of data read from and written to the Siemens Milltronics SmartLinX instrument slave memory. The output words (PLC master Write operation) and input words (PLC master Read operation) are described in the Data Map for Level Products on page 23 and the Data Map for Mass Dynamic Products on page 30.

Parameter Indexes

Most parameters used on Siemens Milltronics SmartLinX instruments are indexed. Indexing allows a parameter to relate to more than one input or output. For example, many parameters are indexed by measurement point while others are indexed by relay output or discrete input.

The way that indexes are handled in the memory map depends on the data access method used.


Primary Index

An index that relates to an input or output is called a Primary Index. (On some older Siemens Milltronics products the primary index is called a point.)

Example:

$P111[3] = 52$

means P111 (Relay Control Function) for relay 3 is set to value 52.



Secondary Index


Sometimes a parameter requires a second index to allow for multiple values on an indexed input or output. For example a measurement point which calculates a reading on volume can require characterization breakpoints. These breakpoints are given on a secondary index (the primary index relates to the transducer input).

An index that relates to a previously indexed parameter is called a secondary index. (On some older Siemens Milltronics products the secondary index is called a mark.)

Example:

$P054[1,3] = 1.6m$

means P054 (Breakpoint Levels) for breakpoint 3 on transducer 1 is set to 1.6m



Data Access Methods

There are three different methods used in the memory mapping to give access to the SmartLinX Instrument parameter table. They are:

- Direct Access
- Multiple Parameter Access (MPA)
- Single Parameter Access (SPA)

Direct Access

Certain values are mapped directly into words. These words can be monitored continuously but they are not configurable.

Multiple Parameter Access (MPA)

Note:

- MPA is used on Level products only.
- In Siemens Milltronics' products, the memory is arranged as Parameter number, Primary Index, Secondary Index.

This is a hand-shaking method where the user specifies the parameter number, secondary index, decimal place, and format, then the SmartLinX writes into a certain area all 10 primary indexes of that parameter.

Using Multiple Parameter Access (MPA)

1. In the output table of the PLC (Write Block) write the values for the parameter number, secondary Index, decimal place and format in the correct location.
2. Monitor the Input table of the PLC (Read Block), and watch for the values you wrote to appear in the appropriate locations of the Read block, then go to Step 3.
3. Read the requested values in the appropriate location of the Read Block. These values are continuously updated. Continue reading from these words until values for another parameter are required. At that time, go to step 1.

Note: MPA values are only updated in Run mode (word 12 = 0).

Parameter Indexing with MPA

Primary Index

The primary index is implicit in the memory address. MPA values are returned through words 21 to 30 of the Read block (see page 26).

Secondary Index

The secondary index is nearly always left at zero. See the manual for the Siemens Milltronics SmartLinX instrument for information on parameters, including those which require a secondary index.

Single Parameter Access (SPA)

Note: SPA is used on both Level and Mass Dynamics products.

This is a hand-shaking method where the PLC specifies:

- parameter number
- primary index
- secondary index
- decimal place
- format
- read/write flag
- value

With this method any value in the Siemens Milltronics product can be read or written.

Note: Parameter P999 (Master Reset) is not accessible via the SmartLinX interface on Level products.

Using Single Parameter Access (SPA)

SPA allows continuous monitoring or demand programming of a parameter.

Reading a Parameter

1. Set the Read/Write flag in the output table (Write Block) to 0, "Read"
2. Write the Parameter Number, Primary Index, Secondary Index, Decimal Place and Format in the correct locations.

Note: If there is no secondary index, then place a 0 in this location.

3. Monitor the Input table of the PLC (Read Block) and watch for the values you wrote to appear in the appropriate locations, then go to Step 4.
4. Read the requested parameter value in the Input table (Read Block). These values are continuously updated. Continue reading from these words until values for other parameters are required. At that time, go back to step 1.

Writing a Parameter

1. Set the Read/Write flag in the output table (Write Block) to **0**, "Read"
2. Write the Parameter Number, Primary Index, Secondary Index, Decimal Place and Format in the correct locations.
3. Write the new value of the parameter into the correct location of the output memory (Write Block)
4. Verify the unit is in program mode (not needed for BW500). For Level see bit 10 of status word in Read Block.
5. If the unit is not in program mode, write a **1** to the operating mode word in the output memory (Write Block). Please note that writing a **1** will only work if the word is currently a **0**; if not, you need to change it to **0** before writing a **1** to it can take effect.
6. Set the Read / Write flag in the output table (Write Block) to a **1** "write."
7. Monitor the Input table of the PLC (Read Block) and watch for the values you wrote to appear in the appropriate locations.
8. Set Read / Write flag back to **0**.
9. Place unit in Run mode.

Note: Parameters for Level Products should only be written to while the unit is in PROGRAM mode. If the level instrument is still in RUN mode, the written value might be ignored.

Data Map: Level Products

Note: The data maps shown for the Write and Read Blocks apply if P762 is set to the default values (see page 14). If any of these values is changed, the data map will be shortened and the configuration will change. (See *Appendix A – Reducing the amount of data being transferred over the Bus*, on page 46.)

This section describes the meaning of the data read from and written to the Siemens Milltronics SmartLinX instrument.

Write Block

Word	Description	Access	Data Type
0	measurement point on priority	direct	bitmapped
1	parameter number	MPA	integer
2	secondary index (mark)		integer
3	decimal place		integer
4	format		0/1
5	parameter number	SPA	integer
6	primary index (point)		integer
7	secondary index (mark)		integer
8	new value		integer
9	decimal place		integer
10	format		0/1
11	read/write flag		0/1
12	operating mode	direct	0/1

Word 0: Point-on-Priority

Bits 00-09 set the priority status of corresponding indexed points 1 to 10.

bit	09	08	07	06	05	04	03	02	01	00
index	10	9	8	7	6	5	4	3	2	1

bit status **0** = normal
 1 = priority

For example, if bits 00 and 02 are set to **1**, then points 3 and 1 are on priority scan. All other bits are reserved and contain **0**.

bit	09	08	07	06	05	04	03	02	01	00
index	0	0	0	0	0	0	0	1	0	1

In order to use word 00 to control point-on-priority, you must configure the Siemens Milltronics SmartLinX instrument to permit this. For each point, set parameter P720 to 1, to permit priority control for that point.

Note: Point on Priority only applies to the AiRanger XPL+ / SITRANS LU 10.

Word 1: Parameter Number, MPA

Specifies the parameter number for the returned values in words 21 to 30. (See *Read Block* on page 26.)

Word 2: Secondary Index, MPA

Specifies the secondary index for the parameter specified by word 1. This word is ignored for parameters that don't use multiple indexes. (See *Parameter Indexes* on page 18 for more information.)

Word 3: Decimal Place, MPA

Specifies the number of decimal places to shift the returned values in words 21 to 30 of the Read Block. Positive values indicate that the decimal place shifts to the left, and negative values indicate that the decimal place shifts to the right.

For example:

- word 3 = 1: all returned values have the decimal place shifted 1 space to the left and a returned value of 5,213 is interpreted as 521.3
- word 3 = -1: a returned value of 5,213 is interpreted as 52,130

Word 4: Format, MPA

Sets the format for the returned values in words 21 to 30.

0 = normal

1 = percent

Note: When the format is selected as "percent" the decimal place value (word 3 of the Write block) is ignored and two decimal places are always used. For example, a value of 5947 represents 59.47%.

Word 5: Parameter, SPA

Specifies the parameter number for Single Parameter Access (SPA); see page 21.

Word 6: Primary Index, SPA

Specifies the primary index number for the parameter in word 5.

Word 7: Secondary Index, SPA

Specifies the secondary index for the parameter in word 5. This word is ignored for parameters that don't use multiple indexes. (See *Parameter Indexes* on page 18 for more information.)

Word 8: New Value, SPA

This word contains the value written to the specified parameter and index. The format of this word is specified by words 9 to 10.

To write a value, ensure word 11 = **1** and word 12 = **1**. (See also: *Data Types* on page 40.)

Word 9: Decimal Place, SPA

This word specifies the number of decimal places for the value in word 8 of the Write Block, and word 38 of the Read Block. Positive values indicate that the decimal place shifts to the left, and negative values indicate that the decimal place shifts to the right.

For example:

word 9 = **1**: all returned values have the decimal place shifted 1 space to the left and a returned value of 5,213 is interpreted as 521.3

word 9 = **-1**: a returned value of 5,213 is interpreted as 52,130

Word 10: Format, SPA

This word sets the format for the value in word 8 of the Write Block and word 38 of the Read Block.

0 = normal

1 = percent

Word 11: Read/Write Flag, SPA

This word instructs the read/write application of word 8.

0 = read parameter as described by words 5, 6, 7, 9 and 10; word 8 ignored

1 = set parameter to the value described by words 5 to 10

Word 12: Operating Mode

This word sets the operating mode of the Siemens Milltronics SmartLinx instrument.

The operating mode can get out of sync if the remote instrument resets back to run mode locally. This can happen due to a time-out or through local programming. The mode is always reported correctly through the Read block. (See bit 10 of *Word 0: Instrument Status* on page 27.)

To reset the instrument to program mode, write **0** to synchronize the SmartLinx module with the instrument and then write **1** to set the instrument to program mode.

0 = run mode

1 = program mode

Read Block

Values in words 0 to 20, and word 41, are directly available: no write operation is required to request them.

Values in words 21 to 41 are determined by the write operation that requested them, either MPA or SPA. (See *Write Block* on page 23.)

Words	Description	Access	Data Type
0	instrument status		bitmapped
1-10	point reading	direct	integer
11-20	point alarm and status		bitmapped
21-30	returned values		integer
31	decimal place		integer
32	format	MPA	0/1
33	parameter number		integer
34	secondary index		integer
35	parameter		integer
36	primary index		integer
37	secondary index		integer
38	returned value	SPA	integer
39	decimal place		integer
40	format		0/1
41	read/write flag		0/1

Word 0: Instrument Status

Bit	Description										
00 to 09	Measurement Point Status Indicates the operation of measurement points 1 to 10.										
	bit	09	08	07	06	05	04	03	02	01	00
	index	10	9	8	7	6	5	4	3	2	1
	0 = operational 1 = non-operational 'Non-operational' means that either the point is not configured or there is an error in the reading. Further information is available in the Point Alarm and Status words (Words 11 to 20).										
10	Operating Mode 0 = Siemens Milltronics SmartLinX instrument in RUN mode 1 = Siemens Milltronics SmartLinX instrument in PROGRAM mode										
11 to 15	Reserved. (These bits are reserved and set to 0.)										

Words 1 to 10: Point Reading

These words contain the value of parameter P920 (Reading) for points 1 to 10, respectively. The reading is expressed as a percent of full scale, multiplied by 100, giving a range of -20,000 to 20,000 which corresponds to -200.00% to 200.00%. Refer to the Siemens Milltronics SmartLinX instrument documentation for a definition of "P920."

Note: These values may contain numeric level data for inoperative or malfunctioning points: refer to read word 0, and read words 11 to 20, for the actual operational status of the measurement points.

Words 11 to 20: Point Alarm and Status

These words contain the corresponding alarm and status bits for indexed measurement points 1 to 10, respectively.

Bit status:

0 = false

1 = true

Bit	description
00	point not configured
01	point failsafe timer expired
02	point failed (cable shorted, open, or transceiver problem)
03	point temperature sensor failed
04 to 12	reserved for future use
13	level emptying
14	level filling
15	scan mode priority

If the product is an AiRanger / SITRANS LU Version 5.19 or above, only:

Bit	Description
04	Low-Low Alarm (1 = ON)
05	Low Alarm (1=ON)
06	High Alarm (1 = ON)
07	High-High Alarm (1 = ON)

These words contain values requested by writing to words 1 to 4 of the Write Block. The type of data and format are specified with that request, and returned in Read words 31 to 34.

Words 31 and 32; 33 and 34: Decimal Place, Format, Parameter Number and Secondary Index, MPA

These words contain the last values written to Write block words 1 and 4. These words indicate what information is contained in Read block words 21 to 30. These words are provided since there can be a delay between writing a request via a Write, and the appearance of the requested values.

Use these words as an indicator that the requested information is updated.

Words 35 to 37 and 39 to 41: Parameter Number / Primary Index / Secondary Index and Decimal Place / Format / Read Write Flag, SPA

These words contain the last values written to words 5 to 7 and 9 to 11 of the Write block. They confirm that the parameter value has been written. These words are not updated until the value has been successfully transferred and stored in the Siemens Milltronics SmartLinx instrument.

See Write formats on page 24 for details.

Word 38: Returned Value, SPA

This word contains the current value of the parameter identified by words 35 to 37 and 39 to 40, regardless of the value of word 11 (Write flag).

If this value does not change when a new value is written to word 8 (Parameter Value) then check the following:

1. Words 5 to 7 and 9 to 10 of the Write block **should match** words 35 to 37 and 39 to 40 of the Read block: if not, then the instrument hasn't responded yet.
2. If words 5 to 7 and 9 to 10 of the Write block **do** match words 35 to 37 and 39 to 40, of the Read block, then the parameter value has not been updated. Check that the Siemens Milltronics SmartLinX instrument is in **PROGRAM** mode and that the program lock (P000) is not on, then try again.

Data Map: Mass Dynamic Products

Note: The data maps shown for the Write and Read Blocks apply if P762 is set to the default values (see page 14). If any of these values is changed, the data map will be shortened and the configuration will change. (See *Appendix A – Reducing the amount of data being transferred over the Bus*, on page 46.)

This section describes the meaning of the data read from and written to the Siemens Milltronics SmartLinX instrument.

Write Block

Description	Start	End	Size	Data Type
parameter number, SPA	0	0	1	integer
primary index, SPA	1	1	1	integer
secondary index, SPA	2	2	1	integer
new value, SPA	3	4	2	UINT32
decimal place, SPA	5	5	1	integer
format, SPA	6	6	1	integer
read/write flag, SPA	7	7	1	integer
command control	8	8	1	bitmapped
multispan selection	9	9	1	1-4
PID 1 setpoint value	10	11	2	UINT32
PID 2 setpoint value	12	13	2	UINT32
batch setpoint value	14	15	2	UINT32
batch prewarn setpoint value	16	17	2	UINT32
word order	18	18	1	0/1

Notes:

- All the 32 bit numbers (except for the SPA numbers) have a fixed decimal place of 3 digits. For example PID 1 setpoint value of 3,245 is a value of 3.245 in the BW500.
- To make a change to any parameter in the BW500 using SmartLinX, P799 Communications Control must be set to 1.

Word 0: Parameter, SPA

Specifies the parameter number for Single Parameter Access (SPA): see page 21.

Word 1: Primary Index, SPA

Specifies the primary index number for the parameter specified by word 0.

Word 2: Secondary Index, SPA

Specifies the secondary index for the parameter specified by word 0. This word is ignored for parameters that don't use multiple indexes.

Words 3 and 4: New Value, SPA

The new value of the specified parameter and index.

Word 5: Decimal Place, SPA

This word specifies the number of decimal places for the value in words 3 and 4. Positive values indicate that the decimal place shifts to the left, and negative values indicate that the decimal place shifts to the right.

For example:

- word 5 = **1**: all returned values have the decimal place shifted 1 space to the left
and a returned value of 5,213 is interpreted as 521.3
- word 5 = **-1**: a returned value of 5,213 is interpreted as 52,130

Word 6: Format, SPA

This word is always set to **0**.

Word 7: Read / Write Flag, SPA

This word determines whether the instrument will allow parameter values to be written.

0 = Read

1 = Write

Word 8: Command Control, Operational Commands

The command control word is used to control the unit. Each bit gives access to a command or state as if the operator was using the keypad.

Bits initiating a command (7 to 12) must change state in order to cause the command to begin. For example, to reset totalizer 1, Bit 9 must be set to **0**, then changed to **1**. It can stay set or clear for any period.

Bit #	Description	Bit Clear (0)	Bit Set (1)
00	PID 1 mode	manual	auto
01	PID 1 freeze	no	yes
02	PID 1 setpoint source	local	remote
03	PID 2 mode	manual	auto
04	PID 2 freeze	no	yes
05	PID 2 setpoint source	local	remote
06	zero	no change	start
07	span	no change	start
08	reset totalizer 1	no change	reset
09	reset totalizer 2	no change	reset
10	reset batch totalizer	no change	reset
11	print		print
12	reserved		
13	reserved		
14	reserved		
15	reserved		

Bit 00 and 03: PID Mode

Sets the mode of PID control to either manual (output determined by P410 – PID Manual) or auto (output determined by PID control in instrument).

Bit 02 and 05 Setpoint Source

Controls the location of the setpoint. If it is set as “local,” then the setpoint used is internal to the BW500. If the setpoint source is set to “remote,” then the setpoint is controlled by a mA input.

For setpoint control through communications this must be set to “local.”

Bit 01 and 04: Freeze

Suspends PID function when PID Mode = **1** (auto) and holds the output at the last value. PID functionality resumes when the freeze bit is cleared.

Bit 06: Zero

Sets the zero point for calibration of the belt scale.

This is a momentary setting that must be reset to **0** once the input is accepted. To check that the input was accepted read word 0, bit 7 (zero status) and ensure it shows **1**. Once it shows a **1** then reset this bit to **0**

Bit 07: Span

Sets the span for calibration of the belt scale.

This is a momentary setting that must be reset to **0** once the input is accepted. To check that the input has been accepted, read word 0, bit 8 (Span Status) and ensure it shows a **1**. Once it shows **1** then reset this bit to **0**.

Bit 08: Reset Totalizer 1

Causes the internal totalizer 1 to be reset to **0**.

This is a momentary setting that must be reset to **0** once the input is accepted. To reset this back to **0**, the use of a timer is recommended.

Bit 09: Reset Totalizer 2

Causes the internal totalizer 2 to be reset to **0**.

This is a momentary setting that must be reset to **0** once the input is accepted. To reset this back to **0**, the use of a timer is recommended.

Bit 10: Reset Batch Totalizer

Causes the batch totalizer to be reset to **0**.

This is a momentary setting that must be reset to **0** once the input is accepted. To reset this back to **0**, the use of a timer is recommended.

Bit 11: Print

Starts print operation. One of the communications ports on the BW500 must be configured for a printer.

This is a momentary setting that must be reset to **0** once the input is accepted. To reset this back to **0**, the use of a timer is recommended.

Word 9: Multispan Selection

Sets the current span (1 to 4). Any parameters that relate to span will use this value to determine which span is referenced. See the manual for the BW500 for more information on multispan.

Words 10 to 13: PID Setpoints

Contain the current setpoint values as P415 in the Milltronics BW500.

To write these setpoints bits 02 and 05 in word 8 - Control must be set to "local."

Words 14 and 15: Batch Setpoint

Contain the current setpoint value as P564 in the Milltronics BW500.

Words 16 and 17: Batch Prewarn Setpoint

Contain the current setpoint value as P567 in the Milltronics BW500.

Word 18: Word Order

This word controls which word comes first in the UINT32 integers. For a value **0**, the most significant word is given first. For a value **1**, the least significant word is given first.

0 = MSW first

1 = LSW first

Read Block

Values returned in the words in the Read are in response to the Write to the Siemens Milltronics SmartLinX instrument.

Words 0 through 20 have values with fixed meanings and formats. This means that you do not have to start communications with a Write in order to use Read, the data is always there.

Words 22 through 29 are values returned in response to writing words 0 through 7 for Single Parameter Access (SPA): (see "Write Block" on page 30).

Description	Start	End	Size	Type
instrument status 1	0	0	1	bitmapped
rate	1	2	2	UINT32
load	3	4	2	UINT32
speed	5	6	2	UINT32
total 1	7	8	2	UINT32
total 2	9	10	2	UINT32
relay status	11	11	1	bitmapped
discrete input status	12	12	1	bitmapped
multispan selection	13	13	1	integer
PID 1 setpoint value	14	15	2	UINT32
PID 2 setpoint value	16	17	2	UINT32
batch setpoint value	18	19	2	UINT32

Description	Start	End	Size	Type
batch prewarn setpoint value	20	21	2	UINT32
parameter, SPA	22	22	1	integer
primary index, SPA	23	23	1	integer
secondary index, SPA	24	24	1	integer
new value, SPA	25	26	2	UINT32
decimal place, SPA	27	27	1	integer
format, SPA	28	28	1	integer
read / write flag, SPA	29	29	1	1/0
word order	30	30	1	1/0
Instrument Status 2 ¹	31	31	1	bitmapped
Batch Total ¹	32	33	2	UINT32

1. This is only available in firmware V 3.05 or higher. In V 3.05, these locations are "turned off" in P762. In higher firmware, they are defaulted on.

Word 0: Instrument Status 1

This word is used to feed back the current operating state of the product. Each bit gives the state of different parts of the product, some mutually exclusive, others are not. The state should be checked to verify operation.

Bit #	Description	Bit Clear (0)	Bit Set (1)
0	PID 1 mode	manual	auto
1	PID 1 freeze	no	yes
2	PID 1 setpoint source	local	remote
3	PID 2 mode	manual	auto
4	PID 2 freeze	no	yes
5	PID 2 setpoint source	local	remote
6	zero	no	in progress
7	span	no	in progress
8	reset totalizer 1	no change	reset
9	reset totalizer 2	no change	reset
10	reset batch totalizer	no change	reset
11	printing	not printing	printing
12	write privileges	no	yes
13	system configured	not configured	run mode
14	mode	calibration mode	run mode
15	totalizing	not totalizing	totalizing

Bits 0 to 5: PID Status

These bits give the status of the product. For example Bit 0 is the mode of the PID 1 controller (if used). It indicates whether the PID is in manual or auto modes.

Bit 6: Zero Status

Indicates whether the unit is currently performing a Zero calibration.

Bit 7: Span Status

Indicates whether the unit is currently performing a Span calibration.

Bits 8 to 11: Totalizer Status

Indicate "1" if the reset totalizer or print operations are taking place (these are momentary and will only stay set for a very short period).

Bit 12: Write Privileges

Indicates whether the PLC can write parameters/commands to the product. This is controlled by parameter P799.

- P799 = 1 PLC may change the Siemens Milltronics SmartLinx instrument's parameters
- P799 = 0 PLC can only read

Bit 13: Configuration Status

Indicates whether the unit is configured (all required parameters have been entered).

Bit 14: Program Mode

Indicates program (calibration) mode:

0 = **PROGRAM** mode

1 = **RUN** mode

Bit 15: Totalizing Status

Indicates whether the unit is totalizing.

Words 1, 2: Rate

Contains the current rate reading in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Words 3, 4: Load

Contains the current load reading in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Words 5, 6: Speed

Contains the current speed reading in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Words 7, 8: Total 1¹

Contains the current value for totalizer 1 in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Words 9, 10: Total 2¹

Contains the current value for totalizer 2 in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Word 11: Relay Status

Shows the current logical status of all relays.

bit	04	03	02	01	00
relay	05	04	03	02	01

0 = relay not asserted

1 = relay asserted

"Asserted" indicates that the function controlling the relay is in an active state. Relay contacts can open or close based on this state: see your instrument manual for details.

¹ The number of fixed decimal places for this value is controlled by P634 primary indexes 1 and 2. The default setting is 3. (See page 17 for details.)

Word 12: Discrete Input Status

Shows the current logical status of all discrete inputs.

bit	04	03	02	01	00
input	05	04	03	02	01

0 = discrete input open

1 = discrete input closed

Word 13: Multispan Selection

Shows the currently selected span (1 to 4).

Words 14, 15: PID 1 Setpoint Value

Contains the current setpoint value for PID 1 in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Words 16, 17: PID 2 Setpoint Value

Contains the current setpoint value for PID 2 in engineering units. (See the Milltronics BW500 manual for a full description of this reading.)

Words 18, 19: Batch Setpoint Value

Contains the value of P564 – Batch Setpoint. (See the Milltronics BW500 manual for a full description of this parameter.)

Words 20, 21: Batch Prewarn Setpoint Value

Contains the value of P567: Batch Prewarn Setpoint. (See the Milltronics BW500 manual for a full description of this parameter.)

Words 22 to 24: Parameter Number / Primary Index / Secondary Index, SPA; words 27 to 29: Decimal Place, Format, Read/Write flag

These words contain the last values written to words 0 to 2 and words 5 to 7 of the Write area. They confirm that the parameter value has been written. These words are not updated until the value has been successfully transferred and stored in the Siemens Milltronics SmartLinX instrument.

Use these words as an indicator that the requested information has been updated.

Words 25, 26: Value, SPA

The returned value of the specified parameter and index.

Word 30: Word Order

The placement of the most significant word (MSW).

0 = MSW first

1 = MSW second

Word 31 Instrument Status 2

This word is used to feed back the current operating state of the product. Each bit gives the state of different parts of the product, some mutually exclusive, others are not. The state should be checked to verify operation.

Bit #	Description	Bit Clear (0)	Bit Set (1)
0	Totalizer 1 overflow	no overflow	overflow condition
1	Totalizer 2 overflow	no overflow	overflow condition

Bits 0 Totalizer 1 overflow

If Totalizer 1 has overflowed, (that is, has exceeded the spaces available in SmartLinX), this bit is set. The overflow condition can be changed by reducing Communication Totalizer resolution (P634).

Bit 1 Totalizer 2 overflow

If Totalizer 2 has overflowed, (that is, has exceeded the spaces available in SmartLinX), this bit is set. The overflow condition can be changed by reducing Communication Totalizer resolution (P634).

Word 32 Batch Totalizer

Contains the current value for the Batch Totalizer in engineering units. (See the Milltronics BW500 manual for a full description of this reading).

Data Types

The Siemens Milltronics SmartLinX instrument parameters take on many values in various formats, as discussed in the Siemens Milltronics SmartLinX instrument manual. For the convenience of the programmer, those values are converted to and from 16-bit integer numbers, since those are easily handled by most PLCs.

Integer

Level Products

Integer parameter values are by far the most common. For example, parameter P920 (Reading) returns a number representing the current reading (either level or volume, depending on the Siemens Milltronics SmartLinX instrument configuration).

You can request numeric values in units or percent of span, and you can specify the number of decimal places.

Numeric values must be in the range $-20,000$ to $+20,000$ to be valid. If a parameter is requested and its value is more than $+20,000$, the number 32,767 is returned; if it is less than $-20,000$, the number $-32,768$ is returned. If this happens, increase the number of decimal places for that parameter.

If a parameter cannot be expressed in terms of percent (e.g. span), or has no meaningful value, the special number 22,222 is returned. Try requesting the parameter in units, or refer to the Siemens Milltronics SmartLinX instrument manual to understand the format and use of the requested parameter.

Mass Dynamics Products

Integers used on the Mass Dynamics products can have any valid value. So, the entire range from $-32,768$ to 32,767 or 0 to 65,535 is available and no values are used as error conditions.

Bit Values

Bits are packed into registers in groups of 16 bits (1 word). In this manual bits are numbered from 00 to 15, with bit 00 referring to the least significant bit and bit 15 referring to the most significant bit.

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
MSB															LSB

Unsigned Double Precision Integer (UINT32)

Note: Used for Mass Dynamics products only.

Large numbers are put into unsigned 32-bit integers. By default they are set up so that the first word (register) is the most significant word (MSW) and the second word (register) is the least significant word (LSW) depending on the setting of the word order bit.

For example, when reading words 7 and 8 on the Mass Dynamics block (Total 1), the 32 bits would look as follows:

word 7			word 8		
15	MSW	0	15	LSW	0
31	32-bit integer value (UINT32)				0

The whole is read as a 32-bit integer.

Split Values

Note: Used for Level products only

Certain parameters are actually a pair of numbers separated by a colon, in the format xx:yy.

One example is P807, Transducer Noise, where:

xx = the average noise value in dB.
yy = the peak noise in dB.

The number which corresponds to xx:yy, either for reading or setting a parameter, is determined by the following formula:

For storing to the Siemens Milltronics device:

value = $(xx + 128) \times 256 + (yy + 128)$

For reading from the Siemens Milltronics device:

xx = $(\text{value} / 256) - 128$
yy = $(\text{value} \% 256) - 128$

Where:

% is the modulus operator.

The modulus can be computed by following these steps:

value₁ = value / 256
value₂ = remainder of value₁
value₃ = value₂ x 256
yy = value₃ - 128

It may simplify programming to notice:

xx = (most significant byte of value) – 128
yy = (least significant byte of value) – 128

Text Messages

Note: Used for Level products only

If a Siemens Milltronics device parameter returns a text message, that message is converted to an integer and provided in the register. The numbers are shown in the table below:

Number	Text Message as displayed on LCD
22222	invalid value
30000	off
30001	on
30002	≡ ≡ ≡ ≡
30003	⌂ (parameter does not exist)
30004	err
30005	err1
30006	open
30007	shrt
30008	pass
30009	fail
30010	hold
30011	lo
30012	hi
30013	de
30014	en
30015	- - - (parameter has not been set)
-32768	value is less than -20,000
32767	value is greater than 20,000

Relay Function Codes (P111 in Level Products Only)

If a Siemens Milltronics instrument parameter returns a relay function code, that message is converted to a number and provided in the register. The numbers are shown in the table below.

(See the Siemens Milltronics SmartLinX instrument manual for full information on P111).

Relay Function Code	Number	P111
off, relay not used	0	0
undesignated level alarm	1	1
low-low level alarm	2	1 – LL
low level alarm	3	1 – L
high level alarm	4	1 – H
high-high level alarm	5	1 – HH
in bounds alarm	6	2
in bounds alarm	7	2 – B1
in bounds alarm	8	2 – B2
out of bounds alarm	9	3
out of bounds alarm	10	3 – B1
out of bounds alarm	11	3 – B2
rate of level change alarm	12	4
rate of level change alarm	13	4 – R1
rate of level change alarm	14	4 – R2
temperature alarm	15	5
loss of echo (LOE) alarm	20	6
transducer cable fault alarm	16	7
pump efficiency alarm	17	8
clock failure alarm	18	9
time of day alarm	19	10
pump failure alarm	21	11
totalizer	22	40
flow sampler	23	41
fixed duty assist	25	50
fixed duty backup	26	51
alternate duty assist	30	52
alternate duty backup	31	53
service ratio duty assist	35	54
service ratio duty backup	36	55
first in first out (FIFO)	40	56
time	45	60
overflow	50	61
aeration	55	62
gate	60	63

Relay Function Code	Number	P111
flush valve	65	64
communication	66	65
pump failure alarm	70	11
power failure alarm	71	12
unknown function	200	

Generally

In all cases, first check P794 and P795, to verify that you have the correct card for your device. Next check that the SmartLinX module has passed its on-going built-in self test (Siemens Milltronics SmartLinX instrument parameter P790). The result should be “pass.”

If “fail” is indicated, either the module is defective, or the module connector on the Siemens Milltronics SmartLinX instrument is defective.

If “err1” is indicated, the Siemens Milltronics software doesn’t recognize the ID number of the installed module. Please contact Siemens Milltronics or your distributor for instructions and/or upgraded Siemens Milltronics SmartLinX instrument software.

Make sure the Siemens Milltronics device is set to a unique address, and does not conflict with any other slave(s) on the bus.

Check the configuration of the scanning master, and make sure it is functioning properly.

1. **If you have configured the Siemens Milltronics device in the Master and downloaded it to the processor, but the device is not coming on line:**
 - Check which GSD file you use, and make sure you used the correct one (see *GSD Files* on page 12).
 - Check the wiring to the card. In particular, check that you have line A and B connected correctly.
 - Verify that you set the correct address on the card. Also, please note that the card does not see a charge until the power has been cycled.
 - Verify that the Read and Write Block sizes are correct. This is particularly important if you are using P762.
2. **If the network was working fine until you connected to the Siemens Milltronics device, at which time other devices dropped out:**
 - Check the termination switch on the PROFIBUS card. The network cable has to be terminated at both ends of the LAN, but not in between.
 - Check your grounding. The PROFIBUS specifications require that all devices be on the same ground. Improper grounding can cause strange effects.

Technical Support or Product Feedback

For product feedback or technical support, please contact your local Siemens Milltronics representative or e-mail us at www.siemens.com/automation/support-request.

Appendix A – Reducing the amount of data being transferred over the Bus

You can limit the amount of data being transferred over the Bus, and save both bandwidth and memory, by using P762. However, when you reduce the size of the data map, the configuration will change. If the data block sizes in the device do not match what is configured in the master, no communications will occur. Therefore it is critical to calculate the size of the new map. The calculation is different for level applications and for mass dynamics applications.

The following sections provide explanations and examples of the calculation required, together with a worksheet to use as a template. The first section explains how it works with level products, and the second explains how it works with mass dynamics products. In each section, the Write Block map is calculated first, followed by the Read Block.

Level Products

The Smartlinx map¹ is controlled by the values of the indices of P762. By turning on an index (setting the value to one or more), you activate both the read and write blocks associated with that index. The table below shows which values in the read/write blocks are turned on by each P762 index.

Name of area	P762 Point	Value	Read area turned On	Write area turned on
Status	1	1	Instrument status	-----
Reading	2	1-10	1-10 point readings	-----
Alarm	3	1-10	1-10 point alarm and status	-----
Point on Priority	4	1	-----	Measurement point on Priority
MPA	5	1	Returned Values (1-10)	Parameter number
			Decimal place	Secondary index
			Format	Decimal place
			Parameter number	Format
			Secondary index	-----
SPA	6	1	Parameter Number	Parameter Number
			Primary index	Primary index
			Secondary index	Secondary index
			Returned Value	New Value
			Decimal Place	Decimal Place
			Format	Format
			Read/Write	Read/ Write
Operating Mode	7	1	-----	Operating Mode

¹ For examples of the data maps before modification, see pages 48 and 50.

Write Block

The standard Write block is made up of the following sections: point on priority, MPA, SPA, and operating mode. If any of these sections is 'turned off' by setting the corresponding part of P762 to a zero, the new map will shift down accordingly and the size will be reduced by that amount. Multiply the parameter value by the memory size, then add up the results to get the total.

Write Block Template for Level Products

Name of area	P762 Point	value	Memory size for Write block per value	Result of multiplying value * memory size
Status	1		0	
Reading	2		0	
Alarm	3		0	
Point on Priority	4		1	
MPA	5		4	
SPA	6		7	
Operating mode	7		1	
			Total words:	

Example 1:

If you want only Point status, and to read the first 7 point readings, the chart is:

Name of area	P762 Point	value	Memory size for Write block per value	value * memory size
Status	1	1	0	0
Reading	2	7	0	0
Alarm	3	0	0	0
Point on Priority	4	0	1	0
MPA	5	0	4	0
SPA	6	0	7	0
Operating mode	7	0	1	0
			Total words:	0

The output data block (Write block) is now 0 words in size (0 bytes).

No map**Example 2:**

If you want only SPA, then the chart is:

Name of area	P762 Point	value	Memory size for Write block per value	value * memory size
Status	1	0	0	0
Reading	2	0	0	0
Alarm	3	0	0	0
Point on Priority	4	0	1	0
MPA	5	0	4	0
SPA	6	1	7	7
Operating mode	7	0	1	0
			Total words:	7

The output data block (Write block) is now 7 words in size (14 bytes) and the Word numbers have shifted to a lower value

New Write Block Data Map

Word	Description
0	Parameter number
1	Parameter primary index
2	Parameter secondary index
3	Parameter value
4	Decimal place
5	Format
6	Read / Write flag

Original Write Block Data Map for Level Products

Words	Description	Access	Data Type
0	measurement point on priority	direct	bitmapped
1	parameter number	MPA	integer
2	parameter secondary index ¹		integer
3	decimal place		integer
4	format		0/1

Words	Description	Access	Data Type
5	parameter number		integer
6	parameter primary index		integer
7	parameter secondary index		integer
8	parameter value	SPA	integer
9	decimal place		integer
10	format		0/1
11	read/write flag		0/1
12	operating mode	direct	0/1

1. The primary index is implicit in the address of the returned parameter values.

Read Block

The standard Read block is made up of the following sections: status, reading, alarm, MPA, and SPA. If any of these sections is 'turned off' by setting the corresponding part of P762 to a zero, the new map will shift down accordingly and the size will be reduced by that amount for the Read block. Multiply the parameter value by the memory size, then add up the results to get the total.

Read Block Template for Level Products

Name of area	P762 Point	value	Memory size for Read block per value	Result of multiplying value * memory size
Status	1		1	
Reading	2		1	
Alarm	3		1	
Point on Priority	4		0	
MPA	5		14	
SPA	6		7	
Operating mode	7		0	
			Total Words:	

Example 1:

If you want only Instrument status, and to read the first 7 point readings, then the chart is:

Name of area	P762 Point	value	Memory size for Read block per value	value * memory size
Status	1	1	1	1
Reading	2	7	1	7
Alarm	3	0	1	0
Point on Priority	4	0	0	0
MPA	5	0	14	0
SPA	6	0	7	0
Operating mode	7	0	0	0
			Total words:	8

The input data block (Read block) is now 8 words in size (16 bytes), and the Word numbers have shifted to a lower value.

New Read Block Data map:

Word	Description
0	Instrument status
1	Reading for point 1
2	Reading for point 2
3	Reading for point 3
4	Reading for point 4
5	Reading for point 5
6	Reading for point 6
7	Reading for point 7

Example 2:

If you want only SPA, then the chart is:

Name of area	P762 Point	value	Memory size for Read block per value	value * memory size
Status	1	0	1	0
Reading	2	0	1	0
Alarm	3	0	1	0
Point on Priority	4	0	0	0
MPA	5	0	14	0
SPA	6	1	7	7
Operating mode	7	0	0	0
			Total words:	7

The input data block (Read block) is now 7 words in size (14 bytes), and the Word numbers have shifted to a lower value.

New Read Block Data map:

Word	Description
0	Parameter number
1	Parameter primary index
2	Parameter secondary index
3	Parameter returned value
4	Decimal place
5	Format
6	Read/Write flag

Original Read Block Data map for Level Products

Words	Description	Access	Data Type
0	instrument status		bitmapped
1-10	point reading	direct	integer
11-20	point alarm and status		bitmapped
21-30	returned values		integer
31	decimal place		integer
32	format	MPA	0/1
33	parameter number		integer
34	parameter secondary index		integer

Words	Description	Access	Data Type
35	parameter	SPA	integer
36	parameter primary index		integer
37	parameter secondary index		integer
38	value		integer
39	decimal place		integer
40	format		0/1
41	read/write flag		0/1

Mass Dynamics Products

The Smartlinx map¹ is controlled by the values of the indices of P762. By turning on an index (setting the value to one or more), you activate both the read and write blocks associated with that index. The table below shows which values in the read/write blocks are turned on by each P762 index.

Name of area	P762 Point	Value	Read area turned On	Write area turned on
Status	1	1	Instrument status	-----
Rate	2	1	Rate	-----
Load	3	1	Load	-----
Speed	4	1	Speed	-----
Total	5	1	Total 1	-----
			Total 2	
Relay Status	6	1	Relay Status	-----
DI Status	7	1	Discrete Input Status	-----
SPA	8	1	Parameter Number	Parameter Number
			Primary index	Primary index
			Secondary index	Secondary index
			Returned Value	New Value
			Decimal Place	Decimal Place
			Format	Format
			Read/Write	Read/ Write
Command Control	9	1	-----	Command Control
Multispan	10	1	-----	Multispan Selection
PID	11	1	-----	PID 1 setpoint value
				PID 2 setpoint value
Batch	12	1	-----	Batch Setpoint Value

¹ For examples of the data maps before modification, see pages 53 and 55

Batch Prewarn	13	1	-----	Batch Prewarn Setpoint Value
Word Order	14	1	Word order	Word order
Status 2	15	1	Instrument Status 2	-----
Batch Total	16	1	Batch Total	-----

Write Block

The standard Write block is made up of the following sections: SPA, command control, multispan, PID, batch, batch prewarn, word order. If any of these sections is 'turned off' by setting the corresponding part of P762 to a zero, the new map will shift down accordingly and the size will be reduced by that amount. Multiply the parameter value by the memory size, then add up the results to get the total

Write Block Template for Mass Dynamic Products

Name of area	P762 Point	value	Memory size for Write block per value	Result of multiplying value * memory size
Status	1		0	
Rate	2		0	
Load	3		0	
Speed	4		0	
Total	5		0	
Relay Status	6		0	
DI Status	7		0	
SPA	8		8	
Command Control	9		1	
Multispan	10		1	
PID	11		4	
Batch	12		2	
Batch Prewarn	13		2	
Word Order	14		1	
Status 2	15		0	
Batch Total	16		0	
			Total words:	

Example 1:

If you want only rate, load, and batch prewarn, then the chart is:

Name of area	P762 Point	value	Memory size for Write block per value	value * memory size
Status	1	0	0	0
Rate	2	1	0	0
Load	3	1	0	0
Speed	4	0	0	0
Total	5	0	0	0
Relay Status	6	0	0	0
DI Status	7	0	0	0
SPA	8	0	8	0
Command Control	9	0	1	0
Multispan	10	0	1	0
PID	11	0	4	0
Batch	12	0	2	0
Batch Prewarn	13	1	2	2
Word Order	14	0	1	0
Status 2	15	0	0	0
Batch Total	16	0	0	0
			Total words:	2

The input data block (Write block) is now 2 words in size (4 bytes) and the Word numbers have shifted to a lower value:

New Write Block Data Map:

Word	Description
0-1	Batch prewarn

Original Write Block Data Map for Mass Dynamic Products

Description	Start	End	Size	Data Type
parameter number, SPA	0	0	1	integer
primary index, SPA	1	1	1	integer
secondary index, SPA	2	2	1	integer
value, SPA	3	4	2	UINT32
decimal place, SPA	5	5	1	integer
format, SPA	6	6	1	integer
read / write flag, SPA	7	7	1	integer
command control	8	8	1	bitmapped
multispan selection	9	9	1	1-4
PID 1 setpoint value	10	11	2	UINT32
PID 2 setpoint value	12	13	2	UINT32
batch setpoint value	14	15	2	UINT32
batch prewarn setpoint value	16	17	2	UINT32
word order	18	18	1	0/1

Read Block

The standard Read block is made up of the following sections: status, rate, load, speed, total, relay status, DI status, multispan, PID, batch, batch prewarn, SPA, Word order. If any of these sections is 'turned off' by setting the corresponding part of P762 to a zero, the new map will shift down accordingly and the size will be reduced by that amount, for the Read block. Multiply the parameter value by the memory size, then add up the results to get the total.

Read Block Template for Mass Dynamic Products

Name of area	P762 Point	value	Memory size for Read block per value	Result of multiplying value * memory size
Status	1		1	
Rate	2		2	
Load	3		2	
Speed	4		2	
Total	5		4	
Relay Status	6		1	
DI Status	7		1	
SPA	8		8	
Command Control	9		0	
Multispan	10		1	
PID	11		4	
Batch	12		2	
Batch Prewarn	13		2	
Word Order	14		1	
Status 2	15		1	
Batch Total	16		2	
			Total words:	

Example 1

If you want only rate, load, and batch prewarn, the chart is:

Name of area	P762 Point	value	Memory size for Read block per value	value * memory size
Status	1	0	1	0
Rate	2	1	2	2
Load	3	1	2	2
Speed	4	0	2	0
Total	5	0	4	0
Relay Status	6	0	1	0
DI Status	7	0	1	0
SPA	8	0	8	0
Command Control	9	0	0	0
Multispan	10	0	1	0
PID	11	0	4	0
Batch	12	0	2	0

Name of area	P762 Point	value	Memory size for Read block per value	value * memory size
Batch Prewarn	13	1	2	2
Word Order	14	0	1	0
Status 2	15	0	1	0
Batch Total	16	0	2	0
			Total words:	6

The input data block (Read block) is now 6 words in size (12 bytes) and the Word numbers have shifted to a lower value:

New Read Block Data Map

Word	Description
0-1	Rate
2-3	Load
4-5	Batch prewarn

Original Read Block Data Map for Mass Dynamic Products

Description	Start	End	Size	Type
instrument status	0	0	1	bitmapped
rate	1	2	2	UINT32
load	3	4	2	UINT32
speed	5	6	2	UINT32
total 1	7	8	2	UINT32
total 2	9	10	2	UINT32
relay status	11	11	1	bitmapped
discrete input status	12	12	1	bitmapped
multispan selection	13	13	1	integer
PID 1 setpoint value	14	15	2	UINT32
PID 2 setpoint value	16	17	2	UINT32
batch setpoint value	18	19	2	UINT32
batch prewarn setpoint value	20	21	2	UINT32
parameter, SPA	22	22	1	integer
primary index, SPA	23	23	1	integer
secondary index, SPA	24	24	1	integer
value, SPA	25	26	2	UINT32
decimal place, SPA	27	27	1	integer
format, SPA	28	28	1	integer
read / write flag, SPA	29	29	1	1/0
word order	30	30	1	1/0
instrument status 2 ¹	31	31	1	bitmapped
batch total ¹	32	33	2	UINT32

1. This is only available in firmware V 3.05 or higher

A

AiRanger Series

- connection 7
- operation 10

Alarm and Status 27

Application Layer 18

B

Batch Prewarn Setpoint 34

Batch Prewarn Setpoint Value 38

Batch Setpoint 34

Batch Setpoint Value 38

Baud Rate 12

Bit Values 40

Bus Address 12

C

Cable

- connector 7
- routing 6

Command Control, Operational Commands 32

Communication Setup 12

Communication Speed 12

Compatibility 4

Compatible Instruments 3

Configuration

- files 12
- slave device 13

Configuration Status 37

CraneRanger

- connection 7
- operation 10

D

Data Access Methods 19

Data Map

- level products 23
- mass dynamics products 30

Data Types 40

- Bit Values 40
- integer 40
- mass dynamic products 40
- Numeric 40
- P111 Values 43
- Split Values 41
- text messages 42
- UINT32 41

Decimal Place 24, 25, 28, 31

Direct Access 19

Discrete Input Status 38

E

EnviroRanger ERS 500

Operation 10, 11

EnviroRanger ERS 500 (rack and panel)

connection 8

EnviroRanger ERS 500 (wall mount)

connection 8

Error Conditions 11

Error Status LEDs 10

F

Flag 28

Format 24, 25, 28, 31

Freeze 32

G

GSD Files 12

I

Index 28

alarm and status 27

direct access 19

MPA 20

point reading 27

primary 18

secondary 19

Indexed Parameters 18

Installation 4

Instrument

compatibility 4

Instrument Status 36

Integer 40

InterRanger DPS 300

- connection 7
- operation 10

L

LEDs

Error state 10

LEDs 10

level products

data map 23

Load 37

M

manual 2

overview 2

Mark 19

Mass Dynamics

data map 30

Master Reset 21

- Measurement Point Status 27
- Milltronics BW500
 - connection 8
- Milltronics BW500
 - Operation 10, 11
- MPA
 - overview 20
 - parameter indexing 20
 - using 20
- Multiple Parameter Access 19, 20
- Multispan Selection 34, 38
- N**
- Network Address 12
- Numeric Values 40
- O**
- Operating Mode 26
- Operation 10
- Operation LED 11
- P**
- P999 21
- Parameter 24, 30
- Parameter Indexes 18
- parameter indexing 21
- Parameter Number 24, 28, 38
- Parameter Number and Secondary Index 28
- Parameter Secondary Index 24
- PID 1 Setpoint Value 38
- PID 2 Setpoint Value 38
- PID Mode 32
- PID Setpoints 34
- PID Status 36, 39
- Point 18, 28
- Point Alarm and Status 27
- Point Reading 27
- Point-on-Priority 23
- Primary Index 18, 25, 30, 38
- Print 33
- Print Status 36
- Program Mode 37
- R**
- Rate 37
- Read
 - level products 26
 - mass dynamics products 34
- Read/Write Flag 25
- Reading 27
 - MPA 20
 - SPA 21
- Relay Function Codes 43
- Relay Status 37
- Returned Values 28
- S**
- Secondary Index 19, 25, 30, 38
- Setpoint Source 32
- Setup
 - communication 12
- Single Parameter Access 21
- SmartLinx® PROFIBUS DP 1
- SPA
 - overview 21
 - reading 21
 - using 21
 - writing 22
- Span 33
- Span Status 36
- Specifications 3
- Speed 37
- Split Values 41
- Status 10
- T**
- target audience 2
- Terminal Block
 - connector 7
- Termination Switch 9
- Text Messages 42
- Total 1 37
- Total 2 37
- Totalizer Reset 33
- Totalizer Status 36
- Totalizing Status 37
- Troubleshooting 45
- U**
- UINT32 41
- Unsigned Double Precision Integer 41
- Using
 - MPA 20
 - SPA 21
- V**
- Value 25, 29, 31, 38
- W**
- Wiring
 - connector 7
- Word Order 34, 39
- Write
 - level products 23
 - mass dynamics products 30
- Write Privileges 36
- Writing 22
- Z**
- Zero 33
- Zero Status 36



www.siemens.com/processautomation

*Siemens Milltronics Process Instruments Inc.
1954 Technology Drive, P.O. Box 4225
Peterborough, ON, Canada K9J 7B1
Tel: (705) 745-2431 Fax: (705) 741-0466
Email: techpubs.smpi@siemens.com*

© Siemens Milltronics Process Instruments Inc. 2006
Subject to change without prior notice



7 M L 1 9 9 8 1 A Q 0 3
Printed in Canada

Rev. 3.2