

# SINAMICS

**SINAMICS S120** 

**High Frequency Drive** 

System Manual



# **SIEMENS**

## **SINAMICS**

S120 High Frequency Drive

**System Manual** 

Valid from: Firmware version 4.7

Foreword	
Fundamental safety instructions	1
System overview	2
High Frequency Modules, line connection	3
High Frequency Modules	4
Voltage Protection Module (VPM)	5
Braking Modules	6
Braking resistors	7
Control Supply Module (CSM)	8
DC link adapter	9
Configuring	10
Cabinet design and EMC	11
Service and maintenance	12
Appendix	Α

### Legal information

#### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

**DANGER** 

indicates that death or severe personal injury will result if proper precautions are not taken.

**∕** WARNING

indicates that death or severe personal injury may result if proper precautions are not taken.

**CAUTION** 

indicates that minor personal injury can result if proper precautions are not taken.

#### NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

#### **Qualified Personnel**

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

#### /!\WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

#### **Trademarks**

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

#### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

### **Foreword**

### SINAMICS documentation

The SINAMICS documentation is organized in the following categories:

- General documentation/catalogs
- User documentation
- Manufacturer/service documentation

### Additional information

You can find information on the following topics at the following address (<a href="http://w3.siemens.com/mcms/mc-solutions/en/motion-control/support/technical-documentation/Pages/technical-documentation.aspx">http://w3.siemens.com/mcms/mc-solutions/en/motion-control/support/technical-documentation/Pages/technical-documentation.aspx</a>):

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

Please send any questions about the technical documentation (e.g. suggestions for improvement, corrections) to the following e-mail address (mailto:docu.motioncontrol@siemens.com).

### My Documentation Manager

At the following address (<a href="http://www.siemens.com/mdm">http://www.siemens.com/mdm</a>), you can find information on how to create your own individual documentation based on Siemens' content, and adapt it for your own machine documentation.

### **Training**

At the following address (<a href="http://www.siemens.com/sitrain">http://www.siemens.com/sitrain</a>), you can find information about SITRAIN (Siemens training on products, systems and solutions for automation and drives).

#### **FAQs**

You can find Frequently Asked Questions in the Service&Support pages under Product Support (https://support.industry.siemens.com/cs/de/en/ps/faq).

### **SINAMICS**

You can find information about SINAMICS at the following address (<a href="http://www.siemens.com/sinamics">http://www.siemens.com/sinamics</a>).

### Usage phases and their documents/tools (as an example)

Table 1 Usage phases and the available documents/tools

Usage phase	Document/tool	
Orientation	SINAMICS S Sales Documentation	
Planning/configuration	SIZER Engineering Tool	
	Configuration Manuals, Motors	
Deciding/ordering	SINAMICS S120 catalogs	
	SIMOTION, SINAMICS S120 and Motors for Production Machines (Catalog PM 21)	
	SINAMICS and Motors for Single-axis Drives (Catalog D 31)	
	SINUMERIK & SINAMICS     Equipment for Machine Tools (Catalog NC 61)	
	SINUMERIK 840D sl Type 1B	
	Equipment for Machine Tools (Catalog NC 62)	
Installation/assembly	SINAMICS S120 Manual for Control Units and Additional System Components	
	SINAMICS S120 Manual for Booksize Power Units	
	SINAMICS S120 Manual for Chassis Power Units	
	SINAMICS S120 Manual for AC Drives	
	SINAMICS S120M Manual Distributed Drive Technology	
	SINAMICS S120 Manual Power Units Booksize C/D Type	
	SINAMICS HLA System Manual Hydraulic Drive	
Commissioning	STARTER Commissioning Tool	
	SINAMICS S120 Getting Started	
	SINAMICS S120 Commissioning Manual	
	SINAMICS S120 CANopen Commissioning Manual	
	SINAMICS S120 Function Manual	
	SINAMICS S120 Safety Integrated Function Manual	
	SINAMICS S120/S150 List Manual	
	SINAMICS HLA System Manual Hydraulic Drive	
Usage/operation	SINAMICS S120 Commissioning Manual	
	SINAMICS S120/S150 List Manual	
	SINAMICS HLA System Manual Hydraulic Drive	
Maintenance/servicing	SINAMICS S120 Commissioning Manual	
	SINAMICS S120/S150 List Manual	
References	SINAMICS S120/S150 List Manual	

### Target group

This documentation is intended for machine manufacturers, commissioning engineers, and service personnel who use the SINAMICS drive system.

#### **Benefits**

This manual provides all of the information, procedures and operator actions required for the particular usage phase.

### Standard scope

The scope of the functionality described in this document can differ from that of the drive system that is actually supplied.

- Other functions not described in this documentation might be able to be executed in the
  drive system. However, no claim can be made regarding the availability of these functions
  when the equipment is first supplied or in the event of service.
- The documentation can also contain descriptions of functions that are not available in a
  particular product version of the drive system. The functionality of the supplied drive
  system should only be taken from the ordering documentation.
- Extensions or changes made by the machine manufacturer must be documented by the machine manufacturer.

For reasons of clarity, this documentation does not contain all of the detailed information on all of the product types, and cannot take into consideration every conceivable type of installation, operation and service/maintenance.

### **Technical Support**

Country-specific telephone numbers for technical support are provided in the Internet at the following address (<a href="https://support.industry.siemens.com/sc/ww/en/sc/2090">https://support.industry.siemens.com/sc/ww/en/sc/2090</a>) in the "Contact" area.

### EC Declaration of Conformity, certificates, certifications, manufacturers declarations

You can find the EC Declaration of Conformity for the relevant directives as well as the relevant certificates, prototype test certificates, manufacturers declarations and test certificates for functions relating to functional safety ("Safety Integrated") in the Internet at the following address (https://support.industry.siemens.com/cs/ww/en/ps/13231/cert).

You can obtain an up-to-date list of currently certified components on request from your local Siemens office. If you have any questions relating to certifications that have not yet been completed, please ask your Siemens contact person.

#### Note

You can find certificates for the North American market on the Internet page of the certifier:

- For products with UL certificate (<a href="http://database.ul.com/cgi-bin/XYV/template/LISEXT/1FRAME/index.html">http://database.ul.com/cgi-bin/XYV/template/LISEXT/1FRAME/index.html</a>)
- For products with TÜV SÜD certificate (<a href="https://www.tuev-sued.de/industry\_and\_consumer\_products/certificates">https://www.tuev-sued.de/industry\_and\_consumer\_products/certificates</a>)
- For products with CSA certificate (<a href="http://www.csagroup.org/de/en/services/testing-and-certification/certified-product-listing">http://www.csagroup.org/de/en/services/testing-and-certification/certified-product-listing</a>)

### **Low-Voltage Directive**

When operated in dry areas, SINAMICS S units conform to the Low-Voltage Directive 2006/95/EC.

### **EMC** directive

SINAMICS S devices fulfill EMC Directive 89/336/EEC or 2014/130/EEC in the configuration specified in the associated EC Declaration of Conformity for EMC and when the Configuration Manual EMC Installation Guideline, article number 6FC5297-0AD30-0□P□, is implemented.

#### **EMC limit values in South Korea**

이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

For sellers or other users, please bear in mind that this device is an A-grade electromagnetic wave device. This device is intended to be used in areas other than at home.

The EMC limit values to be observed for Korea correspond to the limit values of the EMC product standard for variable-speed electric drives EN 61800-3 of category C2 or the limit value class A, Group 1 to CISPR11. By implementing appropriate additional measures, the limit values according to category C2 or limit value class A, Group 1, are observed. Further, additional measures may be required, such as using an additional radio interference suppression filter (EMC filter).

The measures for EMC-compliant design of the system are described in detail in this manual respectively in the EMC Installation Guideline Configuration Manual.

The final statement regarding compliance with the standard is given by the respective label attached to the individual unit.

### Ensuring reliable operation

The manual describes a desired state which, if maintained, ensures the required level of operational reliability and compliance with EMC limit values.

Should there be any deviation from the requirements in the manual, appropriate actions (e.g. measurements) must be taken to check/prove that the required level of operational reliability and compliance with EMC limit values are ensured.

### Spare parts

Spare parts are available on the Internet at the following address (https://support.industry.siemens.com/sc/ww/en/sc/2110).

### **Ground symbols**

Table 2 Symbols

Symbol	Meaning
	Connection for protective conductor (PE)
	Ground (e.g. M 24 V)
<del></del>	Connection for function potential bonding

## Table of contents

	Foreword		5
1	Fundame	ntal safety instructions	17
	1.1	General safety instructions	17
	1.2	Safety instructions for electromagnetic fields (EMF)	21
	1.3	Handling electrostatic sensitive devices (ESD)	21
	1.4	Industrial security	22
	1.5	Residual risks of power drive systems	
2		verview	
_	•		
	2.1	SINAMICS S120 High Frequency Drive components	
	2.2	Overview	26
	2.3	System data	27
3	High Freq	uency Modules, line connection	29
4	High Freq	juency Modules	31
	4.1	Introduction	31
	4.2	Safety instructions for High Frequency Modules	34
	4.3	HF Motor Module	
	4.3.1	Description	
	4.3.2	Interfaces	
	4.3.2.1	Overview	37
	4.3.2.2	X21 EP terminals/temperature sensor motor module	
	4.3.2.3	X200-X202 DRIVE-CLiQ interfaces	
	4.3.2.4	Protective conductor connection	
	4.3.2.5	Busbars	
	4.3.3	Meaning of the LEDs	
	4.3.4	Dimension drawing	
	4.4	HF Sine Filter Module	
	4.4.1	Description	43
	4.4.2	HF Choke Module interfaces	44
	4.4.2.1	Overview	44
	4.4.2.2	X21 outputs for temperature monitoring	45
	4.4.2.3	X22 fan control for commissioning	45
	4.4.2.4	Voltage Protection Module Connection	46
	4.4.2.5	Motor connection	47
	4.4.2.6	Protective conductor connections for the equipotential bonding bar	47
	4.4.2.7	Busbars	48
	4.4.3	HF Damping Module interfaces	
	4.4.3.1	Overview	
	4.4.3.2	X21 inputs for temperature monitoring	

	4.4.3.3	X200-X203 DRIVE-CLiQ interfaces	
	4.4.3.4	Busbars	
	4.4.4	Meaning of the LEDs	
	4.4.5	Dimension drawings	
	4.4.5.1	HF Choke Module	
	4.4.5.2	HF Damping Module	54
	4.5	Installation	55
	4.6	Electrical connection	
	4.6.1	Connecting the DC-link busbars and 24 V busbars	
	4.6.2	Connecting the busbars	
	4.6.3	Protective conductor connection of the HF module	64
	4.7	Connection examples	
	4.7.1	High Frequency Drive with components in the booksize format	
	4.7.2	High Frequency Drive with components in the chassis format	68
	4.8	Technical data	69
	4.8.1	Characteristics	70
5	Voltage P	rotection Module (VPM)	73
	5.1	Description	73
	5.2	Safety instructions for Voltage Protection Modules	74
	5.3	Interfaces	76
	5.3.1	Overview	
	5.3.2	X3 signaling contact	
	5.3.3	Connection busbars U, V, W, PE	
	5.4	Connection example	80
	5.5	Dimension drawing	81
	5.6	Installation	82
	5.7	Electrical connection	83
	5.7.1	Connecting signaling contact X3	
	5.8	Technical data	85
6	Braking M	1odules	
•	6.1	Braking Module Booksize	
	6.1.1	Description	
	6.1.2	Safety instructions for Braking Modules Booksize	
	6.1.3	Interface description	
	6.1.3.1	Overview	
	6.1.3.2	X1 braking resistor connection	
	6.1.3.3	X21 digital inputs/outputs	
	6.1.4	Connection example	
	6.1.5	Meaning of the LEDs	
	6.1.6	Dimension drawing	
	6.1.7	Installation	
	6.1.8	Technical data	
	6.1.8.1	Technical data	
	6.1.8.2	Characteristic curves	
	619	Configuration instructions	98

	6.2	Braking Module Booksize Compact	
	6.2.1	Description	
	6.2.2	Safety instructions for Braking Modules Booksize Compact	
	6.2.3	Interface description	
	6.2.3.1	Overview	
	6.2.3.2	X1 braking resistor connection	
	6.2.3.3	X21 digital inputs/outputs	
	6.2.3.4	X22 digital output/temperature switch	
	6.2.3.5	DIP switch	
	6.2.4	Connection examples	
	6.2.5 6.2.6	Meaning of LEDs on the Braking Module Booksize Compact  Dimension drawing	
	6.2.7	Mounting	
	6.2.8	Technical data	
	6.2.8.1	Technical data  Technical specifications	
	6.2.8.2	Characteristic curves	
	6.2.9	Configuration instructions	
_		•	
7	_	esistors	
	7.1	Description	
	7.2	Safety instructions for braking resistors	118
	7.3	Dimension drawings	119
	7.4	Technical data	124
	7.4.1	Characteristic curves	125
8	Control S	upply Module (CSM)	127
	8.1	Description	127
	8.2	Safety instructions for Control Supply Modules	128
	8.3	Interface description	130
	8.3.1	Overview	130
	8.3.2	X1 line connection	13 <sup>2</sup>
	8.3.3	X21 signaling contact	13 <sup>2</sup>
	8.3.4	X24 24 V terminal adapter	
	8.3.5	S1 DIP switch	133
	8.4	Connection examples	134
	8.4.1	General information	
	8.4.2	Single operation	_
	8.5	Meaning of the LEDs	
	8.6	Dimension drawing	
		<u> </u>	
	8.7	Installation	
	8.8	Technical data	
	8.8.1	Technical data	
	8.8.2	Characteristics	
9	DC link a	dapterdapter	14′
	9.1	Description	14′
	9.2	Safety instructions for the DC link adapter	14

	9.3 9.3.1	Interface description Overview	
	9.3.2	DC link connection	
	9.4	Dimension drawing	144
	9.5	Installation	145
	9.6	Electrical connection	146
	9.6.1	Preparing the cables	
	9.6.2	Fixing the cables to the rear cabinet panel	
	9.6.3	Cable connection and shield support	
	9.7	Technical data	
10	Configurir	ng	
	10.1	Features	
	10.1.1	Speed limitation	
	10.1.2 10.1.3	Star-delta or motor changeover	
		·	
	10.2	Preconditions for commissioning	
	10.2.1 10.2.2	Checklists	
	10.2.2	DRIVE-CLIQ topology at the High Frequency Drive	
	10.2.4	DRIVE-CLiQ topology at the HF line-up	
	10.3	Commissioning with SINUMERIK Operate	159
	10.3.1	Preconditions	159
	10.3.2	Workflow	
	10.3.3	Displaying the configuration/topology	161
	10.4	Overview of important parameters	164
	10.5	Alarm and fault messages	164
	10.6	Safety-related functions	164
11	Cabinet d	esign and EMC	165
	11.1	General information	165
	11.2	Safety instructions for control panel manufacturing	165
	11.3	24 V DC supply voltage	166
	11.3.1	General	
	11.3.2	24 V power supply and connection of components	
	11.3.3	Typical 24 V current consumption of the components	
	11.3.4	Selecting power supply units	170
	11.4	Connection system	171
	11.4.1	Connectable conductor cross-sections for line supply and power cables of the	474
	11.4.2	booksize components	
	11.4.2	Cable lugs	
	11.5	Protective connections and equipotential bonding	
	11.6	Arrangement of the devices	
		•	
	11.7	Cooling circuit and coolant properties	176

12	Service a	and maintenance	177
	12.1	Replacing the fan	177
	12.1.1	Safety instructions for replacing a fan	
	12.1.2	Replacing the fan at the HF Choke Module	177
	12.1.3	Replacing the fan at the HF Damping Module	179
	12.2	Recycling and disposal	180
Α	Appendix	x	181
	A.1	List of abbreviations	181
	A.2	Documentation overview	190
	Index		191

Fundamental safety instructions

### 1.1 General safety instructions



### **↑** DANGER

### Danger to life due to live parts and other energy sources

Death or serious injury can result when live parts are touched.

- Only work on electrical devices when you are qualified for this job.
- · Always observe the country-specific safety rules.

Generally, six steps apply when establishing safety:

- 1. Prepare for shutdown and notify all those who will be affected by the procedure.
- 2. Disconnect the machine from the supply.
  - Switch off the machine.
  - Wait until the discharge time specified on the warning labels has elapsed.
  - Check that it really is in a no-voltage condition, from phase conductor to phase conductor and phase conductor to protective conductor.
  - Check whether the existing auxiliary supply circuits are de-energized.
  - Ensure that the motors cannot move.
- 3. Identify all other dangerous energy sources, e.g. compressed air, hydraulic systems, or water.
- 4. Isolate or neutralize all hazardous energy sources by closing switches, grounding or short-circuiting or closing valves, for example.
- 5. Secure the energy sources against switching on again.
- 6. Ensure that the correct machine is completely interlocked.

After you have completed the work, restore the operational readiness in the inverse sequence.



### / WARNING

### Danger to life through a hazardous voltage when connecting an unsuitable power supply

Touching live components can result in death or severe injury.

 Only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV-(Protective Extra Low Voltage) output voltages for all connections and terminals of the electronics modules.

#### 1.1 General safety instructions



### / WARNING

### Danger to life when live parts are touched on damaged devices

Improper handling of devices can cause damage.

For damaged devices, hazardous voltages can be present at the enclosure or at exposed components; if touched, this can result in death or severe injury.

- Ensure compliance with the limit values specified in the technical data during transport, storage and operation.
- · Do not use any damaged devices.



### /!\WARNING

### Danger to life through electric shock due to unconnected cable shields

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

• As a minimum, connect cable shields and the conductors of power cables that are not used (e.g. brake cores) at one end at the grounded housing potential.



### / WARNING

### Danger to life due to electric shock when not grounded

For missing or incorrectly implemented protective conductor connection for devices with protection class I, high voltages can be present at open, exposed parts, which when touched, can result in death or severe injury.

• Ground the device in compliance with the applicable regulations.



### / WARNING

### Danger to life due to electric shock when opening plug connections in operation

When opening plug connections in operation, arcs can result in severe injury or death.

• Only open plug connections when the equipment is in a no-voltage state, unless it has been explicitly stated that they can be opened in operation.

### / WARNING

### Danger to life due to fire spreading if housing is inadequate

Fire and smoke development can cause severe personal injury or material damage.

- Install devices without a protective housing in a metal control cabinet (or protect the device by another equivalent measure) in such a way that contact with fire is prevented.
- Ensure that smoke can only escape via controlled and monitored paths.

### / WARNING

# Danger to life through unexpected movement of machines when using mobile wireless devices or mobile phones

Using mobile wireless devices or mobile phones with a transmit power > 1 W closer than approx. 2 m to the components may cause the devices to malfunction, influence the functional safety of machines therefore putting people at risk or causing material damage.

 Switch the wireless devices or mobile phones off in the immediate vicinity of the components.

### /!\warning

### Danger to life due to the motor catching fire in the event of insulation overload

There is higher stress on the motor insulation through a ground fault in an IT system. If the insulation fails, it is possible that death or severe injury can occur as a result of smoke and fire.

- · Use a monitoring device that signals an insulation fault.
- Correct the fault as guickly as possible so the motor insulation is not overloaded.

### WARNING

#### Danger to life due to fire if overheating occurs because of insufficient ventilation clearances

Inadequate ventilation clearances can cause overheating of components with subsequent fire and smoke. This can cause severe injury or even death. This can also result in increased downtime and reduced service lives for devices/systems.

 Ensure compliance with the specified minimum clearance as ventilation clearance for the respective component.

#### 1.1 General safety instructions

### / WARNING

### Danger of an accident occurring due to missing or illegible warning labels

Missing or illegible warning labels can result in accidents involving death or serious injury.

- Check that the warning labels are complete based on the documentation.
- Attach any missing warning labels to the components, in the national language if necessary.
- Replace illegible warning labels.

#### NOTICE

#### Device damage caused by incorrect voltage/insulation tests

Incorrect voltage/insulation tests can damage the device.

Before carrying out a voltage/insulation check of the system/machine, disconnect the
devices as all converters and motors have been subject to a high voltage test by the
manufacturer, and therefore it is not necessary to perform an additional test within the
system/machine.

### /!\WARNING

#### Danger to life when safety functions are inactive

Safety functions that are inactive or that have not been adjusted accordingly can cause operational faults on machines that could lead to serious injury or death.

- Observe the information in the appropriate product documentation before commissioning.
- Carry out a safety inspection for functions relevant to safety on the entire system, including all safety-related components.
- Ensure that the safety functions used in your drives and automation tasks are adjusted and activated through appropriate parameterizing.
- · Perform a function test.
- Only put your plant into live operation once you have guaranteed that the functions relevant to safety are running correctly.

#### Note

#### Important safety notices for Safety Integrated functions

If you want to use Safety Integrated functions, you must observe the safety notices in the Safety Integrated manuals.

### 1.2 Safety instructions for electromagnetic fields (EMF)



### /!\WARNING

#### Danger to life from electromagnetic fields

Electromagnetic fields (EMF) are generated by the operation of electrical power equipment such as transformers, converters or motors.

People with pacemakers or implants are at a special risk in the immediate vicinity of these devices/systems.

• Ensure that the persons involved are the necessary distance away (minimum 2 m).

### 1.3 Handling electrostatic sensitive devices (ESD)

Electrostatic sensitive devices (ESD) are individual components, integrated circuits, modules or devices that may be damaged by either electric fields or electrostatic discharge.



#### NOTICE

#### Damage through electric fields or electrostatic discharge

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport and send electronic components, modules or devices in their original packaging or in other suitable materials, e.g conductive foam rubber of aluminum foil.
- Only touch components, modules and devices when you are grounded by one of the following methods:
  - Wearing an ESD wrist strap
  - Wearing ESD shoes or ESD grounding straps in ESD areas with conductive flooring
- Only place electronic components, modules or devices on conductive surfaces (table with ESD surface, conductive ESD foam, ESD packaging, ESD transport container).

### 1.4 Industrial security

#### Note

#### Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (http://www.siemens.com/industrialsecurity).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (http://support.automation.siemens.com).

### / WARNING

### Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/or material damage.

- Keep the software up to date.
  - You will find relevant information and newsletters at this address (http://support.automation.siemens.com).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
  - You will find further information at this address (http://www.siemens.com/industrialsecurity).
- Make sure that you include all installed products into the holistic industrial security concept.

### 1.5 Residual risks of power drive systems

The control and drive components of a drive system are approved for industrial and commercial use in industrial line supplies. Their use in public line supplies requires a different configuration and/or additional measures.

These components may only be operated in closed housings or in higher-level control cabinets with protective covers that are closed, and when all of the protective devices are used.

These components may only be handled by qualified and trained technical personnel who are knowledgeable and observe all of the safety instructions on the components and in the associated technical user documentation.

When assessing the machine's risk in accordance with the respective local regulations (e.g., EC Machinery Directive), the machine manufacturer must take into account the following residual risks emanating from the control and drive components of a drive system:

- 1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example,
  - Hardware and/or software errors in the sensors, control system, actuators, and cables and connections
  - Response times of the control system and of the drive
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - Parameterization, programming, cabling, and installation errors
  - Use of wireless devices/mobile phones in the immediate vicinity of the control system
  - External influences/damage
- 2. In the event of a fault, exceptionally high temperatures, including an open fire, as well as emissions of light, noise, particles, gases, etc. can occur inside and outside the inverter, e.g.:
  - Component failure
  - Software errors
  - Operation and/or environmental conditions outside the specification
  - External influences/damage

Inverters of the Open Type/IP20 degree of protection must be installed in a metal control cabinet (or protected by another equivalent measure) such that contact with fire inside and outside the inverter is not possible.

### 1.5 Residual risks of power drive systems

- 3. Hazardous shock voltages caused by, for example,
  - Component failure
  - Influence during electrostatic charging
  - Induction of voltages in moving motors
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - External influences/damage
- 4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
- 5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly

#### Note

The components must be protected against conductive contamination (e.g. by installing them in a control cabinet with degree of protection IP54 according to IEC 60529 or NEMA 12).

Assuming that conductive contamination at the installation site can definitely be excluded, a lower degree of cabinet protection may be permitted.

For more information about residual risks of the components in a drive system, see the relevant sections in the technical user documentation.

System overview

### 2.1 SINAMICS S120 High Frequency Drive components

### System components

- Line-side power components such as fuses and contactors to switch the energy supply
- Line filter to comply with EMC regulations
- DC link components (Braking Module, Control Supply Module) used optionally for stabilizing the DC link voltage
- Additional system components and encoder system connections to expand the functionality and to handle various interfaces for encoders and process signals.

### Components for High Frequency Drives

- HF Motor Module that operates as an inverter and provides the power supply for the connected motor.
- HF Sine Filter Module consisting of
  - HF Choke Module and
  - HF Damping Module.
- Voltage Protection Module to protect the DC link against high motor voltages (optional).

Additional SINAMICS components are required to provide the required functions:

- Control Unit for processing drive and technology functions.
- Active Line Module that has the function of centrally supplying the power to the DC link.
- Braking Module (optional)
- Control Supply Module (optional)


The SINAMICS S120 High Frequency Drive is exclusively intended for installation in a control cabinet.

### Cooling methods

The SINAMICS S120 High Frequency Motor Module is available with liquid cooling.

The HF Sine Filter Module, comprising the HF Choke Module and the HF Damping Module, is available with the "Cold Plate" cooling type with additional internal fans.

### 2.2 Overview



- 1) Active Interface Module booksize
- ② Control Unit NX15.3
- 3 Active Line Module booksize
- 4 HF Motor Module
- (5) HF Choke Module
- Ontrol Supply Module (optional)
- 8 Braking Module with braking resistor (optional)

Figure 2-1 Example of an HF drive line-up with Active Line Module booksize



Risk of fire when using a synchronous motor without a Voltage Protection Module, Braking Module or Control Supply Module.

When a synchronous motor is not used together with a Voltage Protection Module, a Braking Module and a Control Supply Module then there is a risk of fire and associated smoke. This results in a risk of death.

 When using a synchronous motor, it is imperative that you always use a Voltage Protection Module, Braking Module and Control Supply Module.

### 2.3 System data

Unless explicitly specified otherwise, the following technical data are valid for components of the SINAMICS S120 drive system.

Table 2- 1 Electrical data

Line voltage	3-phase 380 480 VAC ±10%
Line frequency	47 63 Hz
Line supply types	TN systems
Electronics power supply	24 V DC -15/+20 % Safety extra low-voltage (PELV / SELV)
Short-circuit current rating (SCCR) in accordance with UL 508C (up to 600 V)	1.1 447 kW: 65 kA
DC link supply voltage	510 720 V DC
Radio interference suppression	Category C3 for plant and system versions in conformance with the documentation
Overvoltage category	III
Degree of contamination	2

Table 2- 2 Environmental conditions

Degree of protection	IPXXB acc. to IEC 60529, open type according to UL 508C
Protection class, line supply circuits Electronic circuits	I (with protective conductor connection) safety extra-low voltage (PELV / SELV)
Permissible cooling medium temperature (air) and installation altitude in operation	0 °C up to +40 °C and up to 1000 m above sea level without derating, From an altitude of 1000 m, the maximum ambient temperature is reduced by 3.5 K per 500 m. Maximum installation altitude: 4000 m above sea level
Chemically active substances	
Long-term storage in the transport packaging	Class 1C2 according to EN 60721-3-1
Transport in the transport packaging	Class 2C2 according to EN 60721-3-2
Operation	Class 3C2 according to EN 60721-3-3
Biological environmental conditions	
Long-term storage in the transport packaging	Class 1B1 according to EN 60721-3-1
Transport in the transport packaging	Class 2B1 according to EN 60721-3-2
Operation	Class 3B1 according to EN 60721-3-3
Vibratory load	
Long-term storage in the transport packaging	Class 1M2 in accordance with EN 60721-3-1
Transport in the transport packaging	Class 2M3 in accordance with EN 60721-3-2
Operation	Class 3M2 according to EN 60721-3-3

### 2.3 System data

Shock stressing	
Long-term storage in the transport packaging	Class 1M2 in accordance with EN 60721-3-1
Transport in the transport packaging	Class 2M3 in accordance with EN 60721-3-2
Operation	Test values: 15 g / 11 ms
Climatic environmental conditions	
Long-term storage in the transport packaging	Class 1K4 acc. to EN 60721-3-1 Temperature: -25 +55 °C
Transport in the transport packaging	Class 2K4 according to EN 60721-3-2 Temperature: -40°C +70°C
Operation	better than Class 3K3 according to EN 60721-3-3
	Temperature: 0 +40 °C without derating, >40 55 °C see derating curves Relative humidity: 5 95 % (no condensation)
	Oil mist, salt mist, ice formation, condensation, dripping water, spraying water, splashing water and water jets are not permitted

### Table 2- 3 Certificates

Declarations of Conformity	CE
Approvals	USA approval (TÜV SÜD NRTL approval)

High Frequency Modules, line connection

3

To connect the SINAMICS S120 High Frequency Drive drive line-up to the line supply these components are used:

- Overcurrent protection device (line fuse or circuit breaker)
- Line contactor, line disconnector device (optional)
- Line filter
- Active Interface Module

### **Booksize**

The line connection for an S120 High Frequency Drive with a booksize Active Line Module comprises, in addition to the regionally required protective devices, an optional line filter and an Active Interface Module.




Figure 3-1 Overview diagram, line connection booksize

#### Note

With line filter, Active Interface Module and Active Line Module, the High Frequency drive attains radio interference voltage, Category C3 ( $I_{Line} > 100 \text{ A}$ ).

#### Chassis

The line interface for a SINAMICS S120 High Frequency Drive with an Active Line Module Chassis comprises, in addition to the regionally stipulated protective devices, an Active Interface Module – and depending on the frame size of the Active Interface Module, an additional bypass contactor. A drive line-up with chassis components can be implemented with radio interference voltage category C3.




Figure 3-2 Block diagram, line connection, chassis

#### Note

You can find detailed information about the line interface in the SINAMICS S120 Manuals:

- Power components booksize manual (GH2)
- Power units chassis manual (GH3)

High Frequency Modules

### 4.1 Introduction

The SINAMICS S120 High Frequency Drive is an inverter with integrated output filter (HF Sine Filter Module) to control motors with high output frequencies (up to 2400 Hz). The High Frequency Drive is operated with a pulse frequency of 16 kHz or 32 kHz, and a current controller clock cycle of 62.5 µs or 31.25 µs.

High Frequency Drives are used for high-performance machining in tool and mold making for and for cutting gear wheels. It can be used in conjunction with high-speed spindle motors and torque motors.

High Frequency Drives are only designed for installation in control cabinets.

A High Frequency Drive consists of three components (HF modules), which can only be operated together in the HF line-up:


- HF Motor Module
- HF Choke Module (reactor module)
- HF Damping Module

HF Choke Modules and HF Damping Module together form the HF Sine Filter Module.

The HF line-up is supplied from the factory in individual components.

The diagram shows the arrangement of the components in the HF line-up.

### 4.1 Introduction



- 1 HF Motor Module
- ② DC link busbar (behind the protective cover)
- (3) HF Choke Module
- 4 HF Damping Module
- (5) Busbar connector, HF Damping Module HF Choke Module
- 6 Motor connection
- Shield connection plate
- 8 Connection for a Voltage Protection Module (VPM)
- Busbar connector, HF Motor Module HF Choke Module
- 8 Equipotential bonding bar

Figure 4-1 High Frequency Drive: Mechanical design

In addition, these components are required to operate a High Frequency Drive:

- Active Line Module in the booksize or chassis format in conjunction with an Active Interface Module
- Control Unit
- Voltage Protection Module (for synchronous motors)
- Braking Module (for synchronous motors)
- Control Supply Module (for synchronous motors)
- 24 V power supply, for example SITOP

Table 4-1 HF module package Liquid Cooled

Article No.	Dimensions (W x H x D) [mm]	Technical data	Cooling
6SL3125-1UE32-2AD0	750 x 622 x 226	16 kHz, 400 V, 225 A	Liquid cooling

The HF module package includes the parts listed in the table.

Table 4-2 Scope of supply

Designation	Article No.	Quantity
HF Motor Module	6SL3125-1UE32-2AA0	1
HF Choke Module	6SL3125-2UE32-2AA0	1
HF Damping Module	6SL3125-3UE32-2AA0	1
3-phase busbar connector for transverse busbar connections		2
Equipotential bonding bar		1
Shield connection plate		1
Terminal Kit		1

### 4.2 Safety instructions for High Frequency Modules

### / WARNING

Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

The non-observance of the fundamental safety instructions and residual risks stated in Chapter 1 can result in accidents with severe injuries or death.

- Adhere to the fundamental safety instructions.
- · When assessing the risk, take into account remaining risks.



### / WARNING

Danger of death caused by high discharge currents when the external protective conductor is interrupted

Drive components conduct high discharge currents via the protective conductor. When the protective conductor is interrupted, touching live components can result in electric shock, which can lead to death or serious injuries.

- Ensure that the external protective conductor complies with at least one of the following conditions:
  - It is laid protected against mechanical damage.<sup>1)</sup>
  - If it consists of a single conductor, it has a cross section of at least 6 mm<sup>2</sup> Cu.
  - As a core of a multi-core cable, it has a cross section of at least 2.5 mm<sup>2</sup> Cu.
  - It has a parallel, second protective conductor with the same cross-section.
  - It corresponds to the local regulations for equipment with increased leakage current.
  - <sup>1)</sup> Cables routed in control cabinets or enclosed machine enclosures are considered to be adequately protected against mechanical damage.



### **↑** DANGER

Danger of death due to electric shock resulting from residual charge of the DC link capacitors

As a result of the DC link capacitors, a hazardous voltage is present for up to 5 minutes after the power supply has been switched off.

Touching live components results in death or severe injury.

- Only open the DC link protective cover after 5 min. has elapsed.
- Before starting any work, measure the voltage at the DC link terminals DCP and DCN.



### DANGER

Danger to life as a result of electric shock when the DC link protective cover is open

Touching live components results in death or severe injury.

 Only operate the components with the protective cover of the DC link components closed.



### / WARNING

#### Danger to life due to electric shock when connecting to the DC link

Incorrectly established connections can result in overheating and therefore fire with associated smoke. Further, there is risk of electric shock. This can result in severe injury or death.

• To connect to the DC link, only use the adapters that have been released for the purpose (DC link adapter and DC link rectifier adapter).



### /!\WARNING

### Danger to life due to electric shock as a result of missing DC link side covers

If the DC link side covers are missing, there is a risk of electric shock when coming into contact with the DC link.

- Mount the side covers supplied with the equipment at the first and last component in the drive line-up.
- Order any missing side covers (Article number: 6SL3162-5AA00-0AA0).

### / WARNING

### Risk of accident as a result of missing warning labels in the local language

Missing warning labels in the local language can result in accidents leading to death or severe injury.

Attach warning labels in the local language on components.

#### **NOTICE**

#### Material damage caused by loose power connections

Insufficient tightening torques or vibration can result in faulty electrical connections. This can result in damage due to fire or malfunctions.

- Tighten all power connections with the specified tightening torques, e.g. line supply connection, motor connection, DC-link connections.
- Check the tightening torques of all power connections at regular intervals, and retighten them accordingly. This applies in particular after transport.

### **NOTICE**

### Damage when using incorrect DRIVE-CLiQ cables

Damage or malfunctions can occur on the devices or system when DRIVE-CLiQ cables are used that are either incorrect or have not been approved for this purpose.

 Only use suitable DRIVE-CLiQ cables that have been approved by Siemens for the particular application.

### 4.3 HF Motor Module

### 4.3.1 Description

An HF Motor Module is a power unit (inverter) that provides the power for the motor connected to it. An Active Line Module provides the power supply. From the 3-phase line voltage, this generates a regulated constant DC voltage in the DC link of the HF drive lineup.

The HF Motor Module must be connected with the Control Unit via DRIVE-CLiQ.

# 4.3.2 Interfaces

### 4.3.2.1 Overview




Figure 4-2 Interface overview of HF Motor Modules Liquid Cooled

### 4.3.2.2 X21 EP terminals/temperature sensor motor module

Table 4-3 X21 EP terminal/temperature sensor

	Terminal	Function	Technical data
	1	+ Temp	Temperature sensors: KTY84–1C130 / PTC / bimetallic
	2	- Temp	switch with NC contact
2	3	EP +24 V (enable pulses)	Supply voltage: 24 V DC (20.4 28.8 V)
3 4	4	EP M1 (Enable Pulses)	Current consumption: 10 mA Isolated input Signal propagation times: L → H: 100 µs H → L: 1000 µs
			The pulse inhibit function is only available when Safety Integrated Basic Functions are enabled.

Type: Screw terminal 1 (Page 172)

Max. connectable cross-section: 1.5 mm<sup>2</sup>

### **EP** terminal

The filter times to debounce terminals X21.3 and X21.4 are set using parameters (see SINAMICS S120/S150 List Manual). Additional parameter settings are also required in order to prevent discrepancy errors when performing bit pattern tests (light/dark tests). For comprehensive information, see the SINAMICS S120 Safety Integrated Function Manual, Chapter "Controlling the safety functions".



# /!\warning

### Danger to life due to electric shock when connecting unsuitable voltages

Touching parts and components that are at excessively high voltages can result in death or severe injury.

 Only connect safety extra-low voltages (PELV/SELV) at terminals "EP +24 V" and "EP M1".

#### Note

### Function of the EP terminals

The function of the EP terminals is only available when Safety Integrated Basic Functions are enabled.

### Temperature sensor



# /!\WARNING

# Danger to life due to electric shock caused by voltage flashovers to the temperature sensor cable

Voltage flashovers to the signal electronics can occur for temperature sensors without safe electrical separation.

- Use temperature sensors that fully comply with the specifications of protective separation (safety isolation).
- If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), use a Sensor Module External (SME120 or SME125) or Terminal Module TM120.

### NOTICE

# Damage due to overheating, caused by a KTY temperature sensor that has been incorrectly connected

If the KTY temperature sensor was not connected with the correct polarity, motor overheating may not be detected.

Connect the KTY sensor with the correct polarity.

### NOTICE

### Device failure as a result of unshielded or incorrectly routed cables to temperature sensors

Unshielded or incorrectly routed cables to temperature sensors can result in interference being coupled into the signal processing electronics from the power side. This can result in significant disturbance of all signals (fault messages) up to failure of individual components (destruction of the devices).

- Only use shielded cables as temperature sensor cables.
- If temperature sensor cables are routed together with the motor cable, use separately shielded cables twisted in pairs.
- Connect the cable shield at both ends to ground potential through a large surface area.
- Recommendation: Use suitable MOTION CONNECT cables.

### 4.3.2.3 X200-X202 DRIVE-CLiQ interfaces

Table 4- 4 X200-X202 DRIVE-CLiQ interfaces

	Pin	Name	Technical data
	1	TXP	Transmit data +
∘БВВ	2	TXN	Transmit data -
	3	RXP	Receive data +
8 A	4	Reserved, do not use	
ДДА	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 x) Article No.: 6SL3066-4CA00-0AA0


### 4.3.2.4 Protective conductor connection

Table 4-5 Protective conductor connection for HF Motor Module

Terminals	Technical data
PE connection for attaching the equipotential bonding bar	Threaded hole: M8 Tightening torque: 13 Nm For ring cable lugs without insulation (Page 173)

### 4.3.2.5 Busbars

Table 4- 6 Busbars at the HF Motor Module



# 4.3.3 Meaning of the LEDs

Table 4-7 Meaning of the LEDs

S	tate	Description, cause	Remedy
RDY	DC LINK		
Off	Off	The electronics power supply is missing or outside the permissible tolerance range.	_
Green		The component is ready for operation. Cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	The component is ready for operation. Cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is present.	_
	Red	The component is ready for operation. Cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is too high.	Check the line supply voltage.
Orange	Orange	DRIVE-CLiQ communication is being established.	_
Red		This component has at least one fault.  Note: The LED is controlled irrespective of the corresponding messages being reconfigured.	Resolve and acknowledge the fault.
Green/red (0.5 Hz)		Firmware is being downloaded.	_
Green/red (2 Hz)		Firmware download is complete. The system waits for POWER ON.	Carry out a POWER ON.
Green/orange or Red/orange		Recognition of components via LED is activated <sup>1)</sup> . <b>Note:</b> Both options depend on the LED status when activated.	_

<sup>1)</sup> See SINAMICS S120/S150 List Manual for the parameters to activate the recognition of components via LED

# DANGER

# Danger to life as a result of electric shock when coming into contact with the DC link voltage

Irrespective of the state of the LED "DC LINK", hazardous DC link voltages can always be present.

Death or serious injury can result when live parts are touched.

• Observe the warning information on the component.

# 4.3.4 Dimension drawing




Figure 4-3 Dimension drawing of HF Motor Modules Liquid Cooled in mm and (inches)

### 4.4 HF Sine Filter Module

### 4.4.1 Description

The HF Sine Filter Module is the output filter (sine-wave filter) in the High Frequency Drive. It limits the harmonics and switching edges generated by the switching operations of the inverter to values that are permissible for the motor and can be tolerated. It opposes an excessively high dV/dt rise.

The HF Sine Filter Module comprises a HF Choke Module and a HF Damping Module. This filter means that the voltage between the motor terminals is almost sinusoidal. This reduces the voltage stress on the motor windings, which is excited by the pulse frequency of the HF Motor Module.

The HF Sine Filter Module must be mounted directly to the right of the HF Motor Module.

The HF module line-up can be operated with a pulse frequency of 16 kHz or 32 kHz. This increases the damping properties of the system.

#### **HF Choke Module**

The HF Choke Module contains the reactor of the sine-wave filter. It has a terminal block to connect the power cables to the motor and a terminal block to connect the Voltage Protection Module (VPM).

The following signals are acquired in the HF Choke Module, and transferred to the HF Damping Module for monitoring and diagnostics:

- Reactor temperature via KTY temperature sensor
- Overtemperature trip

### **HF Damping Module**

The HF Damping Module contains the capacitors of the sine-wave filter. Further, part of the filter power loss is fed back into the DC link via this module. This is the reason that this module must be connected with the DC link.

4 measured values are acquired in the HF Damping Module, and transferred to the Control Unit via DRIVE-CLiQ:

- Filter currents in all 3 phases of the filter capacitors
- Damping voltage
- Device temperature
- Temperature of the HF Choke Module via the KTY temperature sensor

### 4.4.2 HF Choke Module interfaces

### 4.4.2.1 Overview




Figure 4-4 Interface overview, HF Choke Module

### 4.4.2.2 X21 outputs for temperature monitoring

Table 4-8 X21 outputs for temperature monitoring

	Terminal	Function	Technical data		
1 2 3 4	1	+ KTY	Temperature HF Choke Module analog:		
	2	- KTY	KTY84-1C130 temperature sensor		
	3	+ Temp switch	Temperature monitoring for the HF Choke Module using the		
	4	- Temp switch	integrated bimetallic switch		
T C 6	Type: Seraw terminal 1 (Dece 172)				

Type: Screw terminal 1 (Page 172)

Max. connectable cross-section: 1.5 mm<sup>2</sup>

### Note

### Internal fans

The internal fans of the HF Choke Module run permanently regardless of the temperature and whether the pulses are enabled.

### Connect the terminals to transfer the temperature signals

The HF line-up does not function without the X21 terminals being connected. Therefore, it is absolutely necessary that the following terminals are connected with one another to transfer the temperature signals from the HF Choke Module to the HF Damping Module:

- X21.1 and X21.2 on the HF Choke Module with X21.1 and X21.2 on the HF Damping Module
- X21.3 and X21.4 on the HF Choke Module with X21.3 and X21.4 on the HF Damping Module

Use shielded signal cables and connect the cable shields to the supplied shield terminal.

### 4.4.2.3 X22 fan control for commissioning

Table 4-9 X22 fan control for commissioning

	Terminal	Function	Technical data
1 2 3 4	1	n.c.	
	2	n.c.	
	3	Disable FAN	Using a jumper, the fans can be deactivated <b>for</b>
	4	Disable FAN	commissioning.

Type: Screw terminal 1 (Page 172)
Max. connectable cross-section: 1.5 mm<sup>2</sup>

# 4.4.2.4 Voltage Protection Module Connection

Table 4- 10 Voltage Protection Module Connection

Terminals	Technical data
U1 V1 W1	Threaded bolts: M8 Tightening torque: 13 Nm For ring cable lugs without insulation (Page 173)
PE connection	Threaded hole: M8 Tightening torque: 13 Nm For ring cable lugs without insulation (Page 173) Connection photograph, see Chapter Electrical connection (Page 62)

### Note

The Voltage Protection Module power cables may have a maximum length of 3 m.

### 4.4.2.5 Motor connection

Table 4- 11 Motor connection

Terminals	Technical data
U2 V2 W2	Threaded bolts: M8 Tightening torque: 13 Nm For ring cable lugs without insulation (Page 173)
PE connection	Threaded hole: M8 Tightening torque: 13 Nm For ring cable lugs without insulation (Page 173) Connection photograph, see Chapter Electrical connection (Page 62)

### Note

The total length of the shielded power cables must not exceed 100 m.

# 4.4.2.6 Protective conductor connections for the equipotential bonding bar

Table 4- 12 Protective conductor connections HF Choke Module

Terminals	Technical data
PE connections directly at the housing to fix the equipotential bonding bar	Threaded hole: M8 Tightening torque: 13 Nm For ring cable lugs without insulation (Page 173)

### 4.4.2.7 Busbars

Table 4- 13 Busbars to the HF Motor Module





Table 4- 14 Busbars to the HF Damping Module



# 4.4.3 HF Damping Module interfaces

### 4.4.3.1 Overview




Figure 4-5 HF Damping Module interface overview

### 4.4.3.2 X21 inputs for temperature monitoring

Table 4- 15 X21 inputs for temperature monitoring

	Terminal	Function	Technical data
	1	+ Temp	Temperature HF Choke Module analog:
	2	- Temp	KTY84-1C130 temperature sensor
2	3	+ Temp	Temperature Choke Module digital:
3	4	- Temp	Bimetallic switch
4			

Type: Screw terminal 1 (Page 172)
Max. connectable cross-section: 1.5 mm<sup>2</sup>

### Connect the terminals to transfer the temperature signals

The HF line-up does not function without the X21 terminals being connected. Therefore, it is absolutely necessary that the following terminals are connected with one another to transfer the temperature signals from the HF Choke Module to the HF Damping Module:

- X21.1 and X21.2 on the HF Choke Module with X21.1 and X21.2 on the HF Damping Module
- X21.3 and X21.4 on the HF Choke Module with X21.3 and X21.4 on the HF Damping Module

Use shielded signal cables and connect the cable shields to the supplied shield terminal.

### 4.4.3.3 X200-X203 DRIVE-CLiQ interfaces

Table 4- 16 X200-X203 DRIVE-CLiQ interfaces


	Pin	Name	Technical data
	1	TXP	Transmit data +
。⊟∎В	2	TXN	Transmit data -
8 A	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 x) Article No.: 6SL3066-4CA00-0AA0

### 4.4.3.4 Busbars

Table 4- 17 Busbars to the HF Choke Module



# 4.4.4 Meaning of the LEDs

# Meaning of the LEDs on the HF Choke Module

Table 4- 18 Meaning of the LEDs

State		Description, cause	Remedy
RDY	DC LINK		
Off	Off	The electronics power supply is missing or outside the permissible tolerance range.	_
Green		The component is ready for operation.	-
Red		The temperature switch has responded (temperature monitoring for the HF Choke Module via the integrated bimetallic switch).	Check the cooling and fan.

# DANGER

Danger to life as a result of electric shock when coming into contact with the DC link voltage

Irrespective of the state of the LED "DC LINK", hazardous DC link voltages can always be present.

Death or serious injury can result when live parts are touched.

• Observe the warning information on the component.

### Meaning of the LEDs on the HF Damping Module

Table 4- 19 Meaning of the LEDs

State		Description, cause	Remedy
RDY	DC LINK		
Off	Off	The electronics power supply is missing or outside the permissible tolerance range.	_
Green		The component is ready for operation. Cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	The component is ready for operation. Cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is present.	_
	Red	The component is ready for operation. Cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is too high.	Check the line supply voltage.
Orange	Orange	DRIVE-CLiQ communication is being established.	_
Red	-	This component has at least one fault.  Note: The LED is controlled irrespective of the corresponding messages being reconfigured.	Resolve and acknowledge the fault.
Green/red (0.5 Hz)		Firmware is being downloaded.	_
Green/red (2 Hz)		Firmware download is complete. The system waits for POWER ON.	Carry out a POWER ON.
Green/orange or Red/orange		Recognition of components via LED is activated <sup>1)</sup> . <b>Note:</b> Both options depend on the LED status when activated.	_

<sup>1)</sup> See SINAMICS S120/S150 List Manual for the parameters to activate the recognition of components via LED

# DANGER

# Danger to life as a result of electric shock when coming into contact with the DC link voltage

Irrespective of the state of the LED "DC LINK", hazardous DC link voltages can always be present.

Death or serious injury can result when live parts are touched.

· Observe the warning information on the component.

# 4.4.5 Dimension drawings

# 4.4.5.1 HF Choke Module




Figure 4-6 Dimension drawing HF Choke Module, all data in in mm (inches)

# 4.4.5.2 HF Damping Module




Figure 4-7 Dimension drawing HF Damping Module, all data in mm (inches)

### 4.5 Installation

The High Frequency Drive, depending on the area of application, can be operated with either an Active Line Module, chassis or booksize format. The HF drive lineup can be expanded using SINAMICS S120 Booksize components with cold plate cooling. This allows a uniform mounting depth of the components to be achieved, as well as a simple connection of the DC link and 24 V busbars.

The position of the High Frequency Drive can be chosen freely within the drive line-up.

#### Note

When installing the High Frequency Drive in the control cabinet, always ensure that the HF function line-up – Choke Module and HF Damping Module (HF Sine Filter Module) – is always directly to the right of the HF Motor Module.

### Mounting position in the control cabinet

Always mount the SINAMICS S120 components in the control cabinet in a vertical position. Other permissible mounting positions are listed in the descriptions for the individual components.

### NOTICE

### Shorter component service life when the installation regulations are violated

If you do not observe the guidelines for installing the HF line-up in the electrical cabinet, this can reduce the service life of the components and result in premature component failure.

Comply with the installation regulations of the HF lineup in the electrical cabinet.


### Cooling clearances

Table 4-20 Cooling clearances, HF Modules

Above the HF Module	Below the HF Module	
80 mm	80 mm	

### Use of the mounting aid

To lift the HF Choke Module from the transport pallet using a crane, shackles according to EN 13889 must be attached to the lifting lugs of the mounting aid.



- 1 Shackles according to EN 13889 with a bolt diameter of approx. 16 mm
- ② Mounting aid

Figure 4-8 Mounting aid with shackles

### **NOTICE**

### Damage to the mounting aid when lifting without a shackle

The HF Choke Module can be damaged if the crane hook is directly attached to the lifting eyes of the mounting aid.

• Always use a shackle to lift the HF Choke Module.

### Mounting plate

When installing the High Frequency Drive in a control cabinet, use a mounting plate with the following properties:

Material: Aluminum

Thickness: 15 mm

• Surface roughness: Rz25

### Note

The mounting plate must be connected to the protective conductor connection of the control cabinet through a low impedance. See also Chapter Protective connections and equipotential bonding (Page 174).

# Heat dissipation

It is not necessary to install a separate cold plate cooling to cool the HF Choke Module and HF Damping Module. The modules are cooled through the mounting plate. The mounting plate cooling assumes the internal cooling circuit in the cold plate of the HF Motor Module.

### **Drilling patterns**

The drilling patterns shown below apply to the High Frequency drive with and without Active Line Module, booksize format.

Prepare the mounting plate as follows:

- 1. Machine the M6 threaded holes.
- 2. Countersink the holes with  $\emptyset$  18<sup>+2</sup> mm (for details see the drilling pattern).




Figure 4-9 Drilling pattern for the High Frequency Drive with Active Line Module booksize, all data in mm and (inches)

### 4.5 Installation





Figure 4-10 Drilling pattern for the High Frequency Drive without Active Line Module booksize, all data in mm and (inches)

# Mounting on the mounting plate


- 1. Individually mount the HF Modules one after the other on the mounting plate. Start with the left-hand component. First mount all of the modules of the DC link and the 24 V busbars before connecting them up.
- 2. Before mounting, insert the screws and washers into the mounting plate from the rear as shown below.



- Mounting plate
- ② Countersunk threaded hole
- Washer
- Spring washer
- M6 hexagon screw


Figure 4-11 Preparing the mounting plate

### 4.5 Installation



- Mounting plate
- 2 M6 hexagon screw
- 3 Washer
- Spring washer
- (5) M6 nut, SW10 Tightening torque 10 Nm

Figure 4-12 Mounting the High Frequency Drive with a Active Line Module in the booksize format on a mounting plate



- ① Mounting plate
- ② M6 hexagon screw
- 3 Washer
- Spring washer
- M6 nut, SW10 Tightening torque 10 Nm

Figure 4-13 Mounting the High Frequency Drive on a mounting plate

# 4.6 Electrical connection

### 4.6.1 Connecting the DC-link busbars and 24 V busbars

- 1. Connect the DC link busbars of the HF modules the same as for standard booksize components.
- 2. Connect the 24 V busbars using the red 24 V connector provided in the accessories pack.
- 3. Mount the side cover for the DC link at the first and last component of the drive line-up.





Danger to life as a result of electric shock when connecting hazardous voltages to the 24 V busbars

When a hazardous voltage is connected to the 24 V busbars, you can suffer death or severe injury when coming into contact with the busbars.

• Only connect safety extra low voltages (PELV or SELV) to 24 V busbars.

Additional information and diagrams can be found in the SINAMICS S120 Manual for "Booksize Power Units" (Chapter: Electrical connection for Line Modules and Motor Modules).

### Tightening torque of the screws

The tightening torque for DC link busbar screws is 1.8 Nm (tolerance: +30 %).

### **NOTICE**

### Material damage due to loose DC link connections

Insufficient tightening torques can result in faulty electrical connections. This can result in damage due to fire or malfunctions.

- Check the correct tightening torque of the DC link busbar screws (1.8 Nm) before commissioning with the system disconnected from the power supply and the DC link fully discharged.
- Check the screws at terminal connections, e.g. DC link busbars and motor terminals after transport or at the latest after every 5 years. If necessary, retighten the screws.


# 4.6.2 Connecting the busbars

Before commissioning the drive line-up, connect the busbars between:

- HF Motor Module and HF Choke Module
- HF Choke Module and HF Damping Module


### Mounting steps

- 1. Remove the busbar connections from the accessories pack.
- 2. Insert the connectors on the busbars and hold them in place.
- 3. Tighten the screws with a Torx screwdriver by hand and in a second step with the tightening torque of 3 Nm.



- 1 Busbars (3-part) on the HF Motor Module
- ② Busbar connections
- 3 6 screws (Torx T25, M5
- 4 Busbars (3-part) on the HF Choke Module

Figure 4-14 Connecting the busbars at the HF Motor Module and the HF Choke Module



- 1 Busbars (3-part) on the HF Choke Module
- ② Busbar connections
- 3 6 screws (Torx T25, M5
- 4 Busbars (3-part) on the HF Damping Module

Figure 4-15 Connecting the busbars at the HF Choke Module and HF Damping Module

### 4.6.3 Protective conductor connection of the HF module

# Protective conductor connections for Voltage Protection Module and the motor

The protective conductor of the power cables to the Voltage Protection Module and motor are connected to the HF Choke Module as shown below.



- ① Protective conductor connection for the equipotential bonding bar
- 2 Protective conductor connection motor
- ③ Protective conductor connection Voltage Protection Module

Figure 4-16 Protective conductor connections at the HF Choke Module

### Protective conductor connection via the equipotential bonding bar

The protective conductor connection between the HF modules must be established using the equipotential bonding bar supplied. The equipotential bonding bar is provided in the accessories pack.

The protective conductor connection of the HF module to the equipotential bonding bar of the control cabinet is established through a grounding cable, which is attached at the HF Motor Module.

- 1. Remove the M8 bolts with flat and spring washers from the following protective conductor connections:
  - HF Motor Module (left)
  - HF Choke Module at the left and right, directly at the housing
  - HF Damping Module
- 2. Fix the equipotential bonding bar (⑤) to the protective conductor connections of the housing of the HF Damping Module (⑥) and HF Choke Module (①) using the previously removed screws, washers and spring washers.
- 3. Attach the grounding cable of the cabinet with the ring cable lug to the equipotential bonding bar at the HF Motor Module (④), and fix both using the remaining screw.

### Tightening torques: 13 Nm





Figure 4-17 Installing the equipotential bonding bar


# 4.7 Connection examples

# 4.7.1 High Frequency Drive with components in the booksize format



- 1) Leading opening contact t > 10 ms
- 2) DI/DO controlled from the Control Unit.
- 3) No additional load permitted downstream of line contactor!
- 4) The current carrying capacity of the DO must be observed; an output coupling device must be used if required.
- 5) Contacting via rear mounting panel or shielding buses in accordance with EMC Directive.

Figure 4-18 Example for connecting a High Frequency Drive to the line supply via an Active Line Module in the booksize of format with Active Interface Module



- Optional, e.g. for motor without encoder
   Required for safety
- 3) Use shielded signal cables, connect cable shields to the shield connection terminals provided
- 4) Deactivate the fan, only for commissioning 5) DRIVE-CLIQ connection for High Frequency Drive with 32 kHz pulse frequency
- 6) Protective conductor connection with grounding bar across all HF modules (see Chapter "Electrical connection")
- 7) PE connection, Voltage Protection Module
- 8) PE connection, motor

Figure 4-19 Connection example for a High Frequency Drive with booksize infeed

# 4.7.2 High Frequency Drive with components in the chassis format




Figure 4-20 Connection example for a High Frequency Drive with chassis infeed

# 4.8 Technical data

Table 4- 21 Technical data of HF modules Liquid Cooled

High Frequency Drive Liquid Cooled		6SL3125-1UE32-2AD0
Output current		225
Rated current (In)	AACrms	225
Base load current (I <sub>H</sub> )	A	158
Intermittent duty current (I <sub>S6</sub> ) 40 %	AACrms(Is6)	292
Peak current (I <sub>max</sub> ) <sup>1)</sup>	AACrms	292
Output voltage	V <sub>ACrms</sub>	0 480
DC link current (I <sub>d max</sub> )	A <sub>DC</sub>	200
DC link voltage (up to 2000 m above sea level)	V <sub>DC</sub>	510 720
Input power based on In (600 V DC)	kW	120
DC link capacitance	μF	5800
Overvoltage trip	$V_{DC}$	820 ± 2 %
Undervoltage trip <sup>2)</sup>	V <sub>DC</sub>	380 ± 2 %
Electronics power supply (PELV/SELV)	V <sub>DC</sub>	24 (20.4 28.8)
Electronics current consumption at 24 V DC (PELV/SELV)		
HF Motor Module	A <sub>DC</sub>	0.8
HF Choke Module	A <sub>DC</sub>	1.6
HF Damping Module	ADC	0.9
Current carrying capacity		
DC link busbar	ADC	200
24 V busbar	ADC	20
Type rating <sup>3)</sup>		
Based on In (600 VDC)	kW	120
Based on I <sub>H</sub>	kW	85
Total power loss(including losses from the electronics)		
HF Motor Module	W	3019.2
HF Choke Module	W	598.4
HF Damping Module	W	61.6
Component of internal losses	W	926.8
Max. output frequency	Hz	1200
Max. Pulse frequency		
without derating	kHz	16
with derating	kHz	32
Max. ambient temperature		
without derating	°C	40
with derating	°C	55
Max. coolant temperature	80	45
- without derating	°C	45
- with derating	°C	50
System pressure	kPa	600
Nominal flow rate	I/min	7
for water with a 70 kPa pressure drop <sup>4)</sup>		
Internal volume of liquid	ml	100

### 4.8 Technical data

High Frequency Drive Liquid Cooled		6SL3125-1UE32-2AD0
Sound pressure level		
HF Choke Module	dB(A)	< 73
HF Damping Module	dB(A)	< 60
Weight		
HF Motor Module	kg	30.5
HF Choke Module	kg	48.5
HF Damping Module	kg	14.0

<sup>1)</sup>  $I_{max} = I_{S6} = 1.3 \times I_n$ 

# 4.8.1 Characteristics

# Rated duty cycles of HF modules




Figure 4-21 Load cycle with previous load




Figure 4-22 Load cycle without previous load

<sup>2)</sup> Default for 400 V line supplies; undervoltage trip threshold is adjusted to the parameterized rated voltage

<sup>3)</sup> Rated power of a typical standard induction motor at 3 AC 400 V

<sup>4)</sup> This value applies when water is used as coolant; for other coolant types, see Section "Cooling circuit and coolant properties".




Figure 4-23 S6 duty cycle with initial load with a duty cycle duration of 600 s




Figure 4-24 S6 duty cycle with initial load for a duty cycle duration of 60 s

### Note

The overload factor is a maximum of 1.3 x  $I_n$ .

# Derating characteristics H module




Figure 4-25 Output current as a function of the ambient temperature

### 4.8 Technical data




Figure 4-26 Output current as a function of the installation altitude




Figure 4-27 Output current as a function of the coolant temperature

If a 225 A HF drive is operated with a pulse frequency of 32 kHz, then the output current must be derated down to 60 % (135 A).




Figure 4-28 Output current as a function of the pulse frequency for a 225 A HF drive

**Voltage Protection Module (VPM)** 

5

# 5.1 Description

The Voltage Protection Module (VPM) is used to limit the voltage when using synchronous motors. It is directly connected to the HF Choke Module.

If the line voltage fails at the maximum motor speed or the pulses at the HF Motor Module are canceled as a result of the power failure, the motor regenerates at a high voltage into the DC link.

The Voltage Protection Module measures the motor voltage. If the rectified motor voltage is > 800 V, an armature short-circuit is triggered. The motor is decelerated by the short-circuit. The energy remaining in the motor is converted to heat.

A VPM 200 Dynamik is used as Voltage Protection Module in a High Frequency Drive.

Table 5- 1 VPM 200 Dynamik interface overview

Туре	Quantity
Signaling interface	1
PE connection	4
Load connecting bolt, input	5
Load connecting bolt, output	5

# 5.2 Safety instructions for Voltage Protection Modules

# / WARNING

Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

The non-observance of the fundamental safety instructions and residual risks stated in Chapter 1 can result in accidents with severe injuries or death.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account remaining risks.



# DANGER

Danger to life due to electric shock caused by residual charge of the DC-link capacitors

Due to the DC link capacitors of the inverter, a hazardous voltage is present in the DC link for up to 30 minutes after the power supply has been switched off.

Touching live components results in death or severe injury.

Do not touch the Voltage Protection Module as long as it is under voltage (live).



# /!\WARNING

Danger of death due to electric shock for an excessively high motor speed while the VPM is being ramped up

If the motor is operated with a speed higher than the field weakening threshold speed while the Voltage Protection Module is ramping up (see the technical data), the protection function of the VPM is inactive during this phase. As a consequence, high voltages can be injected into the DC link.

Touching live components results in death or severe injury.

 Only operate the motor below the field weakening threshold speed while the VPM is ramping up.



# / WARNING

Danger to life due to electric shock if the insulation voltage is exceeded

An excessively high voltage will damage the insulation resulting in death or severe injury.

- Do not connect any motors whose electromotive force (EMF) exceeds the permissible value at the highest speed used.
- Route the cables so that they are protected to rule out any damage.



# / WARNING

### Danger to life through electric shock when using third-party motors

VPM can be used with third-party motors. If, when using third-party motors, the VPM does not limit the DC link voltage, this can result in death or severe injury.

- Please observe the following when using third-party motors:
  - Carry out a risk analysis.
  - Ensure that the third-party motors correspond to the electrical properties of the specified Siemens components.
  - Check the correct functioning of the VPM.

# / WARNING

### Danger to life when the drive automatically starts up in an uncontrolled fashion

If a drive inadvertently starts, this can result in accidents and possibly death.

 Take the appropriate measures to prevent the drive automatically starting up in an uncontrolled fashion.

### NOTICE

#### Damage when using motors that are not short-circuit proof

Using motors that are not short-circuit proof in conjunction with a Voltage Protection Module can result in their destruction.

Only use motors that are short-circuit proof.

# / WARNING

# Danger of fire through overheating due to insufficient ventilation clearances

Insufficient ventilation clearances can result in overheating with danger to persons as a result of smoke and fire. Further, increased failures can occur and the service life of components shortened.

Maintain 200 mm ventilation clearances above and below the component.

### **NOTICE**

#### Damage to devices as a result of incorrect connecting cables

Using incorrect connecting cables for Voltage Protection Modules can damage the connected components.

• Use shielded MOTION-CONNECT 800PLUS motor cables, type 6FX8.

# 5.3 Interfaces

# 5.3.1 Overview




Figure 5-1 Interface overview, Voltage Protection Module VPM200 Dynamic (without cover)

### Note

The housing is closed during operation to ensure the electrical terminals are covered.




Figure 5-2 VPM 200 Dynamik connection points

Table 5- 2 Short designations

Short designation	Explanation	
K <sub>1</sub> , K <sub>2</sub>	Cable 1 or 2 from the HF Choke Module	
U <sub>1</sub> , U <sub>2</sub> , U <sub>3</sub> , U <sub>4</sub>	Connection bolts at the busbar U	
V <sub>1</sub> , V <sub>2</sub>	Connection bolts at the busbar V	
W <sub>1</sub> , W <sub>2</sub> , W <sub>3</sub> , W <sub>4</sub>	Connection bolts at the busbar W	
PE <sub>1</sub> , PE <sub>2</sub> , PE <sub>3</sub> , PE <sub>4</sub>	Connection bolts at the busbar PE	
U	Busbar U in the VPM	
V	Busbar V in the VPM	
W	Busbar W in the VPM	

# 5.3.2 X3 signaling contact

Signaling interface X3 on the Voltage Protection Module is wired to a digital input (DI) on the Control Unit, which controls this spindle. If an armature short-circuit occurs, the pulses of the axis involved must remain inhibited. To do this, the connected digital input is interconnected to control bit OFF2 (pulse inhibit) (see SINAMICS S120/S150 List Manual). The signaling interface is operated with +24 V.

Table 5-3 X3 signaling contact

Terminal	Designation	Technical data
1	Operating message for Control Unit	Cable shield and VPM housing are connected via a cable.
2	Operating voltage +24 V (from external source)	Isolated contact,     current carrying capacity: 30 V DC at 0.1 A

Type: WAGO spring-loaded terminal, type 226-111

Max. connectable cross-section: 1.5 mm<sup>2</sup>

shielded cable

Cable entry: Ø max. 9 mm

- Screwed joint: 1 x M16, e.g. from the Pflitsch company, article designation: UNI DICHT EMV 2165211S05
- Locknut M16: GM216PA

### Operating message via signaling contact X3

After the VPM trips or a temperature sensor responds, signaling contact X3 opens and interrupts the inverter pulse enable.

The X3 signal contact automatically closes after t > 120 s, or after the temperature switch has been reset.

Figure 5-3 Signaling contact X3 of the Voltage Protection Module

# / WARNING

#### Danger to life when the drive automatically starts up in an uncontrolled fashion

An uncontrolled automatic start of the drive can result in death or severe injury.

 Take measures to prevent the drive starting automatically in an uncontrolled fashion, as signal contact X3 restores the pulse enable after 2 minutes.

# 5.3.3 Connection busbars U, V, W, PE

As far as the power connections to the HF Choke Module are concerned, cables are routed through the cable entry of the Voltage Protection Module and attached to the connection bars inside the unit.

Table 5-4 Connections U, V, W, and PE

	VPM 200 Dynamik	
Connection bolt	M8 x 14 <sup>1)</sup>	
Cable lug	Tubular cable lug M8, 90° angled	
Cable cross section	25, 35, 50 mm <sup>2</sup>	
Tightening torque	25 Nm	
Cable entry	For cables with Ø40 mm max.	
Gland <sup>2)</sup>	4 x M50, e.g. from the Pflitsch company, article designation: UNI DICHT EMV 250584117 Locknut M50: GM250PA	


<sup>&</sup>lt;sup>1)</sup> There are 4 connection points for phases U, W and PE - and there are 2 connection points for phase V.

#### Note

Power cables with cross-sections of > 50 mm<sup>2</sup> between the HF Choke Module and the Voltage Protection Module are implemented using 2 parallel cables.

<sup>2)</sup> The glands must be separately ordered.

#### Connection example 5.4



- 1) Cable shield is electrically connected to the cable gland 2) Connection using angled cable lugs

Figure 5-4 Connection example for a shared power cable at the VPM 200 Dynamik

# Cable lengths

The maximum length of the power cable between the HF Choke Module and the Voltage Protection Module is 3 m. It must not include any switching elements.

The length of the signal cable must not exceed 10 m.

# 5.5 Dimension drawing




Figure 5-5 Dimension drawing of the Voltage Protection Module VPM 200 Dynamik, all data in mm (inches)

# 5.6 Installation

The Voltage Protection Module is installed in the control cabinet close to the HF Choke Module.




Figure 5-6 Mounting dimensions for a Voltage Protection Module VPM 200 Dynamik

# 5.7 Electrical connection



# /!\DANGER

### Danger of death due to electric shock when live parts are touched

Death or serious injury can result when live parts are touched.

- Bring the system into a no-voltage condition by opening the main switch.
- Take measures to prevent reconnection of the energy sources.

#### Note

It is only permissible to open the enclosure cover to electrically connect the Voltage Protection Module.

Various preparatory work is required to connect the Voltage Protection Module to the HF Choke Module. Cable cross-sections are determined by the rated motor power and can be up to  $2 \times 50 \text{ mm}^2$  for each conductor.

### Prepare the Voltage Protection Module to install cables

- 1. Loosen the 4 screws on the cover of the housing, so that the cover can be shifted in the cutouts.
- 2. Slide the enclosure cover to the widest part of the cutout and remove the cover.
- 3. Secure the cable glands for the signal cable and the power cables to the enclosure cable entries of the Voltage Protection Module.
- 4. Remove 300 mm of the power cable sheath (insulation) to expose the shield.
- 5. Strip the ends of the individual cores and attach the cable lugs.
- 6. Attach the signal cable to X3 and secure the cable with cable ties inside the Voltage Protection Module.

# 5.7.1 Connecting signaling contact X3

Signaling contact X3 must be wired before the power cables are connected.




Figure 5-7 Connecting terminal X3 of the Voltage Protection Module

### Note

Signaling contact X3 on the Voltage Protection Module is routed via a bistable relay. The relay may shift to the other switching state if subjected to excessive movement during transportation and installation. This may prevent the system from starting.

### **NOTICE**

### Damage when switching on the inverter as a result of a short circuit

After it has responded, the Voltage Protection Module generates a short-circuit as long as the motor is rotating. If the inverter is switched on, it can be damaged as a result of the short-circuit.

 Only switch on the inverter again once the motor has come to a complete standstill. The fact that signaling contact X3 has closed again does not prove this conclusively!

### Cause and rectification of faults

Additional information about the cause of faults and how to rectify them is provided in the following document in the "Installation" section:

Operating Instructions for Voltage Protection Module VPM 200 Dynamik, Article No.: A5E00302261B

# 5.8 Technical data

Table 5- 5 Technical data, VPM 200 Dynamik

6SN1113-1AA00-1KCx		
Type of voltage		3-phase pulsed AC voltage, motor EMF
Ramp-up time for VPM	s	1 (from pulse enable)
Normal range of the DC link voltage: Lower limit Upper limit	V <sub>DC</sub>	490 795
Operating range for VPM	V	830 2000 (peak value)
Motor EMF	kV <sub>rms</sub>	< 1.4
Time range: 0 10 ms 10 500 ms 500 ms 2 min > 2 min	A A A	Maximum permissible short-circuit current: 2000 600 200 0
Max. permissible short-circuit time	s	120
Protection class according to EN 61140		I
Protective separation		Between the signaling contact and motor cables U, V, W acc. to UL 508C
Degree of protection to EN 60529		IP20
Permitted humidity	%	< 90
Humidity classification according to EN 60721-3-3		Cl. 3K5, condensation and icing excluded Low air temperature 0 °C
Permissible ambient temperature, min. / max.	°C	0 / 55
Cooling method		Air-cooled, free convection
Weight	kg	approx. 13
Dimensions (W x H x D)	mm	300 x 250 x 260

5.8 Technical data

Braking Modules 6

# 6.1 Braking Module Booksize

# 6.1.1 Description

The Braking Module Booksize is always used together with an external braking resistor. It has the following tasks:

- Specific stop of the drives in the event of a line failure (e.g. emergency retraction or EMERGENCY OFF category 1).
- Limit the DC link voltage for brief periods of generator operation (e.g. if the regenerative feedback capability of the Line Module is deactivated or is not adequately dimensioned).

The Braking Module includes the necessary power electronics and control. When the Braking Module is in operation, the power which is fed back into the DC link is dissipated via an external braking resistor.

## **External braking resistors**

Braking resistors without thermostatic switch 6SN1113-1AA00-0DA0 ( $P_N$  = 0.3 kW) and 6SL3100-1BE31-0AA0 ( $P_N$  = 1.5 kW) can be operated at the Braking Module Booksize. The cable lengths between the Braking Module and braking resistor is limited to a maximum of 10 m.

The scope of delivery of the braking resistor 6SN1113-1AA00-0DA0 includes a shielded connection cable (3 m, 3 x 1.5 mm²).

#### 6.1 Braking Module Booksize

# Rapid discharge

Furthermore, the Braking Module Booksize can used with a braking resistor to quickly discharge the DC link capacitors The DC link is discharged in a controlled manner via the braking resistor once the infeed unit has been switched off and the line-up has been disconnected from the line supply (e.g. via the main switch or line contactor). The function can be activated via a digital input on the Braking Module. A quick discharge makes sense, for example, when maintenance tasks are to be performed at the Motor Module and/or motor installation (reduction of the discharge time).



# /!\warning

### Danger to life when live parts are touched after rapid discharge

On completion of quick discharge, a voltage of 30 V is still present at the DC link. If the fast discharge is interrupted before it has been completed, then this voltage can be more than 60 V. Touching live components can result in death or severe injury.

Check the DC link to ensure that it is in a no voltage state before starting any work.

#### **NOTICE**

### Damage to the Motor Module or connected motors for a fast discharge

For a fast discharge, the Motor Module or the connected motors can be damaged.

- For a rapid discharge, fully disconnect the drive system from the line supply.
- The motors must be at a standstill.

### Monitoring functions

- Automatic detection of braking resistors and braking power monitoring
- I2t monitoring of the braking resistors.
- Temperature monitoring of the Braking Module
- · Short circuit and overload detection
- · Ground fault detection

# 6.1.2 Safety instructions for Braking Modules Booksize

# / WARNING

# Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

If the fundamental safety instructions and remaining risks in Chapter 1 (Page 17) are not observed, accidents involving severe injuries or death may occur.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account residual risks.

# / WARNING

#### Fire hazard due to overheating because of inadequate ventilation clearances

Inadequate ventilation clearances can cause overheating with a risk for personnel due to smoke and fire. This can also result in increased failure rates and a shorter service life of the components.

Maintain the 80 mm clearances above and below the components.

#### NOTICE

### Device failure as a result of unshielded or incorrectly routed cables to braking resistors

Unshielded or incorrectly routed cables to braking resistors can result in interference being coupled into the signal processing electronics from the power side. This can result in significant disturbance of all signals (fault messages) up to failure of individual components (destruction of the devices).

Only use shielded cables for cables to braking resistors.

### **NOTICE**

### Danger to life through the use of non-approved braking resistors

Braking resistors can be damaged when using braking resistors other than those specified in this Manual.

· Only use braking resistors approved by Siemens.

# 6.1.3 Interface description

### 6.1.3.1 Overview




Figure 6-1 Interface overview, Braking Module Booksize

# 6.1.3.2 X1 braking resistor connection

Table 6- 1 X1 braking resistor connection

	Terminal	Designation	Technical data
	1	Braking resistor connection R1	Continuously short-circuit proof
R1 R2	2	Braking resistor connection R2	

Type: Screw terminal 4 (Page 172)

Max. cross-section that can be connected: 4 mm<sup>2</sup>

Table 6-2 Braking resistors without a thermostatic switch for Braking Modules

Braking resistor	R in Ω	P <sub>N</sub> in kW	P <sub>max</sub> in kW
6SN1113-1AA00-0DA0	17	0,3	25
6SL3100-1BE31-0AA0	5,7	1,5	100

For detailed technical information on the braking resistors, see the section entitled Braking resistors (Page 117).

### 6.1.3.3 X21 digital inputs/outputs

Table 6-3 X21 digital inputs/outputs

	Terminal	Designation <sup>1)</sup>	Technical data
1 2	1	DI low: Enable Braking Module DI high: inhibit/acknowledge Edge change, high → low: fault acknowledgement	Voltage: -3 +30 V Typical current drain: 10 mA at 24 V DC Level (incl. ripple)
3 4 5	DI low: braking resistor, not controlled manually DI high: Braking resistor controlled manually		High level: 15 30 V Low level: -3 +5 V
<u> </u>		If X21.1 and X21.2 are activated simultaneously, the Braking Module inhibit has priority.	
	3	DO high: no prewarning DO low: Prewarning, disconnection imminent	Max. load current per output: 100 mA Continuously short-circuit proof
	4	DO high: ready for operation, no fault DO low: Fault	Voltage: 24 V DC
	5	Ground	
	6		

Type: Screw terminal 1 (Page 172)

Max. cross-section that can be connected 1.5 mm<sup>2</sup>:

### Terminal X21.1 - inhibit/acknowledge

Applying a high signal to terminal X21.1 inhibits the Braking Module. Fault messages that are available are acknowledged with a falling edge.

#### Terminal X21.3 - prewarning

When a prewarning is sent, disconnection of the braking module is imminent. This may be due to the following causes:

- The temperature of the Braking Module is 80 % of the maximum value.
- 80 % of the maximum switch on duration of the braking resistor has been reached (I<sup>2</sup>t monitoring).
- 80 % of the maximum braking energy of the braking resistor has been reached.
- An incorrect braking resistor is connected (only braking resistors approved by Siemens for this component are automatically identified).

### Terminal X21.4 - fault

The fault can have the following causes:

- Electronics power supply is missing or outside permissible tolerance range
- Enable missing (input terminal)
- Overtemperature

<sup>1)</sup> DI: digital input; DO: digital output; M: Electronics ground

The "fast discharge function" is used for discharging the capacitors in the DC link after the line supply has been interrupted. It may only be used a maximum of once or twice per week.

- Overcurrent trip
- I2t monitoring has responded.
- Ground fault/short circuit

In the event of an overtemperature, the fault can only be acknowledged with X21.1 = high after a cooling-down time.



# / WARNING

### Danger to life as a result of a hazardous voltage at terminals X21

Hazardous voltages can be present at terminals X21 in the case of a fault. Touching live components can result in death or severe injury.

• Only connect protective extra low voltages at terminals X21.

# 6.1.4 Connection example




Figure 6-2 Connection example of a Braking Module Booksize

Information on how to parameterize the digital inputs or digital outputs, see the SINAMICS S120/S150 List Manual.

# 6.1 Braking Module Booksize

# 6.1.5 Meaning of the LEDs

Table 6-4 Meaning of the LEDs on the Braking Module Booksize

LED	Color	Status	Description, cause	Remedy
READY	-	Off	The electronics power supply is missing or outside the permissible tolerance range.	_
			The component is deactivated via terminal.	
	Green	Continuous light	The component is ready for operation.	_
	Red	Continuous light	Enable missing (input terminal) Overtemperature Overcurrent trip I²t monitoring activated Ground fault/short circuit  Note: In the event of an overtemperature, the error cannot be acknowledged until a cooling time has elapsed.	Troubleshoot the fault using the output terminals and acknowledge it using the input terminal.
DC LINK	-	Off	Only braking resistors approved by Siemens for this component are identified automatically.  The component is not active.	-
	Green	Flashing light	The component is active (DC link is being discharged via the braking resistor).	_

# 6.1.6 Dimension drawing





Figure 6-3 Dimension drawing of Braking Module, all dimensions in mm and (inches)

# 6.1.7 Installation



- ① Delivery condition with spacer mounting depth for drive line-up in booksize format with internal air cooling
- 2 Spacer removed mounting depth for drive line-up in booksize format with external air cooling

Figure 6-4 Methods of installing Braking Modules with/without spacer elements

# 6.1.8 Technical data

### 6.1.8.1 Technical data

Table 6-5 Technical data

6SL3100-1AE31-0ABx		
DC link voltage	$V_{DC}$	510 720
DC link capacitance	μF	110
ON threshold	V	770
Electronics power supply	V <sub>DC</sub>	24 (20.4 28.8)
Electronics current consumption (at 24 V DC)	ADC	0.5
Current carrying capacity DC link busbars 24 V busbars	A <sub>DC</sub>	100 20
Braking power Max. Continuous braking power	kW kW	100 1.5
Power loss	W	20
Cooling method		Natural convection
Weight	kg	4.1

### 6.1.8.2 Characteristic curves

# Duty cycle for braking resistors without a thermostatic switch




Figure 6-5 Duty cycle for braking resistors without a thermostatic switch

T [s] time period of braking duty cycle

A [s] load duration

P<sub>N</sub> [kW] rated power (continuous power) of the braking resistor

P<sub>max</sub> [kW] peak power of braking resistor (6 x P<sub>N</sub>)

#### 6.1 Braking Module Booksize

Table 6- 6 Duty cycles

	6SN1113-1AA00-0DA0		6SL3100-1BE31-0AAx	
	Short duty cycle Long duty cycle S		Short duty cycle	Long duty cycle
A [s]	0.1	0.4	1	2
T [s]	11.5	210	68	460

#### The following applies when connecting Braking Modules in parallel:

 $P_{N \text{ total}} = 0.9 \text{ x total } P_{N} \text{ of single devices}$ 

 $P_{\text{max total}}$  = total  $P_{\text{max}}$  of single devices

# 6.1.9 Configuration instructions

### DC link capacitance

To operate Braking Modules, a minimum capacitance of 440  $\mu F$  is required in the DC link for each Braking Module.

The capacitance of the Braking Module of 110 µF is included in the total capacitance value.

#### Note

Only the components that are connected to each other via the DC link busbar can be included in the total capacitance.

#### DC link cable

In a two-row or distributed drive line-up, the DC links are connected to each other via a DC link cable. When using a Braking Module in the drive line-up, this cable must not be longer than 10 m. The DC link cable must be twisted and have a minimum cross-section of at least 10 mm<sup>2</sup>.

#### Parallel connection

The Braking Module Booksize Compact 6SL3400-1AE31-0AAx is recommended for the parallel connection of Braking Modules.

Parallel connection of the Braking Module 6SL3100-1AE31-0AAx should be avoided as power distribution between the modules is not guaranteed.

#### Note

When Braking Modules are connected in parallel, the DC link capacitance specified above must be available for each Braking Module.

# 6.2 Braking Module Booksize Compact

### 6.2.1 Description

The Braking Module Booksize Compact is always used together with a braking resistor. It has the following tasks:

- Controlled stop of the drives in the event of a power failure (e.g. emergency retraction or EMERGENCY OFF Category 1).
- Limit the DC link voltage for brief generator operation, e.g. if the energy recovery capability of the Line Module is deactivated or is not adequately dimensioned.

The Braking Module includes the necessary power electronics and control. When the module is in operation, the power which is fed back into the DC link is dissipated via an external braking resistor.

The Braking Module can be operated on 200 V or 400 V line supply systems; the 4-pin DIP switch on the top of the module is used to select which one applies in each case. The factory setting is 400 V.

When spacers (6SL3462-1CC00-0AA0) are used, the Braking Module Booksize Compact can be integrated into a drive line-up in booksize format with internal air cooling.

# **External braking resistors**

Braking resistors can be operated with and without thermostatic switch at the Braking Module Booksize Compact. The DIP switch sets the type of braking resistor being used in each case. The factory setting is "braking resistor with a thermostatic switch".

The cable length between the Braking Module and the braking resistor is limited to 10 m.

### Rapid discharge

Furthermore, the Braking Module Booksize Compact can be used with a braking resistor to quickly discharge the DC link. The DC link is discharged in a controlled manner via the braking resistor once the infeed unit has been switched off and the line-up has been disconnected from the line supply (e.g. via the main switch or line contactor). The function can be activated via a digital input on the Braking Module. A quick discharge makes sense, for example, when maintenance tasks are to be performed at the Motor Module and/or motor installation (reduction of the discharge time).



# /!\WARNING

#### Danger to life when live parts are touched after rapid discharge

On completion of quick discharge, a voltage of 30 V is still present at the DC link. If the fast discharge is interrupted before it has been completed, then this voltage can be more than 60 V. Touching live components can result in death or severe injury.

Check the DC link to ensure that it is in a no voltage state before starting any work.

#### **NOTICE**

#### Damage to the Motor Module or connected motors for a fast discharge

For a fast discharge, the Motor Module or the connected motors can be damaged.

- For a rapid discharge, fully disconnect the drive system from the line supply.
- The motors must be at a standstill.

### Cooling methods

The Braking Module Booksize Compact can be operated with the following cooling methods:

- Internal air cooling
- Cold plate cooling

The required cooling method is set using the DIP switch The factory setting is "internal air cooling".

### Internal fan

When the Braking Module is being used with internal air cooling, the internal fan starts up immediately and is subsequently controlled by the temperature.

If the DIP switch is set to cold plate cooling by mistake, the fan will still start up when a certain temperature threshold is reached, in order to prevent the Braking Module shutting down due to overtemperature. If this threshold is exceeded, an alarm is issued via the digital output "Prewarning". This ensures that an emergency stop can be performed if necessary.

### **Monitoring functions**

- Automatic detection of braking resistors without thermostatic switch and corresponding braking power monitoring (only if the "Braking resistor without thermostatic switch" setting is used)
- I2t monitoring of the Braking Module
- Temperature monitoring of the Braking Module
- Temperature monitoring of the connected braking resistor with thermostatic switch (only for setting "Braking resistor with thermostatic switch")
- Short-circuit and overload detection (for all braking resistors)
- Ground fault detection (for all braking resistors)

### Parallel operation

Several Braking Modules Booksize Compact can be connected in parallel to increase the braking power. In this case, the braking energy is divided between the modules. Formulas for calculating the parallel connection are given in Chapter Notes on configuration (Page 116).

# 6.2.2 Safety instructions for Braking Modules Booksize Compact

# **⚠** WARNING

# Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

If the fundamental safety instructions and remaining risks in Chapter 1 (Page 17) are not observed, accidents involving severe injuries or death may occur.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account residual risks.

# / WARNING

#### Fire hazard due to overheating because of inadequate ventilation clearances

Inadequate ventilation clearances can cause overheating with a risk for personnel due to smoke and fire. This can also result in increased failure rates and a shorter service life of the components.

Maintain the 80 mm clearances above and below the components.

#### NOTICE

# Device failure as a result of unshielded or incorrectly routed cables to braking resistors

Unshielded or incorrectly routed cables to braking resistors can result in interference being coupled into the signal processing electronics from the power side. This can result in significant disturbance of all signals (fault messages) up to failure of individual components (destruction of the devices).

Only use shielded cables for cables to braking resistors.

### **NOTICE**

### Danger to life through the use of non-approved braking resistors

Braking resistors can be damaged when using braking resistors other than those specified in this Manual.

• Only use braking resistors approved by Siemens.

# 6.2.3 Interface description

### 6.2.3.1 Overview




Figure 6-6 Interface overview, Braking Module Booksize Compact

# 6.2.3.2 X1 braking resistor connection

Table 6-7 X1 braking resistor connection

Terminal	Designation	Technical data
1	Braking resistor connection R1	Continuously short-circuit proof
2	Not assigned	
 3	Braking resistor connection R2	

Type: Screw terminal 5 (Page 172)

Max. cross-section that can be connected: 6 mm<sup>2</sup>

### Braking resistors without a thermostatic switch

The Braking Module Booksize Compact is only designed for operation with the braking resistors listed below.

Table 6-8 Braking resistors without a thermostatic switch

Braking resistor	RinΩ	P <sub>N</sub> in kW	P <sub>max</sub> in kW
6SN1113-1AA00-0DA0	17	0,3	25
6SL3100-1BE31-0AA0	5,7	1,5	100

### Braking resistors with a thermostatic switch

The Braking Module Booksize Compact is only designed for operation with the braking resistors listed below.

Table 6-9 Braking resistors with a thermostatic switch

Braking resistor	RinΩ	P <sub>N</sub> in kW	P <sub>20</sub> in kW	P <sub>max</sub> in kW
6SE7018-0ES87-2DC0	80	1,25	5	7,5
6SE7021-6ES87-2DC0	40	2,5	10	15
6SE7023-2ES87-2DC0	20	5	20	30

For detailed technical information on the braking resistors, see Chapter Braking resistors (Page 117).

### 6.2.3.3 X21 digital inputs/outputs

Table 6- 10 X21 digital inputs/outputs

1 2 3 4	DI low: Enable Braking Module DI high: inhibit/acknowledge Edge change, high → low: fault acknowledgement DI low: braking resistor, not controlled manually DI high: Braking resistor controlled manually (quick	Voltage: -3 +30 V Typical current drain: 10 mA at 24 V DC Level (incl. ripple) High level: 15 30 V	
ω 2	DI low: braking resistor, not controlled manually DI high: Braking resistor controlled manually (quick	Level (incl. ripple)	
	discharge) <sup>2)</sup>	Low level: -3 +5 V	
5 6	If X21.1 and X21.2 are activated simultaneously, the Braking Module inhibit has priority.		
3	DO high: no prewarning DO low: Prewarning:	Max. load current per output: 100 mA Continuously short-circuit proof	
4	DO high: ready for operation, no fault DO low: Fault	Voltage: 24 V DC	
5	Ground		
6			

Max. cross-section that can be connected 1.5 mm<sup>2</sup>:

### Terminal X21.1 - inhibit/acknowledge

Applying a high signal to terminal X21.1 inhibits the Braking Module. Fault messages that are available are acknowledged with a falling edge.

#### Terminal X21.3 - prewarning

When a prewarning is sent, disconnection of the braking module is imminent. This may be due to the following causes:

- The temperature switch braking resistor has triggered (only if the "Braking resistor with thermostatic switch" setting is used)
- The temperature of the Braking Module is 80 % of the maximum value.
- The I2t counter of the Braking Module has reached 80 % of the maximum value.
- The braking resistor has reached 80 % of the maximum permissible braking energy (only for setting "Braking resistor without thermostatic switch").
- An incorrect braking resistor is connected (only if the "braking resistor without a thermostatic switch" setting is used).

<sup>1)</sup> DI: digital input; DO: digital output; M: Electronics ground

<sup>&</sup>lt;sup>2)</sup> The "fast discharge function" is used for discharging the capacitors in the DC link after the line supply has been interrupted.

### 6.2 Braking Module Booksize Compact

#### Terminal X21.4 - fault

In the event of an overtemperature fault, I<sup>2</sup>t monitoring, or braking power monitoring, the fault will be acknowledged automatically after a cooling phase. Manual acknowledgment is not necessary!



# / WARNING

### Danger to life as a result of a hazardous voltage at terminals X21

Hazardous voltages can be present at terminals X21 in the case of a fault. Touching live components can result in death or severe injury.

Only connect protective extra low voltages at terminals X21.

# 6.2.3.4 X22 digital output/temperature switch

Table 6- 11 X22 digital output/temperature switch, braking resistor

	Terminal	Designation <sup>1)</sup>	Technical data
	1	+ Temp	Temperature switch of the braking
	2	- Temp	resistor
3 4 5 6	3	Reserved	Not assigned!
	4	Reserved	
	5	DO high: 200 V supply system is selected DO low: 400 V supply system is selected	
	6	Reserved	Not assigned!

Type: Screw terminal 1 (Page 172)

Max. cross-section that can be connected 1.5 mm<sup>2</sup>:

<sup>1)</sup> DO: digital output

### 6.2.3.5 DIP switch

The 4-pin DIP switch is located at the top of the Braking Module and sets the braking resistor being used, the cooling method, and the line voltage.

Make the required settings before the Braking Module is mounted in the control cabinet; once the module is mounted, the DIP switch can no longer be accessed from the front.

Table 6- 12 DIP switch for Braking Module Booksize Compact

	Switch	Switch position	Function	Factory setting
n.a. P   P   NT   400V   P   ON < P   ON < P   P   P   P   P   P   P   P   P   P	1	ON	Braking resistor without a thermostatic switch	OFF
		OFF	Braking resistor with a thermostatic switch	
	2	ON	Cold plate cooling	OFF
		OFF	Internal air cooling	
	3	ON	200 V line voltage	OFF
		OFF	400 V line voltage	
	4	ON	Reserved	OFF
		OFF		

### Note

### Terminal assignment for "Braking resistor without a thermostatic switch" mode

For "braking resistor without a thermostatic switch" mode (switch 1 = ON), terminals X22.1 and X22.2 must not be assigned for the Braking Module to work.

# 6.2.4 Connection examples

Braking resistor without thermostatic switch connected to a Braking Module Booksize Compact




Figure 6-7 Connection example for Braking Module Booksize Compact and braking resistor without a thermostatic switch

### Note

The digital inputs DI are isolated and are referenced to M\_DI (X21.5 and X21.6). The reference point of the digital outputs DO is the ground GND of the 24 V supply.

It is not permissible that the connections for the temperature switches (X22.1 and X22.2) are used/assigned for "braking resistor without a thermostatic switch" operation. Otherwise, malfunctions occur.

### Braking resistor with thermostatic switch connected to a Braking Module Booksize Compact




Figure 6-8 Connection example for Braking Module Booksize Compact and braking resistor with a thermostatic switch

### Note

The digital inputs (DI) are isolated and are referenced to M\_DI (X21.5 and X21.6). The reference point of the digital outputs (DO) is the ground GND of the 24 V supply.

Information on how to parameterize the digital inputs or digital outputs, see the SINAMICS S120/S150 List Manual.

## 6.2.5 Meaning of LEDs on the Braking Module Booksize Compact

Table 6- 13 Meaning of LEDs on the Braking Module Booksize Compact

LED	Color	Status	Description	Remedy
READY	-	Off	The electronics power supply is missing or outside the permissible tolerance range.	Check the electronics power supply.
	Green	Continuous light	The component is ready for operation.	-
	Red	Continuous light	Enable missing (input terminal) Overtemperature of IGBT/braking resistor Overcurrent trip I²t monitoring activated Braking power monitoring triggered Ground fault/short circuit	Troubleshoot the fault using the output terminals and acknowledge it using the input terminal.
			Comment: In the event of overtemperature, I <sup>2</sup> t monitoring or braking power monitoring, the fault will be acknowledged automatically after a cooling down phase. Manual acknowledgment is not possible.	
DC LINK	-	Off	The DC link voltage is not available, the electronics power supply is missing or is outside the permissible tolerance range. The component is not active.	
	Orange	Continuous light	The DC link voltage is present.	-
	Orange	Flashing light	The component is active. The DC link is being discharged via the braking resistor.	-

# 6.2.6 Dimension drawing





Figure 6-9 Dimension drawing of Braking Module Booksize Compact, all dimensions in mm and (inches)

## 6.2.7 Mounting

### Mounting a Braking Module Booksize Compact with internal air cooling




- Mounting wall
- 2 M6 x 16 screw Hex combination screw or hex screw with spring washer and plain washer

Figure 6-10 Mounting a Braking Module Booksize Compact with internal air cooling

## Tightening torques:

- 1. Firstly, tighten the nuts by hand. Tightening torque: 0.5 Nm
- 2. Then tighten the nuts. Tightening torque: 6 Nm

### Mounting a Braking Module Booksize Compact with cold plate



- 1 Threaded bolts M6
- ② Cold plate (air or liquid cooling)
- 3 Heat-conducting foil
- 4 Washer
- Spring washer
- 6 M6 nut

Figure 6-11 Mounting a Braking Module Booksize Compact with cold plate

## Tightening torques:

- 1. Firstly, tighten the nuts by hand. Tightening torque: 0.5 Nm
- 2. Then tighten the nuts.
  Tightening torque. 10 Nm

#### 6.2 Braking Module Booksize Compact

### Special points to note in relation to mounting on a cold plate

To improve heat transfer, a heat-conducting medium must be used. Special spherical-indented heat-conducting foil must be used for this purpose. Every Braking Module Booksize Compact is supplied with heat-conducting foil cut to the right size. Note the mounting position of the heat-conducting foil.

#### Note

- Also replace the heat-conducting foil when replacing a component.
- Only use heat-conducting foil released or supplied by Siemens.

	Article No.
Heat-conducting foil, 50 mm	6SL3162-6FB01-0AA0

## 6.2.8 Technical data

## 6.2.8.1 Technical specifications

Table 6- 14 Technical data

6SL3400-1AE31-0AAx			
Line supply		200 V	400 V
DC link voltage	V <sub>DC</sub>	250 360	510 720
ON threshold	V <sub>DC</sub>	400	760
Braking power Maximum <sup>1)</sup> Continuous braking power	kW kW	50 2.5	100 5
Electronics power supply	V <sub>DC</sub>	24 (20.4	28.8)
Electronics current consumption (at DC 24 V) Standby mode	A <sub>DC</sub>	0.	2 4
Current carrying capacity: DC link busbars 24 V busbar	Adc Adc	10	00 0
Power loss Standby operation	W W	5 2	
Switching frequency	Hz	20	00
Cooling methods		Internal a Cold plat	
Max. Ambient temperature	° C	5	5
Weight	kg	2.	.7

<sup>1)</sup> At the upper switch-on threshold

### 6.2.8.2 Characteristic curves

### Duty cycle for braking resistors without a thermostatic switch




Figure 6-12 Duty cycle for braking resistors without a thermostatic switch

T [s] time period of braking duty cycle

A [s] load duration

P<sub>N</sub> [kW] rated power (continuous power) of the braking resistor

P<sub>max</sub> [kW] peak power of braking resistor (6 x P<sub>N</sub>)

Table 6- 15 Duty cycles

	6SN1113-1	AA00-0DA0	6SL3100-1BE31-0AAx		
	Short duty cycle Long duty cycle S		Short duty cycle	Long duty cycle	
A [s]	0.1	0.4	1	2	
T [s]	11.5	46	68	136	

## Duty cycles for braking resistors with a thermostatic switch




Figure 6-13 Duty cycles for braking resistors with a thermostatic switch

T [s] time period of braking duty cycle

A [s] load duration

P<sub>N</sub> [kW] rated power (continuous power) of the braking resistor

P<sub>max</sub> [kW] peak power of braking resistor (6 x P<sub>N</sub>)

4 x P<sub>N</sub> [kW] = power permitted every 90 s for 20 s

#### 6.2 Braking Module Booksize Compact

Table 6- 16 Duty cycles

	6SE7018-0ES87-2DC0		6SE7021-6ES87-2DC0		6SE7023-2ES87-2DC0	
	Duty cycle P <sub>max</sub>	Duty cycle 4 x P <sub>N</sub>	Duty cycle P <sub>max</sub>	Duty cycle 4 x P <sub>N</sub>	Duty cycle P <sub>max</sub>	Duty cycle 4 x P <sub>N</sub>
A [s]	3	20	3	20	3	20
T [s]	90	90	90	90	90	90

## 6.2.9 Configuration instructions

### DC link capacitance

When configuring the drive line-up, please note that only one Braking Module Booksize Compact may be used per complete 500  $\mu$ F DC link capacitance.

Table 6- 17 Configuration examples

DC link capacitance in μF	Max. number of Braking Modules
900	1
2400	4
9800	19

### DC link cable

In a two-row or distributed drive line-up, the DC links are connected to each other via a DC link cable. When using a Braking Module Booksize Compact in the drive line-up, this cable must not be longer than 10 m. In all cases, the DC link cable must have low impedance and a cross-section of at least 10 mm<sup>2</sup>.

### Parallel operation

During configuration of parallel operation for Braking Modules Booksize Compact, dimensioning can only take 90% of the specified braking power into account. Only the peak powers may be added without derating.

The following applies when connecting Braking Modules in parallel:

 $P_{N \text{ total}} = 0.9 \text{ x total } P_{N} \text{ of single devices}$ 

 $4 \times P_{N \text{ total}} = 0.9 \times \text{sum } (4 \times P_{N}) \text{ of single devices}$ 

 $P_{\text{max total}}$  = total  $P_{\text{max}}$  of single devices

Braking resistors

## 7.1 Description

A braking resistor is used to dissipate the excess DC link energy in generator operation. Braking resistors are connected to a Braking Module.

Resistors are available with and without thermostatic switch with various rated power levels. The thermostatic switch monitors the braking resistors for overtemperature and issues a signal at an isolated contact if the limit value is exceeded.

Braking resistor	Braking Module Booksize	Braking Module Booksize Compact					
Braking resistors without a thermostatic switch							
<b>6SN1113-1AA00-0DA0</b> Resistance: 17 $\Omega$ PN: 0.3 kW	х	x					
<b>6SL3100-1BE31-0AA0</b> Resistance: 5.7 Ω PN: 1.5 kW	х	х					
Braking resistors with a thermostatic s	witch						
<b>6SE7018-0ES87-2DC0</b> Resistance: 80 Ω PN: 1.25 kW		x					
<b>6SE7021-6ES87-2DC0</b> Resistance: 40 $\Omega$ PN: 2.5 kW		x					
<b>6SE7023-2ES87-2DC0</b> Resistance: 20 $\Omega$ PN: 5 kW		x					

### Installation

The braking resistors can be installed standing on the floor of the control cabinet or suspended. The braking resistors must be located outside the cooling airflow of the drive lineup.

Positioning the braking resistor outside the control cabinet or switchgear room enables the resulting thermal losses to be routed away. This reduces the level of air conditioning required.

7.2 Safety instructions for braking resistors

#### Connection cables

A shielded connection cable (3 m, 3 x 1.5 mm<sup>2</sup>) is supplied with braking resistor 6SN1113-1AA00-0DA0.

All other braking resistors are supplied without a connection cable. The maximum conductor cross-sections are listed in the technical data.

The maximum cable length for all braking resistors is 10 m.

## 7.2 Safety instructions for braking resistors



Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

If the fundamental safety instructions and remaining risks in Chapter 1 (Page 17) are not observed, accidents involving severe injuries or death may occur.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account residual risks.

# / WARNING

### Risk of fire due to ground fault/short-circuit

Inadequate installation of the cables to the braking resistor can result in a ground fault/short-circuit and place persons at risk as a result of the associated smoke and fire.

- Use the local installation regulations to avoid this fault.
- Protect the cables against mechanical damage.
- Also implement one of the following measures:
  - Use cables with double insulation.
  - Maintain adequate clearance, e.g. by using spacers.
  - Lay the cables in separate cable ducts or conduits.

# / WARNING

#### Risk of fire through overheating if there are insufficient ventilation clearances

Inadequate ventilation clearances can cause overheating with a risk for personnel due to smoke and fire.

Maintain a cooling clearance of 100 mm on all sides of the braking resistor

# **!**CAUTION

### Risk of burns due to high surface temperatures

The braking resistor can become very hot. You can get seriously burnt when touching the surface.

• Mount the braking resistors so that contact is not possible. If this is not possible, attach a clearly visible and understandable warning notice at hazardous positions.

# 7.3 Dimension drawings

## Braking resistors without a thermostatic switch




Figure 7-1 Dimension drawing of braking resistor 6SN1113-1AA00-0DA0 where  $P_n/P_{max} = 0.3 \text{ kW}/25 \text{ kW}$ , all dimensions in mm and (inches)

## 7.3 Dimension drawings




Figure 7-2 Dimension drawing of braking resistor 6SL3100-1BE31-0AA0 where  $P_n/P_{max}$  = 1.5 kW/100 kW, all dimensions in mm and (inches)

## Braking resistors with a thermostatic switch

Air flow (convection)

Control cabinet - roof mounting







Figure 7-3 Dimension and installation drawing (roof and wall mounting) of braking resistor 6SE7018-0ES87-2DC0 where  $P_n/P_{max} = 1.25 \text{ kW}/7.5 \text{ kW}$ , all dimensions in mm and (inches)


### 7.3 Dimension drawings





Wall mounting (electrical connection at the left!)






1, 2 (R) Power cable connection 3, 4 (T)

Temperature sensor connection

Figure 7-4 Dimension and installation drawing (roof and wall mounting) of braking resistor 6SE7021-6ES87-2DC0 where  $P_n/P_{max} = 2.5 \text{ kW}/15 \text{ kW}$ , all dimensions in mm and (inches)



- 1 Thermostatic switch T1 / T2 connection, with connection cross-section 2.5 mm<sup>2</sup>
- 2 Connection for power cable, 2 x M6 bolts

Figure 7-5 Dimension and installation drawing (floor and wall mounting) of braking resistor 6SE7023-2ES87-2DC0 where  $P_n/P_{max} = 5 \text{ kW/}30 \text{ kW}$ , all dimensions in mm and (inches)

## 7.4 Technical data

Table 7-1 Technical data for braking resistors without a thermostatic switch

	Unit	6SN1113-1AA00-0DA0	6SL3100-1BE31-0AAx
Resistance R	Ω	17	5.7
Rated power P <sub>N</sub>	kW	0.3	1.5
Peak power P <sub>max</sub>	kW	25	100
Max. Energy consumption E <sub>max</sub>	kWs	7.5	200
Power cable connection		Included in the scope of delivery; length 3 m, 3 x 1.5 mm <sup>2</sup>	Screw terminal, 4 mm <sup>2</sup>
Weight	kg	3.4	5.6
Dimensions (W x H x D)	mm	80 x 210 x 53	193 x 410 x 240
Degree of protection to EN 60529		IP54	IP20

Table 7-2 Technical data for braking resistors with a thermostatic switch

	Unit	6SE7018-0ES87- 2DC0	6SE7021-6ES87- 2DC0	6SE7023-2ES87- 2DC0
Resistance R	Ω	80	40	20
Rated power P <sub>N</sub>	kW	1.25	2.5	5
Braking power 4 x P <sub>N</sub>	kW	5	10	20
Peak power P <sub>max</sub> 1)	kW	7.5	15	30
	kWs kWs	22.5 100	45 200	90 400
Thermostatic switch connection		Screw terminal <sup>2)</sup> , 4 mm <sup>2</sup>	Screw terminal <sup>2)</sup> , 4 mm <sup>2</sup>	Screw terminal, 2.5 mm <sup>2</sup>
Power cable connection		Screw terminal <sup>3)</sup> , 4 mm <sup>2</sup>	Screw terminal <sup>3)</sup> , 4 mm <sup>2</sup>	M6 screw bolt for ring cable lug
PE connection		M5 bolt	M5 bolt	M6 bolt
Weight	kg	6	12	17
Dimensions (W x H x D)	mm	145 x 180 x 540	145 x 360 x 540	450 x 305 x 485
Degree of protection to EN 60529		IP20	IP20	IP20

<sup>1)</sup> Applies to a DC-link voltage of 760 V

<sup>&</sup>lt;sup>2)</sup> Recommended connection cross-section: 0.75 to 1.5 mm<sup>2</sup>

<sup>3)</sup> Recommended connection cross-section: 2.5 mm<sup>2</sup>

### 7.4.1 Characteristic curves

## Duty cycle for braking resistors without a thermostatic switch




Figure 7-6 Duty cycle for braking resistors without a thermostatic switch

T [s]: Period duration of braking duty cycle

A [s]: Load duration

P<sub>N</sub> [W]: Rated power (continuous power rating) of the braking resistor

P<sub>max</sub> [W]: Peak power of braking resistor (6 x P<sub>N</sub>)

Table 7-3 Duty cycles for Braking Module Booksize

	6SN1113-1	AA00-0DA0	6SL3100-1BE31-0AAx		
	Short duty cycle Long duty cycle S		Short duty cycle	Long duty cycle	
A [s]	0.1	0.4	1	2	
T [s]	11.5	210	68	460	

Table 7-4 Duty cycles for Braking Module Booksize Compact

	6SN1113-1	AA00-0DA0	6SL3100-1BE31-0AAx		
	Short duty cycle Long duty cycle S		Short duty cycle	Long duty cycle	
A [s]	0.1	0.4	1	2	
T [s]	11.5	210	68	460	

The following applies when connecting Braking Modules in parallel:

 $P_{N \text{ total}} = 0.9 \text{ x total } P_{N} \text{ of single devices}$ 

 $P_{\text{max total}}$  = total  $P_{\text{max}}$  of single devices

### 7.4 Technical data

### Duty cycles for braking resistors with a thermostatic switch




Figure 7-7 Duty cycles for braking resistors with a thermostatic switch

T [s]: Period duration of braking duty cycle

A [s]: Load duration

P<sub>N</sub> [W]: Rated power (continuous power rating) of the braking resistor

P<sub>max</sub> [W]: Peak power of braking resistor (6 x P<sub>N</sub>)

4 x P<sub>N</sub> [W] = power permitted every 90 s for 20 s

Table 7-5 Duty cycles

	6SE7018-0ES87-2DC0		6SE7021-6ES87-2DC0		6SE7023-2ES87-2DC0	
	Duty cycle P <sub>max</sub>	Duty cycle 4 x P <sub>N</sub>	Duty cycle P <sub>max</sub>	Duty cycle 4 x P <sub>N</sub>	Duty cycle P <sub>max</sub>	Duty cycle 4 x P <sub>N0</sub>
A [s]	3	20	3	20	3	20
T [s]	90	90	90	90	90	90

### The following applies when connecting Braking Modules in parallel:

 $P_{N \text{ total}} = 0.9 \text{ x total } P_{N} \text{ of single devices}$ 

 $4 \times P_{N \text{ total}} = 0.9 \times \text{sum } (4 \times P_{N}) \text{ of single devices}$ 

 $P_{max total}$  = total  $P_{max}$  of single devices

Control Supply Module (CSM)

## 8.1 Description

The Control Supply Module provides an output voltage of 24 V - 28.8 V DC. The output voltage can be adjusted using an integrated potentiometer.

In normal operation, the Control Supply Module is supplied from the line voltage. When the power fails, the module automatically changes over to supply from the DC link. This makes it possible, for example, to execute retraction movements in the event of a power failure.

The Control Supply Module has safe electrical separation between the line potential and the DC link potential. This therefore ensures that the DC link is not unintentionally charged. The Control Supply Module can therefore remain connected to the supply if the Line Module is galvanically isolated from the line supply, for example using a line contactor.

The 24 V ground of the Control Supply Module is internally grounded. The Control Supply Module is cooled using an internal fan.

Temperature and voltages are internally monitored.

#### Temperature monitoring:

In the event of an overtemperature in the Control Supply Module, a temperature advance warning is issued via a signaling contact. If the temperature falls below the limit value within the advance warning time, then the module remains operational and the signaling contact is de-energized. If the overtemperature condition persists, the module is switched off and restarted.

#### Voltage monitoring:

When the monitoring threshold (32 V) of the output voltage is exceeded for > 20 ms, the control supply module switches off and attempts a restart after 10 s. This is supplemented by a hardware-based overvoltage limiting. This prevents that more than 35 V can be output in the case of a fault.

The Control Supply Module can either be operated individually or in a parallel connection with a maximum of 10 devices. The switchover between single and parallel operation is realized in a no-current state using a DIP switch on the upper side of the module.

### Note

### Compatibility

The Control Supply Module 6SL3100-1DE22-0AA1 with extended functionality described here replaces Control Supply Module 6SL3100-1DE22-0AA0. The modules are upwards compatible (-0AA1 can be used as replacement part for -0AA0).

## 8.2 Safety instructions for Control Supply Modules

# / WARNING

Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

If the fundamental safety instructions and remaining risks in Chapter 1 (Page 17) are not observed, accidents involving severe injuries or death may occur.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account residual risks.



## DANGER

Danger to life when live parts are touched when using the control supply module

The Control Supply Module has 2 supply circuits. Death or serious injury can result when live parts are touched.

Switch off both supply circuits before you start any work.



# DANGER

Danger to life through electric shock due to the residual charge of the DC link capacitors

Due to the DC link capacitors, a hazardous voltage is present in the DC link for up to 5 minutes after the power supply has been switched off.

Contact with live parts can result in death or serious injury.

- Do not open the protective cover of the DC link until 5 minutes have elapsed.
- Measure the voltage before starting work on the DCP and DCN DC link terminals.



# DANGER

Danger to life through electric shock when the protective cover of the DC link is open

Contact with live parts can result in death or serious injury.

Only operate the components with closed protective cover.



## / WARNING

Danger to life through electric shock due to missing DC link side covers

There is a danger of an electric shock through contact when the side covers of the DC link are missing.

- Mount the side covers on the first and last component in the drive line-up.
- Order any missing side covers (Article number: 6SL3162-5AA00-0AA0).

# / WARNING

### Fire hazard due to overheating because of inadequate ventilation clearances

Inadequate ventilation clearances can cause overheating with a risk for personnel due to smoke and fire. This can also result in increased failure rates and a shorter service life of the component.

Maintaining 80 mm ventilation clearances above and below the component is essential.

#### NOTICE

### Material damage due to loose power connections

Insufficient tightening torques or vibration can result in faulty electrical connections. This can cause fire damage or malfunctions.

- Tighten all of the DC link busbar screws with the specified tightening torque (1.8 Nm, tolerance +30 %) an.
- Check the tightening torques of all power connections at regular intervals and tighten them when required. This applies in particular after transport.

#### NOTICE

### Material damage due to loose power connections when using the 24 V terminal adapter

Insufficient tightening torques or vibration can result in faulty electrical connections. This can cause fire damage or malfunctions.

- When using the 24 V terminal adapter, it must be screwed onto the Control Supply Module. Tighten the enclosed EJOT-PT K30 x 16 screw with the specified tightening torque (0.5 Nm).
- Check the tightening torques of all power connections at regular intervals and tighten them when required. This applies in particular after transport.

# 8.3 Interface description

## 8.3.1 Overview




Figure 8-1 Interface overview, Control Supply Module

### 8.3.2 X1 line connection

Table 8-1 X1 line connection

	Terminal	Technical data
WI VI UI	V1 W1	Supply voltage: 3 AC 380 V 480 V, 50 / 60 Hz  Type: Screw terminal 4 (Page 172) Max. cross-section that can be connected: 4 mm² Tightening torque: 0.5 0.6 Nm
	PE connection	M5 screw / 3 Nm at the housing

## 8.3.3 X21 signaling contact

Table 8-2 X21 signaling contact

	Terminal	Technical data
	1	Voltage: 24 V DC
	2	Max. load current: 0.5 A (ohmic load)
Type: Screw terminal 1_1 (Page 172) Max. cross-section that can be connected 1.5 mm²		

The 2-pole terminal connector for the signaling contact is included in the Completion Kit provided.


The signaling contact can be connected with a digital input (DI) on the Control Unit or other digital interface (PLC, SCADA). In parallel or redundant operation the failure of a Control Supply Module is indicated in order to initiate a service call, for example.


The signaling contact operates as an isolated NO contact. When the switch is closed, the Control Supply Module is "OK" and provides the output voltage. The switch opens in the event of a fault "Not OK" – when the overtemperature condition is still present, after a prewarning, wire breakage, short-circuit etc. The Control Supply Module is correspondingly switched off.

### 8.3 Interface description

Table 8-3 Installing the signaling contact







Signaling contact, complete with terminal connector

## 8.3.4 X24 24 V terminal adapter

Table 8- 4 X24 24 V terminal adapter

Terminal	Designation	Technical data
+	24 V power supply	Supply voltage 24 28.8 V DC
M	Ground	Electronics ground

Type: Screw terminal 5 (Page 172)

Max. cross-section that can be connected: 6 mm<sup>2</sup>

The 24 V terminal adapter is included in the scope of supply.

## 8.3.5 S1 DIP switch

Table 8-5 DIP switch S1

Terminal	Designation	Technical data
1	Changeover switch, single operation / parallel operation	Left: Single operation Right: Parallel operation
2	Dummy contact (not used)	Changing over the output characteristic

It is only permissible to changeover when in the no-voltage state.




Figure 8-2 DIP switch on the upper side of the component

When delivered, "single operation" is set. Both switches are set to the left.

## 8.4 Connection examples

### 8.4.1 General information

The Control Supply Module is connected to the line supply (3-ph. 380 V AC -10 % to 480 V AC +10 %) via interface X1 (screw terminals 0.2 to 4 mm<sup>2</sup>). This connection should preferably be made without using an isolating device (e.g. contactor).

The Control Supply Module has an internal line filter (Class A for TN systems), and the precharging circuit for the DC link inside the device is electrically isolated from the 24 V supply.

The Control Supply Module also features a current limitation function.

#### Note

If you use cables with a cross-section of 2.5 mm<sup>2</sup>, no additional protection is required on the 24 V side for the following cable types:

- · Cables of the XLPE type
- Cables of the EPR type
- Cable with a similar properties and which is thermally stable up to 90 °C

#### Note


#### Observe the connection sequence

If a selectively tripping, AC/DC-sensitive RCCB is used for the drive line-up, the Control Supply Module must always be connected to the line supply downstream of this circuit breaker. Otherwise, the residual current operated circuit breaker will trip erroneously if the direct-current component is asymmetrically drawn in certain operating states.

## 8.4.2 Single operation

Within the drive line-up, the Control Supply Module must be connected to the drive line-up via the DC link busbars as well as the 24 V busbars. The red 24 V connector from the accessories pack provided must be inserted under all circumstances. The DIP switch on the Control supply Module must be set to "single mode" The connection can be established as shown below.

The supply for other 24 V loads outside the drive line-up using additional Control Supply Modules, whose outputs are not connected in parallel, must be realized using the 24 V terminal adapter (do not insert the red 24 V connector).



- Permissible types:
   a) SIRIUS circuit breaker, 3RV 1021 1DA10, set to 3A
  - b) KTS-R-6-type branch circuit fuse (class RK1)
- 2) The line supply connection must always be available
- 3) DI/DO, controlled from the Control Unit.
- 4) No additional load permitted downstream of the line contactor!
- 5) The current carrying capacity of the DO must be observed; an output coupling device must be used if required.
- 6) Contact established via rear mounting panel or shielding buses in accordance with the EMC installation guideline

Figure 8-3 Connection example for Control Supply Module in single operation

# 8.5 Meaning of the LEDs

Table 8- 6 Meaning of the LEDs on the Control Supply Module

LED	Color	Status	Description
READY	-	Off	The electronics power supply is outside the permissible tolerance range or the temperature prewarning is active.
	Green	Continuous light	Ready The output voltage is in the tolerance range and the temperature prewarning is inactive.
DC LINK	-	Off	DC input voltage U <sub>E DC</sub> < 280 300 V Buffer operation is not possible.
	Yellow	Continuous light	DC input voltage in the range 360 380 V < U <sub>E DC</sub> < 820 V ± 3 % Buffer operation is possible
	Red	Continuous light	DC input voltage outside the tolerance range: UEDC < 360 380 V or VEDC > 820 V ± 3 %

# 8.6 Dimension drawing





Figure 8-4 Dimension Control Supply Module, all dimensions in mm and (inches)

## 8.7 Installation



- ① Delivered with spacer mounting depth for drive line-up in booksize format with internal air cooling
- ② Spacer removed mounting depth for drive line-up in booksize format with external air cooling

Figure 8-5 Methods of installing the Control Supply Module with and without spacer

The Control Supply Module can be attached to the control cabinet panel with or without spacers.

## 8.8 Technical data

## 8.8.1 Technical data

Table 8-7 Technical data

6SL3100-1DE22-0AA1	Unit	Value
Input data, AC input		
Line voltage Line frequency	V <sub>AC</sub> Hz	3 AC 380 480 ± 15 % 45 66
Rated input current Rated value (at V <sub>E rated</sub> )	A <sub>A</sub> C	≤ 2
Starting current inrush	A <sub>AC</sub>	≤ 28 at > 5 ms
Input data, DC input		
Rated input voltage	V <sub>DC</sub>	600
Input voltage range	V <sub>DC</sub>	300 882
DC link voltage (continuous input voltage)	V <sub>DC</sub>	430 800 300 430 < 1 min 800 853 < 1 min 853 882 < 10 s
Supply current (at 600 V)	A <sub>DC</sub>	1.1
Overvoltage tripping Undervoltage tripping	V <sub>DC</sub> V <sub>DC</sub>	> 882 280 ± 3 %
Output data		
Rated output voltage V <sub>A rated</sub>	$V_{DC}$	24 28.8
Rated output current I <sub>A rated</sub> 1)	ADC	20
Rated output power P <sub>A rated</sub>	W	520
Overcurrent limitation for short-circuit	ADC	approx. 23
Surge suppression	V	< 35
Current carrying capacity of the 24 V busbar	A <sub>DC</sub>	20
Residual ripple (clock frequency approx. 50 kHz)	$mV_{pp}$	< 100
Switching peaks (bandwidth 20 MHz)	$mV_{pp}$	< 200
Power loss ride-through (at 400 V AC)	ms	5
Power loss Line DC link	W	70 65
Efficiency	%	> 83
Circuit breaker (UL) Type designation: Rated current: Resulting rated short-circuit current	A	3RV1021-1DA10 2.2 3.2 (setting value 3)
SCCR at 480 V AC:	kA	100

6SL3100-1DE22-0AA1	Unit	Value	
Fuses (UL)			
Class RK1, listed JDDZ			
Rated current:	Α	6	
resulting rated short-circuit current			
SCCR at 480 V AC:	kA	200	
Cooling method		Internal air cooling	
Max. ambient temperature			
without derating	° C	≤ 40	
with derating as of 26 V output voltage	° C	> 40 55	
Weight	kg	4.8	

<sup>1)</sup> Above 40° C, a linear derating of the output current above a 26 V output voltage and higher must be observed

### 8.8.2 Characteristics

### **Derating characteristic**

For ambient temperatures > 40 °C, a linear derating for the output current must be observed as of 26 output voltage.




Figure 8-6 Current derating for ambient temperatures >40 °C as a function of the output voltage

DC link adapter

## 9.1 Description

The DC link adapter is used to directly feed the DC link voltage in the drive line-up. It is required for the High Frequency Drive if the infeed is realized via an Active Line Module in the chassis format. The supply is established at the side through the HF Damping Module. The connecting cable cross-section should be selected based on the total current required for all of the connected components. Shielded individual cores are recommended.

The connection cables must be fused accordingly.

## 9.2 Safety instructions for the DC link adapter



Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

The non-observance of the fundamental safety instructions and residual risks stated in Chapter 1 can result in accidents with severe injuries or death.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account remaining risks.



## DANGER

Danger to life through electric shock when the protective cover of the DC link is open

Touching live components results in death or severe injury.

• Only operate the components with closed protective cover.



# <u>/</u>!\DANGER

Danger to life through electric shock due to the residual charge of the DC-link capacitors

Because of the DC-link capacitors, a hazardous voltage is present for up to 5 minutes after the power supply has been switched off.

Touching live components results in death or severe injury.

- Do not open the protective cover of the DC link until 5 minutes have elapsed.
- Measure the voltage before starting work on the DCP and DCN DC-link terminals.

## / WARNING

### Risk of fire and device damage as a result of ground fault/short-circuit

The DC link connecting cables must be routed so that a ground fault or short circuit can be ruled out. A ground fault can result in fire with associated smoke.

- Comply with local installation regulations, which allow this fault to be ruled out.
- Protect the cables from mechanical damage.

In addition, apply one of the following measures:

- · Using cables with double insulation.
- Observe adequate clearances, e.g. through the use of spacers.
- Route the cables in separate cable ducts or pipes.

# / WARNING

Risk of fire due to overheating when permissible cable lengths are exceeded

Excessively long DC link cables can cause components to overheat with the associated risk of fire and smoke.

 Restrict the total length of the DC link including the connecting cables to a maximum of 10 m.

#### **NOTICE**


#### Material damage due to loose power connections

Insufficient tightening torques or vibration can result in faulty electrical connections. This can result in damage due to fire or malfunctions.

- Tighten all of the screws with the specified tightening torque.
- Check the tightening torques of all power connections at regular intervals and tighten them when required. This applies in particular after transport.

# 9.3 Interface description

## 9.3.1 Overview



.

Figure 9-1 HF Damping Module with DC link adapter

## 9.3.2 DC link connection

Table 9- 1 DC link connection

Terminal	Function	Technical data
DCP	DC link positive	Current carrying capacity: 150 A
DCN	DC link negative	connection cross-section: 35 95 mm <sup>2</sup> Stripped length: 27 mm

# 9.4 Dimension drawing





Figure 9-2 Dimension drawing of the HF Damping Module with DC link adapter, all dimensions in mm and (inches)


## 9.5 Installation

Required tools:

- Slot-head screwdriver (1 x 5.5) for releasing the protective cover
- Torx screwdriver T20 for DC link screws (Torx slot)

Table 9-2 Installation of the DC link adapter at the HF Damping Module





3. Fix the DC link adapter (1.8 Nm) using the previously removed DC link screws. Use the **right-hand** holes ①.



4. Remove the DC link side cover and close the protective cover until you hear it engage.

# DANGER

### Danger to life through electric shock when touching the DC-link busbars


Touching live components results in death or severe injury.

 Mount the busbars and clips of the DC link as well as the DC link adapter, so that after closing the DC link cover they cannot be touched.

# 9.6 Electrical connection

## 9.6.1 Preparing the cables

- 1. Prepare the DC link connecting cables as shown below.
- 2. Only use shielded cables with insulated end sleeves.



- 1 Protective braided shield folded back and fixed using shrink-on sleeve
- 2 Insulated end sleeve


Figure 9-3 Single-core and two-core DC link connecting cable with insulated end sleeves, all dimensions in mm and (inch)

Refer to the table below for dimension A:

Conductor cross- section [mm²]	Mounting location of the DC link adapter at the drive line-up	Connection	A [mm]
50 / 70 / 95	Left	DCP	70
		DCN	60
	Right	DCP	60
		DCN	70

## 9.6.2 Fixing the cables to the rear cabinet panel

- Fix the DC link connecting cables directly next to the last component at the rear control
  cabinet panel. Use the C-profile rails and the appropriate cable clamps from the Rittal
  company. The distance between the C profile rail and the lower side of the component is
  approximately 125 mm.
- 2. Appropriately insulate the cable cores at the connection location before mounting.



- Control cabinet panel
- ② DC link adapter
- 3 Cores of the DC link connecting cable
- 4 C-profile rail from Rittal company (article number 7831.570 / 7831.571)
- (5) Cable clamps for C profile rails from the Rittal company.

Figure 9-4 Fixing the DC link connecting cable to the control cabinet panel, dimensions in mm and (inch)


## 9.6.3 Cable connection and shield support

In order to simplify installing the DC link connecting cables at the DC link adapter, first fix the cables to the control cabinet panel (also see Chapter Fixing cables to the control cabinet panel (Page 147)).

### Required tools:

- Size 6 Allen key to attach the cables
- Suitable tool for hose clamps, e.g. flat-bladed screwdriver

Table 9-3 Connecting the DC link connecting cables to the DC link adapter





1. Fix the first core of the DC link connecting cable to the profile rail using a cable clamp.

2. Route the cable end through an appropriate cable clamp.




3. Slide the cable clamp onto the tongue, and then insert the end of the cable into the DCN connection of the DC link adapter.



4. Tighten the cable using an Allen key.





5. Tighten the screw of the hose clamp using a suitable screwdriver.

6. Fix the second core of the DC link connecting cable to the profile rail using a cable clamp.

Connect the cable for the DCP connection as described under Points 2 to 5.



The installed DC link connecting cable is shown in the adjacent diagram.

### Note

After installing the cables, ensure that the EMC tongues of the DC link adapter are in contact with the side panel of the component.

## 9.7 Technical data

# 9.7 Technical data

Table 9-4 Technical specifications DC link adapter

6SL3162-2BM01-0AA0	Unit	Value
Current carrying capacity	Α	150
Conductor cross-section	mm²	35 95
Stripped length	mm	27
Tightening torque Terminals DC link busbars	Nm Nm	13 1.8

Configuring 10

## 10.1 Features

# 10.1.1 Speed limitation

The SINAMICS S120 High Frequency Drive was developed for the operation of high-speed synchronous and induction motors.

In order to minimize the motor losses that occur, HF Drive operates with an output filter (HF Sine Filter Module), which significantly reduces the pulse-frequency components of the inverter output voltage at the motor terminals.

Operating the HF Sine Filter Module can mean that the motor speed is restricted.

There are two options available to counteract this speed limitation of the motor or restriction of the maximum inverter output frequency:

- Using a Voltage Protection Module (VPM) for synchronous motors
- Operate the HF Drive with a pulse frequency of 32 kHz, if the reduced inverter current is sufficient for the application.

The following table provides an overview of how a possible speed limitation can be avoided.

Table 10- 1 Measures to avoid speed limitation

	Synchronous motors	Induction motors
Connect a Voltage Protection Module (VPM)	X	-
Operate the HF Drive with 32 kHz pulse frequency (take derating into consideration)	X	Х

### Note

The Voltage Protection Module for synchronous motors must always be used together with a Braking Module and a Control Supply Module.

## Calculating the maximum speed for synchronous and induction motors

Table 10-2 Overview of parameters to calculate the speed

Parameter	Meaning				
r0297	Overvoltage threshold D	Overvoltage threshold DC link 820 V			
p0233	Filter inductance, 0.036	Filter inductance, 0.036 mH			
p0234	Filter capacitance [µF]				
		Without additional capacitance	With additional capacitance		
	16 kHz	11.9 µF	15.2 μF		
	32 kHz	2.72 μF	3.4 µF		
p0304	Rated motor voltage [V]				
p0310	Rated motor frequency	[Hz]			
p0311	Rated motor speed [rpn	1]			
p0314	Motor pole pair number				
	Synchronous motor:	On the rating plate			
	Induction motor:	p0314 = (p0310 [Hz] • 60) / p031	1 [rpm] <sup>1)</sup>		
p0315	Motor pole pair width [m	Motor pole pair width [mm]			
p0316	Motor torque constant, i	r torque constant, rotary [Nm/A]			
	Motor force constant, lir	Motor force constant, linear [N/A]			
p0317	Motor voltage constant [V]				
p0348	Speed at the start of field	Speed at the start of field weakening [rpm] for V <sub>dc</sub> = 600 V (425 V <sub>rms</sub> / p0317 · 1000 rpm)			
p0353	Motor series inductance [mH]				
p0356	Motor stator leakage inc	Motor stator leakage inductance [mH]			
p0358	Motor rotor leakage inductance [mH]				
p0360	Motor magnetizing inductance [mH]				
	Motor leakage inductan	Motor leakage inductance / armature inductance (incl. series inductance, if applicable)			
	Synchronous motor:	L_motor [mH] = p0356 + p0353			
	Induction motor:	$L_{motor}$ [mH] = p0356 + p0360 - p0360 <sup>2</sup> / (p0360 + p0358) + p0353			

<sup>&</sup>lt;sup>1)</sup> The pole pair number for induction motors corresponds to the numbers in front of the decimal place of the calculated parameter.

The maximum motor speed for synchronous and induction motors can be calculated with the following formulas. Here, the parameters should be used in the units listed in the tables above.

### HF Drive without VPM

• Synchronous motor, rotary

$$p1082 \left[\frac{1}{min}\right] \le 4{,}33165 \cdot 10^9 \frac{-p0316 + \sqrt{p0316^2 + 4{,}86 \cdot 10^{-9} \cdot (r0297 \cdot p0314)^2 \cdot L\_motor \cdot p0234}}{r0297 \cdot p0314^2 \cdot L\_motor \cdot p0234}$$

Linear motor

$$p1082\ [\frac{m}{s}] \leq 11,49 \cdot p0315 \frac{\sqrt{p0316^2 \cdot p0315^2 + 0,191865 \cdot r0297^2 \cdot L\_motor \cdot p0234} - p0316 \cdot p0315}{r0297 \cdot L\_motor \cdot p0234}$$

Induction motor
 The higher value from the two calculations indicates the maximum motor speed.

$$p1082 \left[\frac{1}{min}\right] \le \frac{2,11383 \cdot 10^5}{p0314 \cdot \sqrt{(p0356 + p0360 + p0353) \cdot p0234}}$$

$$p1082 \left[\frac{1}{min}\right] \le \frac{0,6364 \cdot r0297 \cdot p0311}{p0304}$$

### HF Drive with VPM

Synchronous motor

$$p1082 \left[\frac{1}{min}\right] \le p0348 \cdot \frac{L_motor + p0233}{p0233}$$

### Note

### Minimum value of the motor leakage inductance

The motor leakage inductance/armature inductance, including series inductance (L\_motor), must not be less than 2 • p0233. If necessary, this condition must be complied with by using a suitable series inductance (p0353).

In order to compensate the shift of the filter resonant frequency as a result of the motor, from a motor leakage inductance/armature inductance of  $< 3.6 \cdot p0233$ , an additional capacitance must be activated in the HF Sine Filter Module (p5174.0 = 1). The default setting for switching-in the additional capacitance is automatically applied when commissioning the system for the first time.

The capacitor can also be manually parameterized using parameter p5174.0 (see also Chapter Overview of important parameters (Page 164)).

- The parameter is activated if the motor leakage inductance is < 3.6 p0233.</li>
- The parameter is deactivated if the motor leakage inductance is > 3.6 p0233.

### Decision matrix to use the appropriate HF Drive

The basis of this decision matrix is the maximum speed of the connected motor.

Take into account the series inductance, if L\_motor <  $2 \cdot p0233$ , so that L\_motor + p 0353  $\geq 2 \cdot p0233$ .

Is the	output fred	uency <	1200 Hz?	
YES				n motor speed (in accordance with the formula with the filter of the HF Drive without ed maximum speed?
	YES	Is the m	notor a sh	ort-circuit proof synchronous motor?
		YES		alculated maximum speed of the motor (in accordance with the formula with VPM) less e required maximum speed?
			YES	Use the HF Drive with VPM and the series inductance, which satisfies this formula.
			NO	Use the HF Drive with VPM.
		NO		alculated maximum speed of the motor (according to the formula with filter of the HF 2 kHz without VPM) less than the required maximum speed, or is the module current
			YES	The motor can only be operated up to the calculated speed as a maximum. Current and maximum speed must be weighed up against one other (HF Drive with 16 kHz <-> HF Drive with 32 kHz)
			NO	Operate the HF drive mit 32 kHz.
	NO	Operate	e the HF o	Irive mit 16 kHz.
NO				n speed of the motor (in accordance with the formula with the filter of the HF Drive at 32 ne required maximum speed?
	YES	Is the m	notor a sh	ort-circuit proof synchronous motor?
		YES		alculated maximum speed of the motor (in accordance with the formula with the filter of Drive at 32 kHz with VPM) less than the required maximum speed?
			YES	Operate the HF drive with 32 kHz and VPM - as well as the series inductance, which satisfies this formula.
			NO	Operate the HF drive mit 32 kHz.
		NO	With the	e HF drive, the motor can only be operated up to the calculated (maximum) speed at 32
	NO	Operate	e the HF o	Irive mit 32 kHz.

# 10.1.2 Star-delta or motor changeover

In principle, motors that can be changed over from a star-delta connection or motors with motor data set changeover can be operated on a High Frequency drive.

For the parameterization it is imperative that the motor leakage inductance/armature inductance must, for **all** connected motors, be either > 3.6 • p0233 or < 3.6 • p0233.

If this condition is not met, no star-delta changeover can be executed because the additional capacitance in the HF Sine Filter Module cannot be changed over depending on the data set.

## 10.1.3 Pole position identification

### Synchronous motors

For synchronous motors, which are operated with pole position identification, the HF Sine Filter Module does not support the saturation-based technique (p1980 < 10).

### Motors that are free to move

The motion-based pole position identification technique (p1980 = 10) can be used for motors that are free to move.

### Motors with motor holding brake

The elasticity-based pole position identification technique (p1980 = 20) can be used for motors that are equipped with a holding brake.

# 10.2 Preconditions for commissioning

### 10.2.1 Checklists

Before commissioning the High Frequency Drive for the first time, check that all of the connected components are ready for operation. To do this, use the checklists that you can find in the SINAMICS S120 Commissioning Manual (IH1) in Chapter: "Preparing for commissioning / checklists for commissioning SINAMICS S":

- · Checklist (1) for commissioning booksize power units
- Checklist (2) for commissioning chassis power units

## 10.2.2 Topology rules for DRIVE-CLiQ

When the Control Unit (CU320-2, NCU15.x) powers up, a component number is assigned to each component.

For the High Frequency Drive, fixed topology rules apply for DRIVE-CLiQ. This applies to:

- · Connecting the HF modules to one other.
- Connecting the HF-module to a Control Unit (HF line-up).

If these rules are violated, an appropriate alarm will be output on the assigned Control Unit or the connected operator panel.

## 10.2.3 DRIVE-CLiQ topology at the High Frequency Drive

The diagrams show how the DRIVE-CLiQ cables between HF Motor Module, HF Choke Module and HF Damping Module must be connected to ensure an error-free function.

### **NOTICE**

### Damage when using incorrect DRIVE-CLiQ cables

Damage or malfunctions can occur on the devices or system when DRIVE-CLiQ cables are used that are either incorrect or have not been approved for this purpose.

 Only use suitable DRIVE-CLiQ cables that have been approved by Siemens for the particular application.

### High Frequency Drive with 16 kHz




Figure 10-1 DRIVE-CLiQ topology at the High Frequency Drive (16 kHz)

# High Frequency Drive with 32 kHz




Figure 10-2 DRIVE-CLiQ topology at the High Frequency Drive (32 kHz)

# DRIVE-CLiQ interface assignment

Table 10-3 Assignment of the DRIVE-CLiQ interfaces at the HF Motor Module

DRIVE-CLiQ interface	Connection with
X200	X101/X102/X103/X100 of the Control Unit
X201	X200 HF Damping Module (only for 16 kHz)
X202	Motor encoder, spindle


Table 10-4 Assignment of the DRIVE-CLiQ interfaces at the HF Damping Module

DRIVE-CLiQ interface	Connection with	
X200	X201 HF Motor Module (only for 16 kHz)	
	X102 at the Control Unit (only for 32 kHz)	

## 10.2.4 DRIVE-CLiQ topology at the HF line-up

To operate a High Frequency Drive with an NX module, the topology depends on the pulse frequency. An overview is shown in the table.

Pulse frequency	Module	Possible number of HF Drives
16 kHz	NX15	2 and infeed (optional)
32 kHz	NX15	1 and infeed (optional)



(1) For operation with only one HF Drive 16 kHz, the DRIVE-CLiQ cable can be directly connected from the Active Line Module to the HF Motor Module.

Figure 10-3 DRIVE-CLiQ topology for HF Drives 16 kHz (62.5  $\mu$ s) with Active Line Module and NX module




Figure 10-4 DRIVE-CLiQ topology for one HF Drive 32 kHz (31.25 μs) with Active Line Module and NX module

# 10.3 Commissioning with SINUMERIK Operate

### 10.3.1 Preconditions

For commissioning High Frequency Drive with SINUMERIK Operate, the following preconditions must be met:

- The High Frequency Drive is connected to an NX module corresponding to the topology rules (see DRIVE-CLiQ topology at the HF lineup (Page 158)).
- The High Frequency Drive is commissioned for the first time.
- The control line-up is switched on.
- The drive software is available in version 4.5 or higher.

### 10.3.2 Workflow

The commissioning of the HF Drive corresponds to the standard commissioning via HMI. A detailed description is provided in the SINUMERIK commissioning manual.

- 1. From the user interface in the "Startup" operating area, initiate the automated commissioning of the drive system.
- 2. Each component of the High Frequency Drive is allocated a dedicated component ID. A SERVO drive object belonging to the HF Motor Module is automatically created. The measuring systems, which are connected to interfaces X202 of the HF Motor Module and X202 of the HF Damping Module, are automatically assigned to the SERVO drive object. In this case, the assignments apply as follows:
  - p0161: HF Damping Module
  - p0162: HF Choke Module
- 3. The drive sets a current controller clock cycle (62.5  $\mu$ s/31.25  $\mu$ s) matching the High Frequency Drive.
- 4. You can optionally perform the following steps:
  - Manually assign a High Frequency Drive a SERVO drive object in the expert list using p0161/p0162.
  - Rename the individual components using the appropriate screen forms at the user interface.

### Faults when commissioning the system for the first time

The High Frequency Drive is not automatically assigned in the following cases:

- The HF damping module is not connected
- The HF Damping Module is not connected corresponding to the DRIVE-CLiQ topology rules.

In these cases, connect the HF Damping Module according to the topology rules (see diagrams DRIVE-CLiQ topology at the High Frequency Drive (Page 156)).

## 10.3.3 Displaying the configuration/topology

To show the configuration and the topology at the user interface, a High Frequency Drive with a pulse frequency of 16 kHz connected to an NX15.3 has been commissioned.

### Configuration view

To call the configuration of the HF line-up, at the user interface in the "Startup" operating area, change to "Drive system" > "Drive unit" > "Configuration".

The actual configuration is displayed as shown below.




Figure 10-5 High Frequency Drive in the configuration view

### Topology display

In order to show the HF line-up in the target topology that has been read out, at the user interface in the "Startup" operating area, change to

"Drive system" > "Drive unit" > "Topology". The High Frequency drive is displayed in the "Topology" window with its three individual modules, each of which has its own assigned component number.

### Note

### **HF Sine Filter Module**

The HF Sine Filter Module is only displayed if the DRIVE-CLiQ filter function is deactivated in the display options.




Figure 10-6 High Frequency Drive in the topology display (part 1)



Figure 10-7 High Frequency Drive in the topology display (part 2)

# 10.4 Overview of important parameters

A detailed description of the parameters listed below can be found in the following manual: SINAMICS S120/S150 List Manual

### Overview of important parameters:

- r5170[0...5] HF phase current actual values
- r5171 CO: HF damping voltage actual value
- r5172[0...3] CO: HF temperatures
- r5173 CO: HF Damping Module overload I<sup>2</sup>t
- r5175[0...1] HF diagnostics
- p5174 HF control word
- p0161 HF Damping Module component number
- p0162 HF Choke Module component number
- p0233 power unit motor reactor
- p0234 power unit sine-wave filter capacitance
- p1980[0...n] PolID technique (the values of this parameter cannot be freely set.)

# 10.5 Alarm and fault messages

All alarm and fault messages are displayed on the operator panel. Detailed information on the displayed alarm and fault messages can be found in the SINUMERIK Diagnostics Manual, in the SINAMICS S120/S150 List Manual and in the online help for the control system.

# 10.6 Safety-related functions

Information on the safety-related functions, which apply for High Frequency Drive, can be found in the following manual:

SINAMICS S120 Function Manual Safety Integrated (FHS)

Cabinet design and EMC

## 11.1 General information

High Frequency Drives are only designed for installation in EMC-compliant control cabinets.

When operating components in the chassis and booksize formats, the information provided in these manuals regarding cabinet design and EMC apply:

- SINAMICS S120 Manual for Booksize Power Units (GH2)
- SINAMICS S120 Manual for Chassis Power Units (GH3)

# 11.2 Safety instructions for control panel manufacturing



Danger to life if the fundamental safety instructions and remaining risks are not carefully observed

The non-observance of the fundamental safety instructions and residual risks stated in Chapter 1 can result in accidents with severe injuries or death.

- Adhere to the fundamental safety instructions.
- When assessing the risk, take into account remaining risks.

# / WARNING

### Danger to life due to malfunctions caused by conductive foreign matter

Foreign objects in the enclosure can cause the devices to malfunction. In turn, this affects the functional safety of machines and can therefore put people in danger or lead to material damage.

- Cover the ventilation slots during installation of the control cabinet to prevent drill swarf, end sleeves, and so on from falling into the enclosure, which could result in shortcircuits or damage the insulation.
- Observe the safety regulations regarding touch protection. See also EN 60204-1.



## / WARNING

### Danger to life through electric shock due to unconnected cable shields

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

• Connect cable shields and unused conductors of power cables (e.g. brake conductors) at least on one side to the grounded housing potential.

### NOTICE

### Damage to the device and malfunctions as a result of static discharge

If static discharge occurs on surfaces or interfaces that cannot be easily accessed, this can cause defects and/or malfunctions.

- Only touch components, modules, and devices when you are grounded by one of the following methods:
  - Wear an ESD wrist strap
  - Wear ESD shoes or ESD grounding straps in ESD areas with conductive flooring

# 11.3 24 V DC supply voltage

### 11.3.1 General

The 24 VDC voltage is required to supply:

- The electronics of the SINAMICS components via the integrated 24 V busbar
- The electronics of the Control Units, option boards, Sensor Modules, and Terminal Modules, as well as the process voltage of their digital inputs
- The load voltage of the digital outputs

### Note

The electronic power supply has to be provided by the user as described in Chapter System data (Page 27).

When connecting a DC power supply as specified in EN 60204-1:1997, sect. 4.3.3, malfunctions may occur due to the voltage interruptions permitted for them.



## / WARNING

# Danger of death as a result of hazardous voltages when connecting an unsuitable power supply

Death or serious injury can result when live parts are touched in the event of a fault.

 For all connections and terminals of the electronic boards, only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) output voltages.

### **NOTICE**

### Damage to further loads due to overvoltage

Overvoltage from switched inducted loads (contactors, relays) can damage connected loads.

Install suitable surge protection.

### Note

### Malfunction because 24 V supply voltage is too low

If the 24 V supply voltage falls short of the specified minimum value on a device in the assembly, a malfunction can occur.

 Select an input voltage that is high enough to ensure a sufficient voltage on the last device. Do not exceed the maximum value for the supply voltage. If required, supply the voltage to the assembly at various locations.

Detailed information on supplying components with 24 V DC can be found in these manuals:

- SINAMICS S120 Manual for Chassis Power Units (GH3)
- SINAMICS S120 Manual for Booksize Power Units (GH2)

## 11.3.2 24 V power supply and connection of components

Active Line Modules booksize, HF modules and DC link components are connected to the 24 V DC power supply via the integrated 24 V DC busbars. The current carrying capacity of these busbars is 20 A.The 24 V supply can be realized in various ways:

### Using a Control Supply Module

When a Control Supply Module is used, the 24 V supply can be directly established via the busbars. The electronic current limiting function integrated in the Control Supply Module protects the busbar system when a fault occurs. Additional loads can be connected via the 24 V terminal adapter.

### Note

When using cables with a cross-section of 2.5 mm², no additional protection is required on the 24 V side if a type XLPE or EPR cable, or a cable with a similar quality and with a thermal stability of up to 90 °C is used.

### Using a SITOP Power modular 20 A

When using a SITOP Power modular 20 A, the 24 V terminal adapter must be used. The SITOP Power module should be located very close to the load (max. cable length 10 m). We recommend using miniature circuit breakers with tripping characteristic D as overcurrent protection devices for the cables and busbars.

### Using an external 24 V power supply

When using an external 24 V power supply, the 24 V terminal adapter must be used. The external power supply should be located very close to the load (max. cable length 10 m). A SITOP Select module, type 6EP1961-2BA00, must be used as overcurrent protection device for the cables and busbars.

### Using the red 24 V connectors

- A 24 V connector should be inserted onto the 24 V busbar between each Active Line Module booksize, HF Motor Module, HF Choke Module, HF Damping Module and DC link component.
- Attachment and removal are only permissible in a de-energized state.
- A maximum of 5 unplugging and plugging cycles is permissible.

### Note

The red 24 V connectors must be attached before the drive line-up is commissioned.

# 11.3.3 Typical 24 V current consumption of the components

A separate 24 V power supply must be used for the SINAMICS S120 drive line-up.

The following table can be used to calculate the 24 V DC power supply. The values for typical current consumption are used as a basis for configuration.

Table 11-1 Overview of the 24 V DC current consumption

Component	Typical current consumption [A <sub>DC</sub> ]
Control Unit	
NCU730.3	
without load	1.9
each digital output	0.1
Active Interface Modules	
120 KW booksize	1.2
132 KW, 160 kW chassis	0.17
Active Line Modules	
120 kW Booksize Liquid Cooled	1.8
132 KW chassis	1.1
HF Motor Module 225 A	0.8
HF Choke Module 225 A	1.6
HF Damping Module 225 A	0.9
Braking Module	0.5

## 11.3.4 Selecting power supply units

It is recommended that the devices in the following tables are used.

Table 11-2 SITOP Power modular

Rated output current [A]	Phases	Rated input voltage [V] Working voltage range [V]	Short-circuit current [A]	Article No.
20	1 / 2	AC 120 / 230 85 132 / 176 264	Approx. 23 (power up) Typ. 60 for 25 ms	6EP1336-3BA00-8AA0
	3	3 AC 230 / 400 288 / 500 320 550	(operation)	6EP1436-3BA00-8AA0
40	1/2	AC 120 / 230 85 132 / 176 264	Approx. 46 (power up) Typ. 120 for 25 ms	6EP1337-3BA00-8AA0
	3	3 AC 230 / 400 288 / 500 320 550	(operation)	6EP1437-3BA00-8AA0

Table 11-3 Control Supply Module

Rated output current [A]	Phases	Input voltage range [V]	Short-circuit current [A]	Article No.
20	3	3 AC 380 -10% (-15% < 1 min) 3 AC 480 +10%	< 24	6SL3100-1DE22-0AAx
		DC 300 800		

### Table 11-4 SITOP Select module

Rated output current [A]	Outputs	Rated input voltage [V]	Short-circuit current [mA]	Article No.
2 10	4	24 V DC	130 % of the set output current	6EP1961-2BA00

# / WARNING

### Danger to life through a hazardous voltage when connecting an unsuitable power supply

Death or serious injury can result when live parts are touched in the event of a fault.

- Connect the ground potential to the PE conductor connection.
- Mount the power supply close to the drive lineup.
   Ideally, they are mounted together on the same mounting plate. If different mounting plates are used, their electrical interconnection must comply with the EMC installation guideline.

# 11.4 Connection system

# 11.4.1 Connectable conductor cross-sections for line supply and power cables of the booksize components

Table 11-5 Connectable cable cross-sections: Line feeder cable / motor cable

		Connection cross-section [mm²]							
Component	Terminal type	25	35	50	70	95	120		
HF Choke Module 225 A <sup>1)</sup>	Threaded bolts M8/13 Nm	Х	Х	Х	Х	Х	Х		
Active Line Module 80 kW / 120 kW <sup>1)</sup>	Threaded bolts M8/13 Nm				Х	Х	Х		
Active Interface Module 80 kW / 120 kW¹)	Threaded bolts M8/13 Nm				Х	Х	Х		

Alternatively, two ring cable lugs without insulation for the parallel connection of two cables with a maximum crosssection of 50 mm<sup>2</sup> can also be connected to the threaded bolts respectively. Both cable lugs should be installed "back to back".

# / WARNING

### Risk of fire due to overheating when permissible cable cross-sections are exceeded

The internal overload monitoring function of the power module only protects the cable if this is dimensioned/selected corresponding to the power module currents. Cables with an excessively low cross-section can overheat and result in fire and smoke.

- Always use cables with adequate cross-sections.
- If you select lower cross-sections, then you must ensure the appropriate level of cable protection in another way, e.g. by suitably setting the control parameters.

# 11.4.2 Screw terminals

The type of screw terminal can be taken from the interface description of the particular component.

Table 11-6 Screw terminals

Screv	w terminal type							
1	Connectable cable cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.08 1.5 mm <sup>2</sup> 0.25 1.5 mm <sup>2</sup> 0.25 0.5 mm <sup>2</sup>					
	Stripped length	7 mm						
	Tool	Screwdriver 0.4 x 2.0 mm						
	Tightening torque	0.22 0.25 Nm						
1_1	Connectable cable cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.14 1.5 mm <sup>2</sup> 0.25 1.5 mm <sup>2</sup> 0.25 0.5 mm <sup>2</sup>					
	Stripped length	7 mm						
	Tool	0.4 x 2.5 mm screwdriver						
	Tightening torque	0.22 0.25 Nm						
4	Connectable cable cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.2 4 mm <sup>2</sup> 0.25 4 mm <sup>2</sup> 0.25 4 mm <sup>2</sup>					
	Stripped length	7 mm						
	Tool	0.6 x 305 mm screwdriver						
	Tightening torque	0.5 0.6 Nm						
5	Connectable cable cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.5 6 mm <sup>2</sup> 0.5 6 mm <sup>2</sup> 0.5 6 mm <sup>2</sup>					
	Stripped length	12 mm						
	Tool	Screwdriver 1.0 x 4.0 mm						
	Tightening torque	1.2 1.5 Nm						

# 11.4.3 Cable lugs




Figure 11-1 Dimension drawing of cable lugs

Table 11-7 Dimensions of cable lugs

Screw/bolt	Cable cross-section [mm²]	a [mm]	c [mm]	d₁ [mm]	d <sub>2</sub> [mm]	d₃ [mm]	l [mm]	r [mm]	s [mm]
M8	25	11	12	7.5	8.4	16	25	10	1.5
M8	35	12	15	9	8.4	16	26	10	1.6
М8	50	16	17	11	8.4	18	34	10	1.8
М8	70	18	21	13	8.4	22	38	12	2
М8	95	20	23	15	8.4	24	42	12	2.5
M8	120	22	24	16.5	8.4	24	44	12	3

# 11.5 Protective connections and equipotential bonding

### Protective connections

The SINAMICS S Booksize drive system is designed for use in cabinets with a PE conductor connection.

The protective conductor connection of the SINAMICS components must be connected to the protective conductor connection of the control cabinet as follows:

Table 11-8 Conductor cross-sections for copper protective connections

Line feeder cable to Line Module [mm²]	Protective connection, copper [mm²]				
Up to 16 mm <sup>2</sup>	The same as the line supply cable				
From 16 mm <sup>2</sup> to 35 mm <sup>2</sup>	16 mm <sup>2</sup>				
From 35 mm <sup>2</sup>	0.5 x line supply cable				

For materials other than copper, the cross-section should be increased so that as a minimum, the same conductivity is attained.

All system components and machine parts must be incorporated in the protection concept.

The protective connection (PE connection) of the motors used must be established through the motor cable. For EMC reasons, these protective connections should be made at the HF Choke Module.

In order to maintain the EMC limit values, the drive line-up must be arranged on the mounting plate as specified in Chapter Installation (Page 55) . The mounting plate must be connected to the protective conductor connection of the control cabinet through a low impedance.

Copper cables with appropriate cross-sections (>2.5 mm²) must be used for the ground connection of PROFIBUS nodes.

For more information about grounding PROFIBUS, see: http://www.profibus.com/fileadmin/media/wbt/WBT\_Assembly\_V10\_Dec06/index.html



# / WARNING

Danger to life as a result of electric shock and fire when operating outside closed electrical equipment rooms and/or control cabinets

Death or serious injury can result if you do not take suitable measures when installing the equipment to provide touch protection for live components or the propagation of a fire.

 Only operate the components in electrical equipment rooms or control cabinets that can be securely locked.



## / WARNING

# Danger of death caused by high discharge currents when the external protective conductor is interrupted

Drive components conduct high discharge currents via the protective conductor. When the protective conductor is interrupted, touching live components can result in electric shock, which can lead to death or serious injuries.

- Ensure that the external protective conductor complies with at least one of the following conditions:
  - It is laid protected against mechanical damage.<sup>1)</sup>
  - For an individual conductor, it has a cross-section of at least 10 mm<sup>2</sup> Cu.
  - As a core of a multi-core cable, it has a cross section of at least 2.5 mm<sup>2</sup> Cu.
  - It has a parallel, second protective conductor with the same cross-section.
  - It corresponds to the local regulations for equipment with increased leakage current.
  - <sup>1)</sup> Cables routed in control cabinets or enclosed machine enclosures are considered to be adequately protected against mechanical damage.

### Functional equipotential bonding with protective conductor connection

The mounting plate, which is connected with the protective conductor connection of the control cabinet through a low impedance connection, simultaneously serves as the function equipotential bonding surface. This means that no additional functional equipotential bonding is required within the drive line-up.

When installing components on standard mounting rails, the data listed in the table also apply to the functional equipotential bonding. If only smaller conductor cross-sections are permissible on components, the largest cross-section must be used (e.g. 6 mm² for TM31 and SMC). These requirements also apply to distributed components located outside the control cabinet.

No functional equipotential bonding conductors are required for PROFIBUS inside a control cabinet. For PROFIBUS connections between different buildings or parts of buildings, a functional equipotential bonding must be routed in parallel to the PROFIBUS cable. The following cross-sections must be observed in accordance with IEC 60364-5-54:

- Copper 6 mm²
- Aluminum 16 mm²
- Steel 50 mm<sup>2</sup>

Additional information about equipotential bonding for PROFIBUS can be found at: http://www.profibus.com/fileadmin/media/wbt/WBT\_Assembly\_V10\_Dec06/index.html

### Note

### **PROFINET**

For installation guidelines and information of protective grounding and equipotential bonding for all PROFINET types and topologies, refer to DOWNLOADS at: http://www.profibus.com

## 11.6 Arrangement of the devices

The arrangement of the components and equipment in the control cabinet takes account of:

- Space requirements
- Cable routing
- Bending radii of the connection cables
   MOTION-CONNECT cables, refer to catalog PM21 or NC61
- Heat dissipation
- EMC

The components of the HF line-up must be mounted on the mounting plate described in Chapter Installation (Page 55).

Components are usually located centrally in a cabinet. The necessary mounting and installation clearances above and below the components can possibly exceed the minimum clearances specified in the product documentation.

# 11.7 Cooling circuit and coolant properties

The cooling circuit is essentially designed as described in the following manual:

SINAMICS S120 Manual for Booksize Power Units

In the corresponding chapters you will also find information on coolant properties.

### Note

### Special features of the High Frequency Drive

- Only use shielded coolant hoses or metal coolant pipes when the routing coolant within the EMC control cabinet.
- Connect the shields of the coolant hoses at both ends.
- You must install flow monitors to completely protect the devices.
   Recommendation: efector300 SM6000 from the ifm electronic GmbH company
   When the rated flow rate is fallen below, the pulses must be inhibited within 10 s.

### **NOTICE**

### Damage to the component as a result of liquids that have entered

Liquids that penetrate the equipment can cause short circuits in the components and damage the components.

- Use a rigid piping system when connecting the cooling circuit to the Motor Modules.
- Apply a thread locking compound/sealant to the screw connections of the cooling water connections to prevent them loosening and leaking. Use Loctite 577 liquid thread sealant and the associated Loctite 7091 activator. Carefully observe the application instructions of the associated product description from Loctite.

Service and maintenance 12

# 12.1 Replacing the fan

# 12.1.1 Safety instructions for replacing a fan

### Note

- When replacing the fan, you must observe the ESD regulations (Page 21).
- Only qualified personnel are permitted to install spare parts.



# **△ DANGER**

### Danger of death when live parts are touched

The fan must be in a no-voltage and disconnected state when it is replaced. A hazardous voltage is still present for up to 5 minutes after the power supply has been switched off.

Touching live components results in death or severe injury.


- Only remove the fan cover or the fan support assembly after this time has expired.
- Before removing the component, check that the drive line-up is in a no-voltage condition.

# 12.1.2 Replacing the fan at the HF Choke Module

### Removing fans

- 1. Remove the HF Choke Module from the drive line-up.
- 2. Remove the screws on the fan cover using a Torx T20 screwdriver.
- 3. Remove the fan cover.
- 4. Release the connecting plug and remove it.
- 5. Remove the screws from the fan support using a Torx T20 screwdriver.
- 6. Remove the fan support with the fans.

### 12.1 Replacing the fan



- 1 Fans (2x)
- 2 Connecting plug
- 3 Fan support
- 4 Oval head screws (2x), M4, Torx T20
- ⑤ Fan cover
- 6 Countersunk head screws (4x), M4, Torx T20

Figure 12-1 Remove the fans at the HF Choke Module


### Installing the fan

- 1. Position the replacement fans on the fan support. Note the direction of the airflow from bottom to top (the arrow on the fan must point to the inside of the module).
- 2. Push the fan support and fan into the device. The connecting cables must not be crushed when doing this.
- 3. Tighten the oval head screws at the fan support (tightening torque: 1.8 Nm).
- 4. Insert the connecting plugs so that you can hear them engage.
- 5. Put the fan cover on. The connecting cables must not be damaged when doing this.
- 6. Screw the countersunk screws on the fan cover and tighten them crosswise (tightening torque: 1.8 Nm).

## 12.1.3 Replacing the fan at the HF Damping Module

### Removing fans

- 1. Remove the HF Damping Module from the drive line-up.
- 2. Remove the retaining screws from the fan support using a Torx T20 screwdriver.
- 3. Release the connecting plug and remove it.
- 4. Remove the fan support with the fan.



- Connecting plug
- ② Fans
- 3 Fan support
- 4 Retaining screws (4x), M4, Torx T20

Figure 12-2 Remove the fans at the HF Damping Module

### Installing the fan

- 1. Position the replacement fan on the fan support. Note the direction of the airflow from bottom to top (the arrow on the fan must point to the inside of the module).
- 2. Insert the connecting plug so that you can hear it engage.
- 3. Push the fan support and fan into the device. The connecting cable must not be crushed when doing this.
- 4. Tighten the retaining screws on the fan support and tighten them crosswise (tightening torque: 1.8 Nm).

# 12.2 Recycling and disposal

Dispose of the product according to the applicable national regulations.

The products described in this Equipment Manual are extensively recyclable on account of the low-toxic composition of the materials used. To recycle and dispose of your old device in an environmentally friendly way, please contact a company that disposes of electronic waste.

Appendix

## A.1 List of abbreviations

#### Note

The following list of abbreviations includes all abbreviations and their meanings used in the entire SINAMICS family of drives.

Abbreviation	Source of the abbreviation	Meaning	
Α			
A	Alarm	Alarm	
AC	Alternating Current	Alternating current	
ADC	Analog Digital Converter	Analog-digital converter	
Al	Analog Input	Analog input	
AIM	Active Interface Module	Active Interface Module	
ALM	Active Line Module	Active Line Module	
AO	Analog Output	Analog output	
AOP	Advanced Operator Panel	Advanced Operator Panel	
APC	Advanced Positioning Control	Advanced Positioning Control	
AR	Automatic Restart	Automatic restart	
ASC	Armature Short-Circuit	Armature short-circuit	
ASCII	American Standard Code for Information Interchange	American standard code for information interchange	
AS-i	AS-Interface (Actuator Sensor Interface)	AS interface (open bus system in automation technology)	
ASM	Asynchronmotor	Induction motor	
В			
BB	Betriebsbedingung	Operating condition	
BERO	-	Proximity switch	
BI	Binector Input	Binector Input	
BIA	Berufsgenossenschaftliches Institut für Arbeitssicherheit	BG Institute for Occupational Safety and Health	
BICO	Binector Connector Technology	Binector connector technology	
BLM	Basic Line Module	Basic Line Module	

Abbreviation	Source of the abbreviation	Meaning	
ВО	Binector Output	Binector output	
BOP	Basic Operator Panel	Basic Operator Panel	
С			
С	Capacitance	Capacitance	
C	-	Safety message	
CAN	Controller Area Network	Serial bus system	
CBC	Communication Board CAN	Communication Board CAN	
CBE	Communication Board Ethernet	PROFINET communication module (Ethernet)	
CD	Compact Disc	Compact disk	
CDS	Command Data Set	Command data set	
CF Card	CompactFlash Card	CompactFlash card	
CI	Connector Input	Connector Input	
CLC	Clearance Control	Clearance control	
CNC	Computer Numerical Control	Computerized numerical control	
CO	Connector Output	Connector output	
CO/BO	Connector Output/Binector Output	Connector/binector output	
COB ID	CAN Object-Identification	CAN object identification	
CoL	Certificate of License	Certificate of License	
COM	Common contact of a change-over relay	Center contact on a changeover contact	
COMM	Commissioning	Commissioning	
CP	Communication Processor	Communications processor	
CPU	Central Processing Unit	Central processing unit	
CRC	Cyclic Redundancy Check	Cyclic redundancy check	
CSM	Control Supply Module	Control Supply Module	
CU	Control Unit	Control unit	
CUA	Control Unit Adapter	Control Unit Adapter	
CUD	Control Unit DC MASTER	Control Unit DC MASTER	
D			
DAC	Digital Analog Converter	Digital-analog converter	
DC	Direct Current	Direct current	
DCB	Drive Control Block	Drive Control Block	
DCBRK	DC Brake	DC braking	
DCC	Drive Control Chart	Drive Control Chart	
DCN	Direct Current Negative	Direct current negative	
DCP	Direct Current Positive	Direct current positive	
DDS	Drive Data Set	Drive data set	
DI	Digital Input	Digital input	
DI/DO	Digital Input/Digital Output	Bidirectional digital input/output	
DMC	DRIVE-CLiQ Hub Module Cabinet	DRIVE-CLiQ Hub Module Cabinet	
DME	DRIVE-CLiQ Hub Module External	DRIVE-CLiQ Hub Module External	

Abbreviation Source of the abbreviation Meaning

DMM Double Motor Module Double Motor Module

DO Digital Output Digital output

DO Drive Object Drive object

DP Decentralized Peripherals Distributed I/O

DPRAM Dual Ported Random Access Memory Dual-Port Random Access Memory

DQ DRIVE-CLIQ DRIVE-CLIQ

DRAM Dynamic Random Access Memory Dynamic Random Access Memory

DRIVE-CLiQ Drive Component Link with IQ Drive Component Link with IQ

DSC Dynamic Servo Control Dynamic Servo Control

DTC Digital Time Clock Timer

Ε

F

EASC External Armature Short-Circuit External armature short-circuit

EDS Encoder Data Set Encoder data set

EEPROM Electrically Erasable Programmable Electrically Erasable Programmable

Read-Only Memory Read-Only-Memory

ESD Elektrostatisch gefährdete Baugruppen Electrostatic sensitive devices

ELCB Earth Leakage Circuit Breaker Residual current operated circuit breaker

ELP Earth Leakage Protection Ground-fault monitoring

EMC Electromagnetic Compatibility Electromagnetic compatibility

EMF Electromotive Force Electromotive force
EMK Elektromotorische Kraft Electromotive force

EMV Elektromagnetische Verträglichkeit Electromagnetic compatibility

ΕN Europäische Norm European standard **EnDat Encoder-Data-Interface** Encoder interface ΕP **Enable Pulses** Enable pulses **EPOS** Einfachpositionierer Basic positioner ES **Engineering System Engineering System ESB** Ersatzschaltbild Equivalent circuit diagram **ESD Electrostatic Sensitive Devices** Electrostatic sensitive devices

ESM Essential Service Mode Essential service mode
ESR Extended Stop and Retract Extended stop and retract

Fault

F... Fault

FAQ Frequently Asked Questions Frequently asked questions

FBLOCKS Free Blocks Free function blocks

FCC Function Control Chart Function control chart

FCC Flux Current Control Flux current control

FD Function Diagram Function diagram

F-DI Failsafe Digital Input Fail-safe digital input
F-DO Failsafe Digital Output Fail-safe digital output

Abbreviation	Source of the abbreviation	Meaning
FEM	Fremderregter Synchronmotor	Separately excited synchronous motor
FEPROM	Flash-EPROM	Non-volatile write and read memory
FG	Function Generator	Function generator
FI	-	Residual current
FOC	Fiber-Optic Cable	Fiber-optic cable
FP	Funktionsplan	Function diagram
FPGA	Field Programmable Gate Array	Field programmable gate array
FW	Firmware	Firmware
G		
GB	Gigabyte	Gigabyte
GC	Global Control	Global control telegram (broadcast telegram)
GND	Ground	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as M)
GSD	Gerätestammdatei	Generic station description: describes the features of a PROFIBUS slave
GSV	Gate Supply Voltage	Gate supply voltage
GUID	Globally Unique Identifier	Globally Unique Identifier
Н		
HF	High frequency	High frequency
HFD	Hochfrequenzdrossel	High-frequency reactor
HLA	Hydraulic Linear Actuator	Hydraulic linear drive
HLG	Hochlaufgeber	Ramp-function generator
HM	Hydraulic Module	Hydraulic Module
HMI	Human Machine Interface	Human machine interface
HTL	High-Threshold Logic	Logic with high fault threshold
HW	Hardware	Hardware
1		
i. V.	In Vorbereitung	Under development: This property is currently not available
I/O	Input/Output	Input/output
I2C	Inter-Integrated Circuit	Internal serial data bus
IASC	Internal Armature Short-Circuit	Internal armature short-circuit
IBN	Inbetriebnahme	Commissioning
ID	Identifier	Identification
IE	Industrial Ethernet	Industrial Ethernet
IEC	International Electrotechnical Commission	International Electrotechnical Commission
IF	Interface	Interface
IGBT	Insulated Gate Bipolar Transistor	Bipolar transistor with insulated control electrode
IGCT	Integrated Gate-Controlled Thyristor	Semiconductor power switch with integrated control electrode

Abbreviation	Source of the abbreviation	Meaning
IL	Impulsioschung	Pulse suppression
IP	Internet Protocol	Internet Protocol
IPO	Interpolator	Interpolator
IT	Isolé Terre	-
		Non-grounded three-phase line supply
IVP	Internal Voltage Protection	Internal voltage protection
J JOG	lancing	la m
К	Jogging	Jog
KDV	Krouzweiger Deterwereleich	Crosswing data comparison
	Kreuzweiser Datenvergleich	Crosswise data comparison
KHP	Know-how protection	Know-how protection
KIP	Kinetische Pufferung	Kinetic buffering
Kp	-	Proportional gain
KTY	-	Special temperature sensor
L		Our half of the harteness
L	-	Symbol for inductance
LED	Light Emitting Diode	Light emitting diode
LIN	Linearmotor	Linear motor
LR	Lageregler	Position controller
LSB	Least Significant Bit	Least significant bit
LSC	Line-Side Converter	Line-side converter
LSS	Line-Side Switch	Line-side switch
LU	Length Unit	Length unit
FO cable	Lichtwellenleiter	Fiber-optic cable
M		
M	-	Symbol for torque
М	Masse	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as GND)
MB	Megabyte	Megabyte
MCC	Motion Control Chart	Motion Control Chart
MDI	Manual Data Input	Manual data input
MDS	Motor Data Set	Motor data set
MLFB	Maschinenlesbare Fabrikatebezeichnung	Machine-readable product code
MM	Motor Module	Motor Module
MMC	Man-Machine Communication	Man-machine communication
MMC	Micro Memory Card	Micro memory card
MSB	Most Significant Bit	Most significant bit
MSC	Motor-Side Converter	Motor-side converter
MSCY_C1	Master Slave Cycle Class 1	Cyclic communication between master (class 1)

and slave

Abbreviation	Source of the abbreviation	Meaning	
MSC	Motorstromrichter	Motor-side converter	
MT	Messtaster	Probe	
N	Wicostasto.	11000	
N. C.	Not Connected	Not connected	
N	No Report	No report or internal message	
NAMUR	Normenarbeitsgemeinschaft für Mess- und Regeltechnik in der chemischen Industrie	Standardization association for measurement and control in chemical industries	
NC	Normally Closed (contact)	NC contact	
NC	Numerical Control	Numerical control	
NEMA	National Electrical Manufacturers Association	Standardization body in the US	
NM	Nullmarke	Zero mark	
NO	Normally Open (contact)	NO contacts	
LSC	Netzstromrichter	Line-side converter	
NVRAM	Non-Volatile Random Access Memory	Non-volatile read/write memory	
0			
OA	Open Architecture	Software component (technology package) which provides additional functions for the SINAMICS drive system	
OAIF	Open Architecture Interface	Version of the SINAMICS firmware from which the OA-application can be used	
OASP	Open Architecture Support Package	Expands the STARTER commissioning tool by the corresponding OA-application	
oc	Operating Condition	Operating condition	
OEM	Original Equipment Manufacturer	Original equipment manufacturer	
OLP	Optical Link Plug	Bus connector for fiber-optic cable	
OMI	Option Module Interface	Option Module Interface	
P			
p	-	Adjustable parameters	
P1	Processor 1	CPU 1	
P2	Processor 2	CPU 2	
PB	PROFIBUS	PROFIBUS	
PcCtrl	PC Control	Master control	
PD	PROFIdrive	PROFIdrive	
PDS	Power unit Data Set	Power unit data set	
PE	Protective Earth	Protective ground	
PELV	Protective Extra Low Voltage	Safety extra-low voltage	
PEM	Permanenterregter Synchronmotor	Permanent-magnet synchronous motor	
PG	Programmiergerät	Programming device	
PI	Proportional Integral	Proportional integral	
PID	Proportional Integral Differential	Proportional integral differential	
PLC	Programmable Logical Controller	Programmable logic controller	

Abbreviation Source of the abbreviation Meaning

**PLL** Phase-Locked Loop Phase-locked loop PM Power Module **Power Module** PΝ **PROFINET PROFINET** 

PNO **PROFIBUS Nutzerorganisation** PROFIBUS user organization PPI Point to Point Interface Point-to-point interface

**PRBS** Pseudo Random Binary Signal White noise **PROFIBUS** Serial data bus **Process Field Bus** PS **Power Supply** Power supply

**PSA** Power Stack Adapter Power Stack Adapter

PTP Point To Point Point-to-point

Positive Temperature Coefficient

**PWM** Pulse Width Modulation Pulse width modulation

**PZD** Prozessdaten Process data

Q R

PTC

r...

Display parameters (read only)

RAM Random Access Memory Read/write memory

**RCCB** Residual Current Circuit Breaker Residual current operated circuit breaker RCD Residual Current Device Residual current operated circuit breaker

Residual Current Monitor **RCM** Residual current monitor **RFG** Ramp-Function Generator Ramp-function generator

RJ45 Registered Jack 45 Term for an 8-pin socket system for data

transmission with shielded or non-shielded multi-

wire copper cables

Positive temperature coefficient

**RKA** Rückkühlanlage Cooling unit

**RLM** Renewable Line Module Renewable Line Module

RO Read Only Read only

ROM Read-Only Memory Read-only memory

**RPDO** Receive Process Data Object Receive Process Data Object

Recommended Standard 232 Interface standard for cable-connected serial data RS232

transmission between a sender and receiver

(also known as EIA232)

**RS485** Recommended Standard 485 Interface standard for a cable-connected

differential, parallel, and/or serial bus system (data

transmission between a number of senders and

receivers, also known as EIA485)

RTC Real Time Clock Realtime clock

**RZA** Raumzeigerapproximation Space vector approximation

**S1** Continuous duty Intermittent duty S3

SAM Safe Acceleration Monitor Safe acceleration monitoring

Abbreviation	Source of the abbreviation	Meaning
SBC	Safe Brake Control	Safe brake control
SBH	Sicherer Betriebshalt	Safe operating stop
SBR	Safe Brake Ramp	Safe brake ramp monitoring
SBT	Safe Brake Test	Safe brake test
SCA	Safe Cam	Safe cam
SD Card	SecureDigital Card	Secure digital memory card
SDI	Safe Direction	Safe motion direction
SE	Sicherer Software-Endschalter	Safe software limit switch
SG	Sicher reduzierte Geschwindigkeit	Safely-limited speed
SGA	Sicherheitsgerichteter Ausgang	Safety-related output
SGE	Sicherheitsgerichteter Eingang	Safety-related input
SH	Sicherer Halt	Safe standstill
SI	Safety Integrated	Safety Integrated
SIL	Safety Integrity Level	Safety Integrity Level
SLM	Smart Line Module	Smart Line Module
SLP	Safely-Limited Position	Safely-limited position
SLS	Safely-Limited Speed	Safely-limited speed
SLVC	Sensorless Vector Control	Vector control without encoder (sensorless)
SM	Sensor Module	Sensor Module
SMC	Sensor Module Cabinet	Sensor Module Cabinet
SME	Sensor Module External	Sensor Module External
SMI	SINAMICS Sensor Module Integrated	SINAMICS Sensor Module Integrated
SMM	Single Motor Module	Single Motor Module
SN	Sicherer Software-Nocken	Safe software cam
SOS	Safe Operating Stop	Safe operating stop
SP	Service Pack	Service pack
SP	Safe Position	Safe position
SPC	Setpoint Channel	Setpoint channel
SPI	Serial Peripheral Interface	Serial peripheral interface
SPS	Speicherprogrammierbare Steuerung	Programmable logic controller
SS1	Safe Stop 1	Safe stop 1 (monitored for time and ramping up)
SS2	Safe Stop 2	Safe Stop 2
SSI	Synchronous Serial Interface	Synchronous serial interface
SSM	Safe Speed Monitor	Safe feedback from speed monitor
SSP	SINAMICS Support Package	SINAMICS support package
STO	Safe Torque Off	Safe torque off
STW	Steuerwort	Control word

Abbreviation	Source of the abbreviation	Meaning
Т		
ТВ	Terminal Board	Terminal board
TIA	Totally Integrated Automation	Totally Integrated Automation
TM	Terminal Module	Terminal Module
TN	Terre Neutre	Grounded three-phase line supply
Tn	-	Integral time
TPDO	Transmit Process Data Object	Transmit process data object
π	Terre Terre	Grounded three-phase line supply
TTL	Transistor-Transistor-Logic	Transistor-transistor logic
Tv	-	Rate time
U		
UL	Underwriters Laboratories Inc.	Underwriters Laboratories Inc.
UPS	Uninterruptible Power Supply	Uninterruptible power supply
UPS	Unterbrechungsfreie Stromversorgung	Uninterruptible power supply
UTC	Universal Time Coordinated	Universal time coordinated
V		
VC	Vector Control	Vector control
Vdc	-	DC-link voltage
VdcN	-	Partial DC link voltage, negative
VdcP	-	Partial DC link voltage, positive
VDE	Verband Deutscher Elektrotechniker	Verband Deutscher Elektrotechniker [Association of German Electrical Engineers]
VDI	Verein Deutscher Ingenieure	Verein Deutscher Ingenieure [Association of German Engineers]
VPM	Voltage Protection Module	Voltage Protection Module
Vpp	Volt peak to peak	Volt peak to peak
VSM	Voltage Sensing Module	Voltage Sensing Module
W		
WEA	Wiedereinschaltautomatik	Automatic restart
WZM	Werkzeugmaschine	Machine tool
X		
XML	Extensible Markup Language	Extensible markup language (standard language for web publishing and document management)
Υ		
Z		
ZK	DC Link	DC Link
ZM	Zero Mark	Zero mark
ZSW	Status word	Status word

# A.2 Documentation overview

General doc	umentation/cat	alogs	
SINAMICS	G110	D11.1	- Inverter built-in units 0.12 kW up to 3 kW
	G120	D31	- SINAMICS Inverters for Single-Axis Drives and SIMOTICS Motors
	G130, G150	D11.1	- Inverter built-in units
	3.55, 3.50		- Inverter cabinet units
	S120, S150	D21.3	- SINAMICS S120 Built-in units in the Chassis format and Cabinet Modules
			- SINAMICS S150 Drive Converter Cabinet Units
SIMOTION,	S120	PM21	SIMOTION, SINAMICS S120 and Motors for Production Machines
SINAMICS			
Manufacture	r/service docu	mentation	
SINAMICS	G110		- Getting Started
			- Operating instructions
			- List Manuals
	G120		- Getting Started
			- Operating instructions
			- Hardware Installation Manuals
			- Function Manual Safety Integrated
			- List Manuals
	G130		- Operating instructions
			- List Manual
	G150		- Operating instructions
	0.00		- List Manual
	GM150		- Operating instructions
	SM120/SM150		- List Manuals
	GL150		
	SL150		
	S110		- Manual
			- Getting Started
			- Function Manual
			- List Manual
	S120		- Getting Started
			- Commissioning Manual
			- Commissioning Manual CANopen
			- Function Manual Drive Functions
			- Function Manual Safety Integrated
			- Function Manual DCC
			- List Manual - Manual for Control Units and Additional Components
			- Manual PU Booksize
			- Manual PU Booksize C/D Type
			- Manual PU Chassis
			- Manual PU Chassis Liquid Cooled
			- Manual Cabinet Modules
			- Manual AC Drive
			- SINAMICS S120M Manual Distributed Drive Technology
			- SINAMICS HLA System Manual Hydraulic Drive
	S150		- Operating instructions
			- List Manual
Motors			- Configuration Manuals, Motors
General			- Configuration Manual, EMC Guidelines

# Index

2 24 V connector, 168	High Frequency Drive, 55 Cooling method HF Motor Module, 25 HF Sine Filter Module, 25 Current consumption (24 V DC), 169
Braking Module Booksize, 87 Connection example, 93 Braking Module Booksize Compact, 99 Connection example for braking resistor with a thermostatic switch, 109 Connection example for braking resistor without a thermostatic switch, 108 Busbars High Frequency Drive, 63	DC link Busbars, 62 DC link adapter, 141 DC link connecting cables, 146 Connection, 148 Fixing to the control cabinet panel, 147 Preparation, 146 Derating characteristics HF modules, 71
С	Diagnostics via LEDs
Commissioning Checklists, 155 Expert list, 160 Preconditions, 159 SINUMERIK Operate, 159 Topology rules, 159 Workflow, 160 Components Braking Module Booksize, 87 Braking Module Booksize Compact, 99 Braking resistors, 117 Control Supply Module CSM, 127 DC link adapter, 141 HF Choke Module, 44 HF Damping Module, 49 HF Motor Module, 37	Braking Module Booksize, 94 Braking Module Booksize Compact, 110 Control Supply Module, 136 HF Choke Module, 51 HF Damping Module, 52 HF Motor Module, 41 Dimension drawings Braking Module Booksize, 95 Braking Module Booksize Compact, 111 Braking resistors, 119 Control Supply Module, 137 DC link adapter, 144 HF Choke Module, 53 HF Damping Module, 54 HF Motor Module, 42 Voltage Protection Module, 81 DRIVE-CLiQ
Connection examples	Topology at the High Frequency Drive, 156
Braking Module Booksize, 93 Braking Module Booksize Compact, 108 Control Supply Module, 134 High frequency Drive with booksize infeed, 67 High Frequency Drive with chassis infeed, 68 Line connection for booksize infeed, 66 Voltage Protection Module, 80 Control Supply Module Connection example, single mode, 135	Topology rules, 155 Duty cycles Braking Module Booksize, 97 Braking Module Booksize Compact, 115 Braking resistors, 125 HF modules, 70

Cooling clearances

Control Supply Module CSM, 127

E	Example of connection for booksize infeed, 67
Electrical connection, 148 Equipotential bonding bar, 65 High Frequency Drive, 62, 63	Fault messages, 164 Features, 31 Installation, 55 Line connection booksize, 29
Voltage Protection Module, 83 Equipotential bonding, 174 Equipotential bonding bar	Line connection for booksize infeed, 66 Line connection, chassis, 30 Motor speed calculation, 152
Electrical connection, 65 Expert list, 160	Motor speed limitation, 151 Parameter, 164 Safety functions, 164
Н	System data, 27 Usage matrix, 154
HF Choke Module, 44 Article Nos., 33 Dimension drawings, 53	Voltage Protection Module, 73
Features, 43 Interfaces, 44	I
VPM and motor protective conductor connections, 64	Induction motor, 151 Installation  Braking Medulo Booksize, 96
HF Damping Module, 49 Article Nos., 33 Dimension drawings, 54	Braking Module Booksize, 96 DC link adapter, 145 High Frequency Drive, 55 Voltage Protection Module, 82
Features, 43 Interfaces, 49	Interface descriptions Braking Module Booksize, 90
HF modules Derating characteristics, 71 Duty cycles, 70	Braking Module Booksize Compact, 103 Control Supply Module, 130 DC link adapter, 143
Technical data, 69 Topology rules, 159 HF Motor Module, 37	HF Choke Module, 44 HF Damping Module, 49
Article Nos., 33 Cooling method, 25	HF Motor Module, 37 Voltage Protection Module, 76
Dimension drawings, 42 Features, 36	L
Interfaces, 37 HF Sine Filter Module	LEDs
Cooling method, 25 Features, 43	Braking Module Booksize, 94 Braking Module Booksize Compact, 110
High Frequency Drive Alarm messages, 164	Control Supply Module, 136 HF Choke Module, 51
Article Nos., 33 Busbars, 63 Components, 25, 31	HF Damping Module, 52 HF Motor Module, 41 Line connection
Connection example with chassis infeed, 68 Cooling clearances, 55 DC link, 62	Booksize, 29 Chassis, 30
Drilling patterns, 57 Drive Line-Up, 26	M
DRIVE-CLiQ topology, 156 Electrical connection, 62, 63	Motor Induction motor, 151
Equipotential bonding bar connection, 65	Parameterizing rules, 154

Pole position identification, 155
Speed calculation, 152
Speed limitation, 151
Star-delta changeover, 154
Synchronous motor, 151, 155
Usage matrix HF Drive, 154
Mounting
Braking Module Booksize Compact, 112
Control Supply Module, 138

### Ν

NX module Topology rules, 158

### Р

Parameter, 164
Parameterizing rules, 154
Pole position identification, 155
Power Supply Units, 170
Protective conductor connections at the HF Choke Module, 64

### S

Safety functions, 164
Safety instructions
Braking resistors, 118
Voltage Protection Module, 74
SINUMERIK Operate
Configuration view, 161
Topology display, 162
Star-delta changeover, 154
Synchronous motor, 151
System data
High Frequency Drive, 27

### Т

Technical data
Braking Module Booksize, 97
Braking Module Booksize Compact, 114
Braking resistors, 124
Control Supply Module, 139
DC link adapter, 150
HF modules, 69
Voltage Protection Module, 85
Topology rules
HF modules, 159


High Frequency Drive, 155, 157 NX module, 158

### U

Usage matrix High Frequency Drive, 154

### V

Voltage Protection Module Connection examples, 80 Dimension drawings, 81 Electrical connection, 83 Features, 73 Installation, 82 Interfaces, 76 Technical data, 85



Siemens AG Digital Factory Motion Control Postfach 3180 91050 ERLANGEN GERMANY We reserve the right to make changes © Siemens AG 2012 - 2015