

MASTERDRIVES MC

Function diagram "F01 technology option" (Positioning and synchronization)

Status: 01/2002 V.1.6

Notes:

- **The F01 technology option must have been enabled:**



The F01 technology option can only be used with MASTERDRIVES units which are supplied ex-works with the enabled F01 option or for which this option has been enabled retrospectively by means of the PIN No.

The display parameter n978 can be used to check if the F01 option is present:

n978 = 2 ==> F01 technology option has been enabled for 500 hours
n978 = 1 ==> F01 technology option has been enabled
n978 = 0 ==> F01 has been disabled

On sheet [850], you can find out how you can retrospectively enable the technology option on a permanent basis or for a 500-hours trial period.


- The technology functions are performed only if they are specifically nested in a sampling time by means of the assigned U95x parameter; see also sheets [702] and [802]! If the F01 technology option has not been enabled, when an attempt is made to nest a technology function in a sampling time, error message F063 appears.
- The technology functions synchronization (U953.33) and positioning (U953.32) must not be enabled at the same time.
- The following technology function can also be used without enabling of the technology option:
 - 833 - Real master with dead time compensation
 - MD1 ... MD50 = Machine data for positioning (stored in parameters U501.01 ... U501.50); see [804]
 - LU = Length Unit = The unit of length defined by the position-feedback scaling factor (PSF). The PSF is specified by means of P169/P170 [330] if the motor encoder is used and by means of P155/P156 [335] if an external machine encoder is used.


1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_799_e.vsd	Function diagram	
Cover sheet					08.01.02	MASTERDRIVES MC	- 799 -

MASTERDRIVES MC function diagram - List of contents of the technology option


Contents	Sheet	Contents	Sheet	Contents	Sheet
General, input/output signals		Positioning modes of operation			
Cover sheet	799	Set-up mode	819		
List of contents	800	Homing procedure	821		
Embedding the technology in the basic unit	801	Reference point setting on the fly	822		
Technology overview, operating mode manager	802	MDI mode (point-to-point positioning)	823		
Machine data	804	Control mode	825		
Parameter download file "Positioning via bus"	806	Automatic positioning mode	826		
Positioning control signals	809	Entering and editing automatic programs	828		
Positioning status signals	811	Roll feeding	830		
Digital inputs/outputs for positioning	813				
Evaluation and control of position detection	815	Synchronism			
Output and release of setpoints	817	Synchronism operating mode (overview)	831		
Faults, alarms, basic unit control bits	818	Virtual master axis	832		
Enabling with PIN number	850	Real master with deadtime compensation	833		
		Engaging/disengaging actions catch-up	834		
		Engaging/disengaging actions catch-up	834a		
		Electronic gearbox, function changeover	835		
		Generation of position setpoint	836		
		Catch-up	837		
		Cam	839		
		Cam 1 table with 400 points	839a		
		Cam 2 tables with 200 points each	839b		
		Cam 4 tables with 100 points each	839c		
		Cam 8 tables with 50 points each	839d		
		Cam with max. 8 tables in variable configurations	839e		
		Synchronization, displacement angle setting	841		
		Synchronism - Synchronization	841a		
		Position correction, referencing	843		
		Master setpoint correction	845		
		Master setpoint correction compatible mode	845a		
		Master setpoint correction speed path	845b		
		Master setpoint correction position path	845c		
		Synchronism status signals	846		

1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_800_e.vsd	Function diagram		- 800 -
List of contents				08.01.02	MASTERDRIVES MC		





1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_802_e.vsd	Function diagram		- 802 -
Technology overview, operating mode manager				08.01.02	MASTERDRIVES MC		



<2>

I = Needed for incremental encoder (resolver, ERN encoder, pulse encoder...)
A = Needed for absolute-value encoder (EQN, SSI, ...)
W = Needed for roll feeding

MD No.	I A W	Name (Factory setting) [Page in function diagram]	Range of values
MD1	I A W	Position-encoder type / axis type (1) Reset after an alteration of technology [RST] [809.4] or switch power on/off	0 = Axis does not exist 1 = Axis with incremental position encoder (resolver, ERN encoder, pulse encoder) 2 = Axis with absolute position encoder 3 = Roll feed
MD2	I A W	Axis assignment (1) Name give to the axis for automatic mode	1 = X axis 2 = Y axis 3 = Z axis 4 = A axis 5 = B axis 6 = C axis
MD3	I	Reference-point coordinate (0)	[821.4] -999 999 999... 999 999 999 LU
MD4	I	Reference-point offset (0)	[821.5] -999 999 999... 999 999 999 LU
MD5	I	Reference-point approach (1)	[821.3] 1 = Reference point to right of proximity switch 2 = Reference point to left of proximity switch 3 = Set reference point 1... 19 999 999 [x 1000 LU/min]
MD6	I	Reference-point reducing velocity (500)	[821.3] 1... 19 999 999 [x 1000 LU/min]
MD7	I	Reference-point approach velocity (5000)	[821.3] 1... 19 999 999 [x 1000 LU/min]
MD8		0 = Homing with bero and zero mark 1 = Homing with bero only 2 = Homing with zero mark only	[822] -999 999 999... 999 999 999 LU
MD10	A	Position-encoder alignment (0) (offset for absolute-value encoder)	[815.4] -999 999 999... 999 999 999 LU
MD11	I A W	Linear/rotary axis length (4096)	[836.6] [837.3] [841.7] 0 = Linear axis >0 = Rotary axis 1... 999 999 999 LU = Length of rotary axis
MD12	I A	Software limit switches - negative, for linear axis (-999 999 999)	[819.7] [823.7] -999 999 999... 999 999 999 LU
MD13	I A	Software limit switches - positive, for linear axis (999 999 999)	[819.7] [823.7] -999 999 999... 999 999 999 LU
MD14	I A W	Following error monitoring - at standstill (100)	[818.6] 1... 100 000 LU
MD15	I A W	Following error monitoring - in motion (20 000)	[818.6] 1... 999 999 999 LU
MD16	I A W	In position - timer monitoring (500)	[811.4] 10... 99 999 ms
MD17	I A W	In position erreicht - exact stop (100)	[811.4] 1... 99 999 LU
MD18	I A W	Acceleration (1000)	[819.5] [823.4] 1... 99 999 [x 1000 LU/s ²]
MD19	I A W	Deceleration (1000)	[819.5] [823.5] 1... 99 999 [x 1000 LU/s ²]
MD20	I A W	Deceleration for collision (1000) for autom. mode	0... 99 999 [x 1000 LU/s ²]
MD21	W	Jerk limiting - positive for roll feeding (0)	[830] 1... 999 999 [x 1000 LU/s ²]
MD23	I A W	Traversing velocity - maximum (12 288) must be = P205 [340.2]	[821.5] [825.5][837.2] 0... 19 999 999 [x 1000 LU/min]
MD24	I A W	M functions - output type (1) for automatic mode	1 = During positioning, time-driven 2 = During positioning, acknowledge-driven 3 = Before positioning, time-driven 4 = Before positioning, acknowledge-driven 5 = After positioning, time-driven 6 = After positioning, acknowledge-driven 4... 99 999 ms
MD25	I A W	M functions output time (500) for automatic mode	0 = Time override active
MD26	I A W	Time override (1) for MDI and automatic mode	1 = Time override inactive

MD-No.	I A W	Name (Factory setting) [Page in function diagram]	Range of values
MD29	W	Acceleration breakpoint - velocity for roll feeding (0)	[830.2] 1... 1 500 000 [x 1000 LU/min] 0 = inactive
MD30	W	Deceleration breakpoint - velocity for roll feeding (0)	[830] 1... 1 500 000 [x 1000 LU/min] 0 = inactive
MD31	W	Accelerating breakpoint - acceleration for roll feeding (0)	[830] 1... 99 999 [x 1000 LU/s ²] 0 = inactive
MD32	W	Deceleration breakpoint - deceleration for roll feeding (0)	[830] 1... 99 999 [x 1000 LU/s ²] 0 = inactive
MD33	W	Constant travel time for roll feeding (0)	[830] 1... 99 999 ms 0 = inactive
MD34	W	Pre-position reached - lead time for roll feeding (0)	[830] 1... 99 999 ms 0 = inactive
MD35	W	Pre-position reached - output time for roll feeding (0)	[830] 1... 99 999 ms 0 = inactive
MD36	W	Acceleration overshoot (0)	[830] 0... 100% (for roll feeding) 0 = Standard response
MD37	W	Response after abort (0) for roll feeding	[830] 1 = Approach last target position with no evaluation of direction of movement 2 = Approach last target position with evaluation of direction of movement
MD38	I A W	Backlash compensation (0)	0... 9 999 LU 1 = Preferred position positive (no backlash compensation calculated during first positive traversing movement)
MD39	A	Backlash compensation - preferred position (1) with absolute position encoder	2 = Preferred position negative (no backlash compensation calculated during first negative traversing movement)
MD40	I A W	Backlash compensation - velocity limitation (999)	1... 999 [x 1000 LU/min] 0 = inactive
MD41	I A W	Acceleration time, operating mode "reference-point approach/control" (1000)	[821.4] [825.5] 1... 99 999 ms (from 0 to MD23 [340.2]) 0 = inactive
MD42	I A W	Deceleration time, operating mode "reference-point approach/control" (1000)	[821.4] [825.5] 1... 99 999 ms (from MD23 to 0 [340.2]) 0 = inactive
MD43	I A W	Deceleration time during errors (1000) e.g. when following error > MD15	[818.7] 1... 99 999 ms (from MD23 to 0) 0 = inactive (jump function)
MD44	I A W	External block change - setting (0) for automatic mode	0 = Warning at end of NC block 1 = No warning at end of NC block
MD45	I A W	Digital inputs E1... E6 for positioning - function 1 (0)	[813.3] 0... 9 (range of values per decade)
MD46	W	Digital inputs E1... E6 for positioning - function 2 (0)	[813.5] 0... 4 (range of values per decade)
MD47	I A W	Digital outputs A1... A6 for positioning - funktion 1 (0)	[813.3] 0... 6 (range of values per decade)
MD48	W	Digital outputs E1... E6 for positioning - function 2 (0)	[813.5] 0... 5 (range of values per decade)
MD49	I A W	Precontrol - velocity Evaluation factor (0)	[817.6] 0... 150 %
MD50	I A W	Precontrol - Acceleration Evaluation factor (0)	[817.5] 1... 99 999 [x 1000 LU/s ²] 0 = Acceleration precontrol switched off

1

2

3

4

5

6

7

8

Technology option

V1.6 fp_mc_804_e.vsd

Function diagram

Machine data

08.01.02

MASTERDRIVES MC

- 804 -

Parameter download file for controlling positioning / synchronization via the CBx field-bus interface (e.g. via PROFIBUS DP)

By means of this SIMOVIS / DriveMonitor download file, 10 process-data words are assigned to each field-bus telegram in the transmit and receive directions in accordance with Ch. 2, "Description of functions" (see manual "Motion Control for MASTERDRIVES MC and SIMATIC M7")

This download file is located on your SIMOVIS / DriveMonitor CD-ROM or floppy disk under the following name:



SIMOVIS for DOS:

- **POS_1_1.MCD+POS_1_1.M2D**
for Compact PLUS units
(Download both files)

- **POS_1_1.SCD+POS_1_1.S2D**
for compact and chassis-type units with CUMC
(Download both files)



SIMOVIS / DriveMonitor for WINDOWS 95 and higher:

- **POS_1_1.DNL**
(Download this file. Is equally valid for Compact PLUS, Compact and chassis-type units)

Communication - General:
P53 = 7 ; Parameter access from CBx, PMU and USS
P722.1 = 500 ; Telegram OFF time 500 ms [120.1]

CBx receive word 1

Connect up basic unit control bits from CBx[120] ⇒ [180]:
P554.1 = 3100 ; [OFF1] from bit 0
P555.1 = 3101 ; [OFF2] from bit 1
P558.1 = 3102 ; [OFF3] from bit 2
P561.1 = 3103 ; [ENC] Inverter release from bit 3
P565.1 = 3107 ; [ACK_F] Fault acknowledgement from bit 7

CBx receive words 2 and 3

Connect up position control bit from CBx [120] ⇒ [809]:
U530 = 3032 ; Receive words 2 and 3 (bytes 2-5) = Positioning control word

CBx receive word 4

Connect up synchronization control bits from CBx [120] ⇒ [832...839]:

U619 = 3400 ; [SET_T] Set table	[839.4] from bit 0
U612.2 = 3402 ; [SST] Eng./diseng. trigger signal	[834.2] from bit 2
U621 = 3403 ; [SYN_T] Synchronizing table	[839.4] from bit 3
U650 = 3404 ; [TABLE_NO] Select. of current table	[839.7] from bit 4
U684.2 = 3407 ; [ST_VM] START virtual master	[832.2] from bit 7
U657.1 = 3408 ; [FUNCTION; Bit 0]	[836.4] from bit 8
U657.2 = 3409 ; [FUNCTION; Bit 1]	[836.4] from bit 9
U656.1 = 3410 ; [OPERATION; Bit 0]	[834.5] from bit 10
U656.2 = 3411 ; [OPERATION; Bit 1]	[834.5] from bit 11
U612.1 = 3412 ; [SSC] Eng./diseng. action permanent	[834.2] from bit 12
U684.3 = 3414 ; [S_VM] SET virtual master	[832.2] from bit 14
U684.1 = 3415 ; [R_VM] RESET virtual master	[832.2] from bit 15

CBx transmit word 1

Connect up basic unit control bits [200] [210] to CBx word 1 [125] with the help of the binector / connector converter U076/K431 [720]

U076.1 = 100 ; Bit 0 from K431 = [RTS]	1 = Ready for switch-on
U076.2 = 102 ; Bit 1 from K431 = [RDY]	1 = Ready for operation
U076.3 = 104 ; Bit 2 from K431 = [IOP]	1 = Operation
U076.4 = 106 ; Bit 3 from K431 = [FAULT]	1 = Fault
U076.5 = 108 ; Bit 4 from K431 = [OFF2]	0 = OFF2
U076.6 = 110 ; Bit 5 from K431 = [OFF3]	0 = OFF3
U076.7 = 114 ; Bit 6 from K431 = [WARN]	1 = Alarm
U076.8 = 0 ; Bit 7 from K431 = 0 (Reserve)	
U076.9 = 136 ; Bit 8 from K431 = [SMAX]	0 = Overspeed [480]
U076.10 = 144 ; Bit 9 from K431 = [OLC]	1 = Alarm, converter overload
U076.11 = 148 ; Bit 10 from K431 = [OTC]	1 = Alarm, converter overtemp.
U076.12 = 150 ; Bit 11 from K431 = [OTM]	1 = Fault motor overtemp.
U076.13 = 0 ; Bit 12 from K431 = 0 (Reserve)	
U076.14 = 0 ; Bit 13 from K431 = 0 (Reserve)	
U076.15 = 0 ; Bit 14 from K431 = 0 (Reserve)	
U076.16 = 0 ; Bit 15 from K431 = 0 (Reserve)	
U952.89 = 4 ; Nest binector / connector converter in time slot T4	
P734.1 = 431 ; Connect up its output K431 to CBx word 1	

CBx transmit word 2

Connect up fault number and alarm number [510] to the CBx [125]:
P734.2 = 250

CBx transmit words 3 and 4

Connect up positioning status word [811] to the CBx [125]:
P734.3 = 315 ; Hi word to CBx transmit word 3
P734.4 = 315 ; Lo word to CBx transmit word 4

Nest technology in time slot

U953.32 = 4	; Nest positioning technology in time slot T4
	; (= 3.2 ms with 5 kHz clock frequency) [802.7]
U953.34 = 4	; Nest virtual master in T4 [832]

Establishing connection between pos. controller and speed controller via ramp-function generator

P443.1 = 131	; Pos. controller output [340.8] to ramp-function gen. [310.1]
P220.1 = 75	; Connect up ramp-function generator output [320.8] to speed controller input [360.1]
P462.1 = 0	; Acceleration time = 0 [320.3]
P464.1 = 0	; Deceleration time = 0 [320.3]

Release for position controller [340.3] (see also [817])

P210.1 = 1	; Release position controller 1 permanently to "1"
P211.1 = 104	; Release position controller 2 from status word 1, bit 2 "Operation"
P213 = 305	; Release controller

Connecting up speed precontrol from technology:

P209.1 = 312	; Connect up speed precontrol value [817] to adding point behind speed controller [340.7]
--------------	---

Connecting up digital inputs / outputs for positioning

P647.1 = 3	; Input E4 = Terminal X101.6 = Adoption of actual position ; into the measured-value memory with rising ; edge [90.5] [330.5]
P651.1 = 311	; Outputs A1, A2, A3 from technology [813]
P652.1 = 312	; ... ⇒ digital output terminals X101.3...5
P653.1 = 313	; ... [90.5]

Connecting up technology ⇔ position sensing motor encoder slot C

P178 = 20	; Digital input DE6 terminal X101.8 [90.5] as rough-pulse ; proximity switch for position detection [330.5]
P172 = 302	; Position setting value [815.5] ⇒ [330.5]
P174 = 301	; Position correction value [815.5] ⇒ [330.5]
P184 = 303	; Position offset [815.5] ⇒ [330.7]
U535 = 120	; Actual offset [330.8] ⇒ [815.3]
U539 = 122	; Position measured value from position memory [330.7] ⇒ [815.3]


Connecting up synchronous-operation position correction [843] with position sensing slot C [330]:


U666 = 212	; "Start position correction" by means of "Meas. val. valid" [330.7]
U665 = 122	; "Pos. meas. value" to "Actual position for interrupt" [330.7]


Configuration of the virtual master axis

U683 = 1	; Specification of the speed setpoint in ; [10 LU/min] [832.2]
----------	---

1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_806_e.vsd	Function diagram	
Parameter download file "Positioning via bus"					23.11.01	MASTERDRIVES MC	- 806 -







<1> Example of configuring the digital inputs for positioning:
 MD45=7xxxxx) ==> Digital input, terminal X101.8 [90] =
 Reference-point proximity switch U536.06 = 20)

<2> Example of assigning the digital outputs for positioning:
 MD47 = xxx4xx ==> Bineror B313 = "M change from M97"


<3> Double assignment of an input or output with more than one function is not premitted.


<4> The measured position value memory is used for this function, and one of the digital inputs, terminal 6 or 7, must be used [90.3].

<5> Function 1 - 3 for roller feed only

<6> For roller feed only


1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_813_e.vsd	Function diagram	
Digital inputs / outputs for positioning					24.10.01	MASTERDRIVES MC	- 813 -





1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_817_e.vsd	Function diagram	
Setpoint output and enabling					09.01.02	MASTERDRIVES MC	- 817 -

Up to V1.0, these 3 signals from the basic unit were not permanently connected up but had to be connected up via U529.1-3.




Set-up mode (position-controlled jogging with limit-switch evaluation)

<1>

Sampling time for positioning

U953.32 = (20)

Recommended: U953.32=4



<1> The software limit switches are only evaluated on incremental position encoders if the axis is referenced (status bit [ARFD]=1)


1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_819_e.vsd	Function diagram	- 819 -
Set-up mode					08.01.02	MASTERDRIVES MC	

<1> The homing position direction of approach in MD5 must correspond to the parameterization of position sensing (e.g.. P183 if the motor encoder is used in slot C [330.2]), i.e.:
 MD5 = 1 ==> increasing positions from A to B ==> P183 = xx1x
 MD5 = 2 ==> decreasing positions from A to B ==> P183 = xx2x

<2> If the technology option F01 in MASTERDRIVES MC is used, the "Homing position setting value" in position sensing (e.g. P176 [330]) is not required

<3> The BERO must be adjusted mechanically or via P188 [330.2] such that the falling edge of the BERO signal does not fall together with the encoder zero position (e.g. as can be observed at KK090 [550])

<4> **Special case MD5=3: Directly set homing position without approach:**



Set position setpoint and actual value to MD3
 (Beforehand, traverse through any displacement path MD4 with speed MD6)

<5> Acceleration/deceleration times MD41/42 refer to a traversing action from 0 to MD23 or from MD23 to 0.


<6> Homing with automatic reversal at reversing cam right and/or left, see [813.4]

Sampling time for positioning

U953.32 = ___(20)


Recommended: U953.32 = 4

Special case: Bero and rotor zero position (as shown)
 Special case: Homing with bero only: MD8 = 1
 Special case: Homing with rotor zero position only or zero pulse only: MD8 = 2




1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_821_e.vsd	Function diagram		
Homing procedure operating mode				08.01.02	MASTERDRIVES MC		- 821 -

Reference point setting on the fly
 (acts in control, setup, MDI and automatic)
 For synchronism, see [843]



<1> During referencing, only the position setpoint and actual value are corrected by the same amount in each case. No compensation movement takes place.
 <2> Referencing on the fly is enabled dynamically with "Enable referencing" (binector input U675.1).
 The interrupt-generating digital inputs of terminal 6 or 7 are parameterized via MD46. Referencing is activated by the signal "Measured position value valid".

1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_822_e.vsd	Function diagram	- 822 -
Reference point setting on the fly					09.01.02	MASTERDRIVES MC	




Control mode (speed-controlled jogging without limit-switch evaluation)


Sampling time for positioning

U953.32 = (20)

Recommended: U953.32=4




1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_825_e.vsd	Function diagram	
Control mode					08.01.02	MASTERDRIVES MC	- 825 -



Entering and editing automatic NC programs by means of parameters U571... U590


Proceed as follows in order to enter or edit a block (see also parameter list):




1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_828_e.vsd	Function diagram		- 828 -
Entering and editing automatic programs				08.01.02	MASTERDRIVES MC		

Roll feeding (possible in MDI and automatic modes)


See Function description, Ch. 5.2.2



1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_830_e.vsd	Function diagram		
Roll feeding				08.01.02	MASTERDRIVES MC	- 830 -	




1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_831_e.vsd	Function diagram	
Synchronism operating mode (overview)					08.01.02	MASTERDRIVES MC	- 831 -



Should be calculated in the same time slot as the synchronization block.

Real master with speed-dependent deadtime compensation (introduced with V1.3)




<1> Typical setting values for U424 depending on the master value source:

- approx. 3 ms with external machine encoder
- approx. 6 ms with motor encoder
- approx. 10 ms if input value is coming from SIMOLINK


<2> It is recommended to use the measured actual speed if possible (U422.03>0)


<3> You can normally set the axis cycle lengths U425.1 and U425.2 to the same value.

1	2	3	4	5	6	7	8
Optional free block			V1.6	fp_mc_833_e.vsd	Function diagram		- 833 -
Synchronism - real master with deadtime compensation				08.01.02	MASTERDRIVES MC		




1	2	3	4	5	6	7	8
Technology Option				V1.6	fp_mc_834_e.vsd	Function diagram	
Synchronism - engaging/disengaging actions catch-up				08.01.02		MASTERDRIVES MC	- 834 -






1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_835_e.vsd	Function diagram		- 835 -
Synchronism - electr. gearbox, function changeover				08.01.02	MASTERDRIVES MC		





1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_836_e.vsd	Function diagram	
Synchronism - generation of position setpoint					03.09.01	MASTERDRIVES MC	- 836 -


<1> The axis is first traveled at "catch-up setpoint speed" until the halt position in the required direction of rotation can be approached.
 If the position is to be reached in the forward direction, a positive speed setpoint must be input.
 If the position is to be reached in the reverse direction, a negative speed setpoint must be input.
 <2> with intermediate approach of setpoint speed
 <3> without intermediate approach of setpoint speed
 <4> After completion of catch-up, the angular synchronism must be explicitly established, e.g. by linking the message "Catch-up finished" with the command "Synchronize master value" (U676-820 [841.2])
 <5> Mode: 1=With ramp-up/ramp-down
 0 = Without ramp-up/ramp-down





[CU_SP] B (0) .01
 [CU_EN] B (0) .02
 [CU_DR] B (1) .03
 [CU_TR] B (0) .04
 0 = catch-up
 1 = halt
 Enable positioning
 Mode <5>
 Trig. stop position transfer
 Rounding mode U649(0)
 0 = Rounding does not take effect on sudden reduction of the input value during ramp-up
 1 = Rounding always takes effect.























1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_841_e.vsd	Function diagram	
Synchronism - Synchronization, displacement angle setting (introduced with V1.3)					08.01.02	MASTERDRIVES MC	- 841 -




1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_841a_e.vsd	Function diagram	- 841a-
Synchronization with window / Synchronization - Synchronization					08.01.02	MASTERDRIVES MC	




1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_843_e.vsd	Function diagram	
Synchronism - position correction, referencing				09.01.02	MASTERDRIVES MC		- 843 -







1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_845a_e.vsd	Function diagram	
Master setpoint correction compatible mode					03.09.01	MASTERDRIVES MC	- 845a -



1	2	3	4	5	6	7	8
Technology option			V1.6	fp_mc_845b_e.vsd	Function diagram		- 845b -
Master setpoint correction speed path				08.01.02	MASTERDRIVES MC		



1	2	3	4	5	6	7	8
Technology option				V1.6	fp_mc_845c_e.vsd	Function diagram	
Master setpoint position path					08.01.02	MASTERDRIVES MC	- 845c-



1	2	3	4	5	6	7	8
Technology Option			V1.6	fp_mc_846_e.vsd	Function diagram		- 846 -
Synchronism status signals				03.09.01	MASTERDRIVES MC		

Enabling of the "F01 technology option" (positioning and synchronization)

It is necessary that the F01 technology option has been enabled:

The F01 technology option can only be used with MASTERDRIVES MC units which have been delivered ex-works with the enabled F01 option or for which this option has been enabled retrospectively by means of a PIN number. The display parameter n978 can be used to check if the F01 is present:

n978 = 2 ==> Technology option F01 is enabled for 500 h (from V1.31)
 n978 = 1 ==> F01 technology option has been permanently enabled
 n978 = 0 ==> F01 technology option has been disabled



The technology function remains enabled even after a software update and does not have to be entered again after new software has been loaded into the flash EPROM. From version V1.31 onwards, temporary enabling is indicated by the value 2 in n978.

Retrospective enabling of the F01 technology function (involves extra costs):

Proceed as follows if you want to permanently enable the F01 technology option retrospectively

- 1) Determine the factory serial number of the MASTERDRIVES unit electronics. There are two ways of doing this:
 - a) From parameters U976.01 and U976.02, you can read out the last 8 figures of the factory serial number which are necessary for determining the PIN number.
 (Example: U976.01 = 3032, U976.02 = 4198 ==> Factory serial number = ... 30324198)
 - b) The serial number can also, if necessary, be obtained from a MASTERDRIVES unit without connecting it to the supply.
 - In the case of Compact PLUS units, it is on the sheet accompanying the delivery note or on the electronics PC board in the unit (remove side cover), e.g. "RFU80982510106"
 - In the case of Compact and chassis-type units, it is on the upper connector strip on the rear of the CUMC basic electronics board, e.g. "Q6970730324198"
- 2) Contact your nearest Siemens branch in order to purchase the PIN number which matches your serial number. Quote the last eight figures of the serial number.
- 3) After you have obtained the PIN number, enter it in parameters U977.1 and U977.2.
- 4) Switch off the power supply to the electronics and then switch it on again.
- 5) The F01 technology option is now enabled. You can check this by referring to n978 (see above)

Caution: If the PIN-No. U977 is subsequently changed, enabling of the technology is reset (n978=0).



Special PIN number

Temporary enabling of the F01 technology option (free of charge):

For all units and electronics boards, the F01 technology option can be enabled free of charge with a special PIN No.. This can be done once for a trial period of 500 hours. This time can be used for testing purposes or for using substitute units which have been ordered without the F01 option as long as the PIN number has not yet been received. The operating-hours counter (r825) determines when this time has expired. Only that time is counted during which the drive is on. After the 500 hours have expired and the voltage supply has been turned off, the F01 option is disabled again unless the 'normal' PIN has been entered in the meantime. The 500 hours can no longer be interrupted (e.g. by changing the PIN entries).

Input of the special PIN number can only be done via the PMU. The special PIN is the same for all units and is as follows

U977.1= 0727, U977.2 = 0101

Enabling for units with software version 1.1 (free of charge):

In the case of units which have been supplied with software version V1.1, an individual serial number has not been explicitly entered. In this case, permanent enabling of the F01 technology option when your equipment is upgraded with a new software version is always possible. If you have version V1.1, the following table shows the 4 possible serial numbers and the matching PIN numbers which can be read out in U976 in order to enable the function.

FID U976.1		PIN U976.2		FID U977.1		PIN U977.2		FID U976.1		PIN U976.2		FID U977.1		PIN U977.2		
0000	0000	==>	9970	5525		FFFF	FFFF	==>	9978	0025						
0000	FFFF	==>	6682	5525	0000	2800	==>	1970	5543							
1	2		3		4		5		6		7		8			
Technology option								V1.6		fp_mc_850_e.vsd		Function diagram		- 850 -		
Enabling with PIN number								08.01.02		MASTERDRIVES MC						