

Three-phase induction motor with direct-on-line starter and braking unit 3RW21...1BG01

- A1 3RW21 braking unit
- F1 Semiconductor fuses
- F4 Control fuse (or m.c.b.)
- K1 Main contactor
- K2 Brake contactor
- S1 Pushbutton »BRAKE«
- S2 Pushbutton »START«
- Q1 Motor-protection circuit-breaker
- M1 Motor

Setting potentiometers – braking (A1):

- M_B Braking torque
- t_A Braking time

