


3.37 端子板 30 (TB30)

功能图

9099 - 一览	2409
9100 - 电位隔离数字输入端 (DI 0 ... DI 3)	2410
9102 - 电位隔离数字输出端 (DO 0 ... DO 3)	2411
9104 - 模拟输入端 (AI 0 ... AI 1)	2412
9106 - 模拟输出端 (AO 0 ... AO 1)	2413

图 3-356 9099 - 一覽







图 3-357 9100 - 电位隔离数字输入端 (DI 0 ... DI 3)

图 3-358 9102 - 电位隔离数字输出端 (DO 0 ... DO 3)






图 3-360 9106 - 模拟输出端 (AO 0 ... AO 1)

