

ControlUnit	Firmware Version	Internet Download	Internal Version ID	Upgrade/Downgrade Options				STARTER		Startdrive	
				< V4.5.x	V4.5.x	V4.6.x	V4.7.x	Version	Support package for existing STARTER installations	Version	Support package
SINAMICS G120P											
CU230P-2	V4.7 SP6 HF4	109482659	V04.70.83.18	---	---	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	--- Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	---	D	U/D ¹⁾				
	V4.7 SP6 HF2	---	V04.70.83.11	---	---	D	U/D ¹⁾				
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	---	D	U/D ¹⁾				
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	---	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	---	D	U/D ¹⁾				
	V4.7 HF8	92554110	V04.70.35.19	---	---	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---
	V4.7 HF3	---	V04.70.35.08	---	---	D	U/D ¹⁾				
	V4.6 HF17	67385235	V04.60.21.35	---	---	U/D ¹⁾	U	V4.3 SP2	---	---	---
	V4.5 for CU230P-2 not available	---	-----	---	---	---	---				
≤ 4.4	---	-----	---	---	---	---					
SINAMICS G120											
CU240B-2	V4.7 SP6 HF4	109482659	V04.70.83.18	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	--- Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	D	D	U/D ¹⁾				
	V4.7 SP6 HF2	---	V04.70.83.11	---	D	D	U/D ¹⁾				
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	D	D	U/D ¹⁾				
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	D	D	U/D ¹⁾				
	V4.7 HF8	92554110	V04.70.35.19	---	D	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---
	V4.7 HF3	---	V04.70.35.08	---	D	D	U/D ¹⁾				
	V4.6 HF17	67385235	V04.60.21.35	---	D	U/D ¹⁾	U	V4.3 SP2	---	---	---
	V4.5 HF11	72841234	V04.50.30.16	---	U/D ¹⁾	U	U	V4.3 SP1	---	---	---
< V4.5	---	-----	---	---	---	---					
CU240E-2	V4.7 SP6 HF4	109482659	V04.70.83.18	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	--- Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	D	D	U/D ¹⁾				
	V4.7 SP6 HF2	---	V04.70.83.11	---	D	D	U/D ¹⁾				
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	D	D	U/D ¹⁾				
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	D	D	U/D ¹⁾				
	V4.7 HF11	92554110	V04.70.35.24	---	D	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---
	V4.7 HF8	---	V04.70.35.19	---	D	D	U/D ¹⁾				
	V4.7 HF3	---	V04.70.35.08	---	D	D	U/D ¹⁾				
	V4.6 HF17	67385235	V04.60.21.35	---	D	U/D ¹⁾	U	V4.3 SP2	---	---	---
V4.5 HF11	72841234	V04.50.30.16	---	U/D ¹⁾	U	U	V4.3 SP1	---	---	---	
< V4.5	---	-----	---	---	---	---					
CU250S-2	V4.7 SP6 HF4	109482659	V04.70.83.18	---	---	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	--- Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	---	D	U/D ¹⁾				
	V4.7 SP6 HF2	---	V04.70.83.11	---	---	D	U/D ¹⁾				
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	---	D	U/D ¹⁾				
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	---	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	---	D	U/D ¹⁾				
	V4.7 HF11	92554110	V04.70.35.24	---	---	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---
	V4.7 HF8	---	V04.70.35.19	---	---	D	U/D ¹⁾				
V4.7 HF3	---	V04.70.35.08	---	---	D	U/D ¹⁾					
V4.6 HF17	67385235	V04.60.21.35	---	---	U/D ¹⁾	U	V4.3 SP2	---	---	---	
SINAMICS G120C											

	V4.7 SP6 HF4	109482659	V04.70.83.18	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	D	D	U/D ¹⁾					
	V4.7 SP6 HF2	---	V04.70.83.11	---	D	D	U/D ¹⁾					
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	D	D	U/D ¹⁾					
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	D	D	U/D ¹⁾					
	V4.7 HF10	92554110	V04.70.35.23	---	D	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---	
	V4.7 HF8	---	V04.70.35.19	---	D	D	U/D ¹⁾					
	V4.7 HF3	---	V04.70.35.08	---	D	D	U/D ¹⁾					
	V4.6 HF17	67385235	V04.60.21.35	---	D	U/D ¹⁾	U	V4.3 SP2	---	---	---	
	V4.5 HF11	72841234	V04.50.30.16	---	U/D ¹⁾	U	U	V4.3 SP1	---	---	---	
	< V4.5	---	-----	---	---	---	---					
SINAMICS G120D												
CU240D-2	V4.7 SP6 HF4	109482659	V04.70.83.18	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	D	D	U/D ¹⁾					
	V4.7 SP6 HF2	---	V04.70.83.11	---	D	D	U/D ¹⁾					
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	D	D	U/D ¹⁾					
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	D	D	U/D ¹⁾					
	V4.7 HF11	92554110	V04.70.35.24	---	D	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---	
	V4.7 HF8	---	V04.70.35.19	---	D	D	U/D ¹⁾					
	V4.7 HF3	---	V04.70.35.08	---	D	D	U/D ¹⁾					
	V4.6 HF17	67385235	V04.60.21.35	---	D	U/D ¹⁾	U	V4.3 SP2	---	---	---	
	V4.5 HF11	72841234	V04.50.30.16	---	U/D ¹⁾	U	U	V4.3 SP1	---	---	---	
	< V4.5	---	-----	---	---	---	---					
CU250D-2	V4.7 SP6 HF4	109482659	V04.70.83.18	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	D	D	U/D ¹⁾					
	V4.7 SP6 HF2	---	V04.70.83.11	---	D	D	U/D ¹⁾					
	V4.7 SP6 HF1	---	V04.70.83.04	---	D	D	U/D ¹⁾					
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	D	D	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	D	D	U/D ¹⁾					
	V4.7 HF11	92554110	V04.70.35.24	---	D	D	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---	
	V4.7 HF8	92554110	V04.70.35.19	---	D	D	U/D ¹⁾					
	V4.7 HF3	---	V04.70.35.08	---	D	D	U/D ¹⁾					
	V4.6 HF17	67385235	V04.60.21.35	---	D	U/D ¹⁾	U	V4.3 SP2	---	---	---	
	V4.5 HF11	72841234	V04.50.30.16	---	U/D ¹⁾	U	U	V4.3 SP1	---	---	---	
	< V4.5	---	-----	---	---	---	---					
SINAMICS G110M												
	V4.7 SP6 HF4	109482659	V04.70.83.18	---	---	---	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	---	---	U/D ¹⁾					
	V4.7 SP6 HF2	---	V04.70.83.11	---	---	---	U/D ¹⁾					
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	---	---	U/D ¹⁾					
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	---	---	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3	---	V04.70.64.00	---	---	---	U/D ¹⁾					
	V4.7 HF11	92554110	V04.70.35.24	---	---	---	U/D ¹⁾	V4.4	SSP SINAMICS G120 V4.7	V13	---	
	V4.7 HF8	---	V04.70.35.19	---	---	---	U/D ¹⁾					
	V4.7 HF3	---	V04.70.35.08	---	---	---	U/D ¹⁾					
	V4.6 HF14	---	V04.60.21.28	---	---	---	U					
SINAMICS ET 200pro FC-2												
	V4.7 SP6 HF4	109482659	V04.70.83.18	---	---	---	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V14 Update 2 V13 SP1	---	Support Package for SINAMICS Firmware V4.7 SP6
	V4.7 SP6 HF3	---	V04.70.83.17	---	---	---	U/D ¹⁾					

	V4.7 SP6 HF2	---	V04.70.83.11	---	---	---	U/D ¹⁾				
	V4.7 SP6 HF1 ²⁾	---	V04.70.83.04	---	---	---	U/D ¹⁾				
	V4.7 SP3 HF2	109476335	V04.70.64.04	---	---	---	U/D ¹⁾	V4.4 SP1	SSP SINAMICS G120 V4.7 SP6	V13 SP1	Support Package for SINAMICS Firmware V4.7 SP3
	V4.7 SP3 HF1	---	V04.70.64.01	---	---	---	U/D ¹⁾				
SINAMICS G110											
	V1.21 ²⁾	---	V01.21.00.00	---	---	---	---				
SINAMICS G110D											
	V3.61 ²⁾	---	V03.61.00.00	---	---	---	---				

¹⁾ Upgrade/ Downgrade auf gleiche Major/Minor Version (z.B. V4.6 HFx <-> V4.6 HFx+n)

²⁾ aktueller Lieferstand

1) Upgrade/ downgrade to same major/minor version (e.g. V4.6 HFx <-> V4.6 HFx+n)

2) Actual delivery status