

Q: 交换机日志中，CNT 什么含义？

A: CNT: 重启次数，指交换机从上次复位为出厂设置以来的第N次重启次数，如下框1所示，冷启动后，CNT次数从26增加到27，该参数老版本交换机是用CNT标识，在新版本的交换机用Restart表示，如下所示。

System Event Log Table			
N	Cnt	Time	Event Text
1	26	00:00:21	Link up on port 4.
2	26	00:00:20	Fault state: No fault.
3	26	00:00:20	Link up on port 6.
4	26	00:00:11	Fault state: fault (Link down on port 6).
5	26	00:00:11	Link down on port 6.
6	26	00:00:11	Link up on port 5.
7	26	00:00:10	Link down on port 4.
8	26	00:00:10	Link down on port 3.
9	26	00:00:10	Link down on port 2.
10	26	00:00:10	Link up on port 1.
11	26	00:00:08	Device has not failed.
12	26	00:00:07	Redundancy role: client (HSR).
13	26	00:00:07	IP Parameters changed to: IP - 10.252.42.105, Mask - 255.255.255.0, Gateway - 10.252.42.105.
14	26	00:00:07	Cold start performed. <span style="color:red">2.</span>
15	27	00:00:01	Port Monitoring Barrier disabled.
16	27	00:00:01	Port Mirroring disabled.
17	27	16:42:55	Link down on port 1.
18	27	14:50:36	Fault state: fault (Link down on port 5).
19	27	14:50:36	Link down on port 5.
20	27	18:14:24	Fault state: No fault.
21	27	18:14:24	Link up on port 5.
22	27	17:26:08	Fault state: fault (Link down on port 5).
23	27	17:26:08	Link down on port 5.
24	27	15:06:14	Fault state: No fault.
25	27	15:06:14	Link up on port 5.
26	27	15:05:02	Fault state: fault (Link down on port 5).
27	27	15:05:02	Link down on port 5.
28	27	20:00:21	Link up on port 4.
29	27	20:00:20	Fault state: No fault.
30	27	20:00:20	Link up on port 6.
31	27	20:00:11	Fault state: fault (Link down on port 6).
32	27	20:00:10	Link down on port 6.
33	27	20:00:10	Link up on port 5.
34	27	20:00:10	Link down on port 4.
35	27	20:00:09	Link down on port 3.
36	27	20:00:09	Link down on port 2.
37	27	20:00:09	Link up on port 1.
38	27	20:00:08	Device has not failed.
39	27	20:00:07	Redundancy role: client (HSR).
40	27	20:00:07	IP Parameters changed to: IP - 10.252.42.105, Mask - 255.255.255.0, Gateway - 10.252.42.105.
41	27	20:00:07	Cold start performed. <span style="color:red">1.</span>
42	26	00:00:01	Port Monitoring Barrier disabled.
43	26	00:00:01	Port Mirroring disabled.
44	26	03:51:14	Link down on port 1.
45	26	03:51:14	Link up on port 1.

Restart	System Up Time	System Time	Severity	Log Message
41	09:25:24	Date/time not set	6 - Info	Spanning Tree: topology change detected.
41	08:24:48	Date/time not set	6 - Info	Link up on P0.15.
41	08:24:18	Date/time not set	6 - Info	Link down on P0.15.
41	07:29:01	Date/time not set	6 - Info	IP communication is possible. Remote logging activated.